QAI AEROSPACE

CAPABILITY LIST
JULY, 2017

PART NUMBER	DESCRIPTION
115.015	HYDRAULIC TEMPERATURE INDICATOR
117.902031	TURBINE OUTLET TEMPERATURE INDICATOR
122.444	TURBINE OUTLET TEMPERATURE INDICATOR
124.013	OIL TEMPERATURE & PRESSURE INDICATOR
124.014	OIL TEMPERATURE & PRESSURE INDICATOR
124.027	INTER TURBINE TEMPERATURE INDICATOR
124.029	INTER TURBINE TEMPERATURE INDICATOR
124.039	DUAL AMMETER
124.04	VOLTMETER
124.040	VOLTMETER
124.041	OIL TEMPERATURE & PRESSURE INDICATOR
124.043	OIL TEMPERATURE & PRESSURE INDICATOR
124.044	FUEL PRESSURE INDICATOR
124.045	OIL TEMPERATURE & PRESSURE INDICATOR
124.069	FUEL PRESSURE INDICATOR
124.1012	OIL TEMPERATURE & PRESSURE INDICATOR
124.1013	OIL TEMPERATURE & PRESSURE INDICATOR
124.1014	FUEL PRESSURE/LOAD METER
124.113	VOLTMETER
124.1149	OIL TEMPERATURE & PRESSURE INDICATOR
124.115	OIL TEMPERATURE & PRESSURE INDICATOR
124.1185	OIL TEMPERATURE & PRESSURE INDICATOR
124.193	INTER TURBINE TEMPERATURE INDICATOR
124.323	AMMETER
124.331	EGT INDICATOR
124.439	TRANSMISSION OIL PRESSURE INDICATOR
124.44	FUEL QUANTITY INDICATOR
124.443	DC AMMETER
124.444	TURBINE OUTLET TEMPERATURE INDICATOR
124.5	TEMPERATURE INDICATOR
124.503	DUAL OIL PRESSURE INDICATOR
124.511	TORQUE INDICATOR
124.545	FUEL QUANTITY INDICATOR
124.546	OIL TEMPERATURE & PRESSURE INDICATOR
124.549	OIL TEMPERATURE & PRESSURE INDICATOR
124.55	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
124.676	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
124.677	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
124.678	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
124.679	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR

124.838	TEMPERATURE INDICATOR
200	DIRECTIONAL GYRO
449	POWER SUPPLY
904	HORIZON GYRO
1432	ALTIMETER
1434	ALTIMETER
2816	TRIM MOTOR ACTUATOR
3459	CONTROL UNIT
3935	TURN AND SLIP INDICATOR
5257	TEMPERATURE PROBE
5586	BLOWER ASSEMBLY
5728	TURN AND SLIP INDICATOR
5932	ALTIMETER
6335	PRESSURE SWITCH
6445	FIRE OVERHEAT CONTROL CARD
7030	VERTICAL SPEED INDICATOR
7040	VERTICAL SPEED INDICATOR
7060	VERTICAL SPEED INDICATOR
7160	VERTICAL SPEED INDICATOR
7200	RATE OF CLIMB INDICATOR
7201	RATE OF CLIMB INDICATOR
7210	RATE OF CLIMB INDICATOR
7211	RATE OF CLIMB INDICATOR
8000	AIRSPEED INDICATOR
8025	AIRSPEED INDICATOR
8030	AIRSPEED INDICATOR
8100	AIRSPEED INDICATOR
8125	AIRSPEED INDICATOR
8130	AIRSPEED INDICATOR
8135	AIRSPEED INDICATOR
9000	TURN COORDINATOR
9130	HORIZONTAL SITUATION INDICATOR
9500	TURN AND SLIP INDICATOR
9501	TURN AND SLIP INDICATOR
9502	TURN AND SLIP INDICATOR
9550	TURN AND SLIP INDICATOR
9551	TURN AND SLIP INDICATOR
9552	TURN AND SLIP INDICATOR
9696	DC MOTOR
11760	RATE GYRO
12003	ALTIMETER
13503	ALTIMETER
17500	SEARCHLIGHT
31807	FLUX VALVE
31808	FLUX VALVE
33204	THERMOMETER
33205	DUAL THERMOMETER INDICATOR

33349	THERMOMETER
33350	DUAL THERMOMETER INDICATOR
33724	DUAL THERMOMETER INDICATOR
34970	THERMOMETER
35350	THERMOMETER
36101	GYRO HORIZON
38200	GYRO HORIZON
38204	GYRO HORIZON
38300	GYRO HORIZON
38314	GYRO HORIZON
41830	ROTOR RPM INDICATOR
42370	ROTOR RPM INDICATOR
42960	ROTOR RPM INDICATOR
42965	ROTOR RPM INDICATOR
50010	ANNUNCIATOR PANEL
50084	BLOWER MOTOR
50143	BLOWER MOTOR
50145	BLOWER ASS'Y
50234	HYDRAULIC PRESSURE TRANSMITTER
50579	HYDRAULIC PRESSURE TRANSMITTER
50629	HYDRAULIC PRESSURE TRANSMITTER
50871	PRESSURE TRANSDUCER
53500	ANNUNCIATOR
53860	WARNING ANNUNCIATOR PANEL
55670	LIGHT DIMMER
59410	FAN PERFORMANCE MONITOR
70129	TACHOMETER INDICATOR
70160	TACHOMETER INDICATOR
70285	ANTI-COLLISION LIGHT
73949	CONTROL GRIP ASSEMBLY
81579	NOMEN GRIP ASSEMBLY
86197	TRANSMITTER
95211	VOLTAGE REGULATOR
100524	HORIZONTAL SITUATION INDICATOR
101420	ENCODING ALTIMETER
101720	ALTIMETER
101730	ALTIMETER
101735	ALTIMETER
101750	ALTIMETER
102262	REMOTE ATTITUDE INDICATOR
102524	REMOTE ATTITUDE INDICATOR
102550	ATTITUDE INDICATOR
102630	REMOTE ATTITUDE INDICATOR
109290	RATE GYRO
112090	REMOTE ATTITUDE INDICATOR
117800	ATTITUDE INDICATOR
118550	HORIZONTAL SITUATION INDICATOR

118600	COURSE INDICATOR
129060	VERTICAL SPEED INDICATOR
129222	HORIZONTAL SITUATION INDICATOR
131070	ATTITUDE INDICATOR
133640	HORIZONTAL SITUATION INDICATOR
157800	GAS TEMPERATURE INDICATOR
200138	STATIC INVERTER
200139	STATIC INVERTER
200158	STATIC INVERTER
200169	STATIC INVERTER
200175	STATIC INVERTER
200176	STATIC INVERTER
200177	STATIC INVERTER
200181	DC TO DC CONVERTER
206112	DUAL TACHOMETER INDICATOR
206115	TORQUE INDICATOR
206116	TACHOMETER INDICATOR
206500	INSTRUMENT CLUSTER
233565	MOTOR DRIVEN VALVE
254030	DC VOLTMETER
260245	AC VOLTMETER
260246	AC VOLTMETER
260283	AC AMMETER
260287	AC AMMETER
304565	DUAL RATE SENSOR
400086	AIRCRAFT CLOCK
400201	AIRCRAFT CLOCK
400202	AIRCRAFT CLOCK
400216	CLOCK
400240	CLOCK
400250	CLOCK
400270	CLOCK
401894	2 AXIS SENSOR
473051	SMOKE DETECTOR
473054	SMOKE DETECTOR
520104	AC AMMETER
520108	AC AMMETER
520127	AC VOLTMETER
520479	AC VOLTMETER
522215	PRESSURE INDICATOR
522298	TURBINE OUTLET TEMPERATURE INDICATOR
522808	AC POWER MONITOR
523139	TACHOMETER INDICATOR
630000	BLOWER MOTOR
640000	BLOWER MOTOR
656520	FLUX VALVE
664543	FLUX VALVE

716879	FUEL INDICATOR
727790	AIRSPEED INDICATOR
748538	FUEL QUANTITY INDICATOR
748735	FUEL QUANTITY INDICATOR
749753	INDICATOR
764590	TANK PROBE, UPPER
764591	TANK PROBE, LOWER
764805	FUEL PROBE
766804	FUEL PROBE
788664	NR/NF INDICATOR
788864	NR/NF INDICATOR
794165	FUEL PROBE
794166	FUEL PROBE
864490	VOLTMETER
1168504	AIRSPEED INDICATOR
1918407	LIGHTING PANEL
2593691	VERTICAL GYRO
2594484	FLUX VALVE
4019759	DIRECTIONAL GYRO
4094489	GYRO HORIZON
4100579	FAN PERFORMANCE MONITOR
4168732	RETRACTABLE LIGHT
4168748	RETRACTABLE LIGHT
4168762	SEARCHLIGHT
4171072	RETRACTABLE LIGHT
4189941	WINDSHIEL WIPER SYSTEM
4202104	SEARCHLIGHT
4217212	RETRACTABLE LIGHT
4217228	SEARCHLIGHT
4219867	RETRACTABLE LIGHT
4226271	SEARCHLIGHT
4257624	RETRACTABLE LIGHT
4274479	SEARCHLIGHT
4296000	N ROTOR INDICATOR
4296788	SEARCHLIGHT
4307405	SEARCHLIGHT
4360404	SEARCHLIGHT
4361646	SEARCHLIGHT
5017567	PHASE ADAPTER
6481302	ANTI-COLLISION LIGHT
6482002	POWER SUPPLY
6485000	ANTI-COLLISION LIGHT
6485200	ANTI-COLLISION LIGHT
6829274	TORQUE INDICATOR
6896822	FUEL PUMP
7010133	FLUX VALVE
7028511	STROBE LIGHT

7090502	ANTI-COLLISION LIGHT
24929532	ENCODING ALTIMETER
32005023	TACH GENERATOR
39951213	TACHOMETER INDICATOR
41003285	SWITCH
83910001	HANDGRIP
83910004	HANDGRIP
83910051	HANDGRIP
88060263	TRANSMISSION PRESSURE GAUGE
420800001	BLOWER MOTOR
420800006	EVAPORATION MOTOR
446000275	VERTICAL SPEED INDICATOR
446001239	FUEL QUANTITY INDICATOR
446001265	FUEL QUANTITY INDICATOR
488001241	SELECTOR SWITCH
488069366	FUEL SELECTOR SWITCH
495269986	FUEL PROBE
621396231	COMPASS
4060001130	ANTI-COLLISION LIGHT
4700716860	REAR POSITION LIGHT
5040017908	GYRO HORIZON
5040031914	ATTITUDE GYRO
5040045901	GYRO HORIZON
5040045904	GYRO HORIZON
5040053901	ATTITUDE INDICATOR
5050010904	DIRECTIONAL GYRO
5050031903	DIRECTIONAL GYRO
5050031904	DIRECTIONAL GYRO
5050031930	DIRECTIONAL GYRO
5070020910	TURN AND BANK INDICATOR
5207137011	RMI
5209130004	HORIZONTAL SITUATION INDICATOR
6401497000	TEMPERATURE PROBE
9550176240	TORQUE TRANSMITTER
9580113720	TORQUE TRANSMITTER
5930143670158	FUEL LEVEL SWITCH
5930143670159	FUEL LEVEL SWITCH
5930143670160	FUEL LEVEL SWITCH
5930143819305	FUEL LEVEL SWITCH
5930143819306	FUEL LEVEL SWITCH
5930143819307	FUEL LEVEL SWITCH
5930145754605	FUEL LEVEL SWITCH
6340143998000	CONTROL UNIT
6610005809363	POSITION INDICATOR
6610005809690	POSITION INDICATOR
6610007582385	ATTITUDE INDICATOR
6610008087037	POSITION INDICATOR

6610008087038	POSITION INDICATOR
6610012590251	ENCODING ALTIMETER
6615011253869	MODE ANNUNCIATOR
6620011579266	TACHOMETER INDICATOR
6620012568370	DUAL TORQUE INDICATOR
6625004427047	AC AMMETER
6625144468309	VOLTMETER
6625144468310	AMMETER
6680005809557	OIL QUANTITY INDICATOR
6680143670161	TACH GENERATOR
6680144757331	TACH GENERATOR
6685001830351	TEMPERATURE INDICATOR
6685005570215	PRESSURE INDICATOR
6685007537668	OIL PRESSURE INDICATOR
6685008017587	TEMPERATURE INDICATOR
6685008978400	TEMPERATURE INDICATOR
6685011773442	TEMPERATURE INDICATOR
515E100	DISPLACEMENT GYRO
000-20382	OIL TEMPERATURE & PRESSURE INDICATOR
000-20439-2	TEMPERATURE & PRESSURE INDICATOR
000-20442-2	OIL TEMPERATURE & PRESSURE INDICAT0R
0003-007	ALTIMETER
006-5169-003	VHF COMMUNICATIONS TRANSCEIVER
006-5169-01	VHF COMMUNICATIONS TRANSCEIVER
006-5169-02	VHF COMMUNICATIONS TRANSCEIVER
006-5169-03	VHF COMMUNICATIONS TRANSCEIVER
006-5169-04	VHF COMMUNICATIONS TRANSCEIVER
01-003-1	EXHAUST GAS TEMPERATURE INDICATOR
01-004-1	EXHAUST GAS TEMPERATURE INDICATOR
01-0770285-11	ANTI-COLLISION LIGHT
01-0770285-21	ANTI-COLLISION LIGHT
01-0770905-01	ANTI-COLLISION LIGHT
01-200-102	ENCODING ALTIMETER
01-200-103	ENCODING ALTIMETER
01-200-105	ENCODING ALTIMETER
01-200-106	ENCODING ALTIMETER
017-22000-01	ANNUNICATOR DIMMER
017499-1	LIGHT ASSEMBLY
017500-11	SEARCHLIGHT
0202644-001	SEARCHLIGHT
0202644-002	SEARCHLIGHT
0202644-003	SEARCHLIGHT
0202644-004	SEARCHLIGHT
0202644-005	SEARCHLIGHT
020644-004	SEARCHLIGHT
020-960-001	FUEL QUANTITY TANK UNIT
022-100-000	COMPASS

022-100-010	COMPASS
022-100-020	COMPASS
022-100-110	COMPASS
022-100-120	COMPASS
022-200-000	COMPASS
022-200-010	COMPASS
022-200-011	COMPASS
022-200-020	COMPASS
022-200-031	COMPASS
022-200-041	COMPASS
022-200-110	COMPASS
022-200-120	COMPASS
022-201-041	COMPASS
022-210-031	COMPASS
022-210-041	COMPASS
022-210-120	COMPASS
022-220-031	COMPASS
022-220-041	COMPASS
022-220-120	COMPASS
022TA01-01	ALARM
022TA04-01	CONTROL WARNING SYSTEM
022TA05-01A	CONTROL WARNING SYSTEM
0230116-001	TRI LAMP SEARCHLIGHT
0230116-002	TRI LAMP SEARCHLIGHT
0230134-002	SEARCHLIGHT
0230134-003	SEARCHLIGHT
0230154-001	SEARCHLIGHT
0230154-002	SEARCHLIGHT
0230311-001	SEARCHLIGHT
0230311-003	SEARCHLIGHT
0230311-004	SEARCHLIGHT
0230311-005	SEARCHLIGHT
0230311-006	SEARCHLIGHT
0230311-007	SEARCHLIGHT
0230311-101	SEARCHLIGHT
0230311-103	SEARCHLIGHT
0230311-104	SEARCHLIGHT
0230311-105	SEARCHLIGHT
0230311-106	SEARCHLIGHT
0230311-107	SEARCHLIGHT
0230380-001	SEARCHLIGHT
0230380-002	SEARCHLIGHT
0230380-003	SEARCHLIGHT
0230380-101	SEARCHLIGHT
0230380-102	SEARCHLIGHT
0230380-111	SEARCHLIGHT
0230380-112	SEARCHLIGHT

0230380-201	SEARCHLIGHT
0230380-202	SEARCHLIGHT
0230380-211	SEARCHLIGHT
0230380-212	SEARCHLIGHT
0230390-001	SEARCHLIGHT
0230390-002	SEARCHLIGHT
0230390-101	SEARCHLIGHT
0230390-102	SEARCHLIGHT
0230390-201	SEARCHLIGHT
0230390-202	SEARCHLIGHT
0230397-001	SEARCHLIGHT
0230397-002	SEARCHLIGHT
0230636-001	SEARCHLIGHT
0230636-002	SEARCHLIGHT
0230636-003	SEARCHLIGHT
0230636-004	SEARCHLIGHT
0230636-005	SEARCHLIGHT
0230636-006	SEARCHLIGHT
0230636-007	SEARCHLIGHT
0230636-008	SEARCHLIGHT
0230636-009	SEARCHLIGHT
0230636-010	SEARCHLIGHT
0230636-011	SEARCHLIGHT
0230636-012	SEARCHLIGHT
0230644-001	TRI LAMP SEARCHLIGHT
0230644-002	TRI LAMP SEARCHLIGHT
0230697-101	SEARCHLIGHT
0230697-102	SEARCHLIGHT
0230697-201	SEARCHLIGHT
0230697-202	SEARCHLIGHT
0231102-001	SEARCHLIGHT
0231102-002	SEARCHLIGHT
0231102-003	SEARCHLIGHT
0231102-004	SEARCHLIGHT
0231102-005	SEARCHLIGHT
0231102-006	SEARCHLIGHT
0231102-007	SEARCHLIGHT
0231102-008	SEARCHLIGHT
0231241-101	SEARCHLIGHT
0231241-102	SEARCHLIGHT
0231241-201	SEARCHLIGHT
0231241-202	SEARCHLIGHT
0231318-101	SEARCHLIGHT
0231318-102	SEARCHLIGHT
0231318-201	SEARCHLIGHT
0231318-202	SEARCHLIGHT
0231370-001	SEARCHLIGHT

0231370-002	SEARCHLIGHT
027-003-001	FUEL QUANTITY TANK UNIT
027-003-002	FUEL QUANTITY TANK UNIT
027-003-003	FUEL QUANTITY TANK UNIT
027-003-004	FUEL QUANTITY TANK UNIT
027-003-005	FUEL QUANTITY TANK UNIT
027-003-006	FUEL QUANTITY TANK UNIT
027-003-013	FUEL QUANTITY TANK UNIT
028-025-001	FUEL QUANTITY TRANSMITTER
0306-003	DC VOLTMETER
0307-007	DC AMMETER
050052-1	BLOWER MOTOR
050084-4	FAN MOTOR
050084-6	BLOWER ASSEMBLY
050084-7	BLOWER ASSEMBLY
05088 CU09609168	SERVO MOTOR
05088-91D74-01	CABIN TEMPERATURE CONTROL
05088-91D74-1	SERVO CONTROL
05088-91D75-1	ACTUATOR
060-00016-0000	DIRECTIONAL GYRO
060-00026-0000	VERTICAL GYRO
060-00040-0100	3 AXIS SENSOR
060-00040-0200	3 AXIS SENSOR
060-0013-00	DIRECTIONAL GYRO
060-0013-01	DIRECTIONAL GYRO
060-0015-00	DIRECTIONAL GYRO
060-0016-00	DIRECTIONAL GYRO
060-0016-01	DIRECTIONAL GYRO
060-0026-00	VERTICAL GYRO
060-0037-00	ATTITUDE GYRO
060-0037-01	GYRO HORIZON
060-0037-02	GYRO HORIZON
060-0037-03	GYRO HORIZON
060-0038-00	GYRO HORIZON
060-0038-01	GYRO HORIZON
060-0038-02	GYRO HORIZON
060-0038-03	GYRO HORIZON
060-0038-04	GYRO HORIZON
060-0038-05	GYRO HORIZON
060-01078-0014	NAVIGATION RECEIVER
060-2600-15C	STATIC INVERTER
064-01009-0000	VHF COMMUNICATIONS TRANSCEIVER
064-01019-0000	VHF COMMUNICATIONS TRANSCEIVER
064-01019-0004	VHF COMMUNICATIONS TRANSCEIVER
064-01019-0005	VHF COMMUNICATIONS TRANSCEIVER
064-01019-0022	VHF COMMUNICATIONS TRANSCEIVER
064-01023-0000	VHF COMMUNICATIONS TRANSCEIVER

064-01053-0010	VHF COMMUNICATIONS TRANSCEIVER
064-01053-0011	VHF COMMUNICATIONS TRANSCEIVER
064-01053-0012	VHF COMMUNICATIONS TRANSCEIVER
064-01053-0030	VHF COMMUNICATIONS TRANSCEIVER
064-01053-0031	VHF COMMUNICATIONS TRANSCEIVER
064-01053-0032	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0010	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0011	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0012	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0030	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0031	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0032	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0040	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0041	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0042	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0050	VHF COMMUNICATIONS TRANSCEIVER
064-01054-0060	VHF COMMUNICATIONS TRANSCEIVER
064-01065-0100	VHF COMMUNICATIONS TRANSCEIVER
064-01084-0101	VHF COMMUNICATIONS TRANSCEIVER
064-1009-00	VHF COMMUNICATIONS TRANSCEIVER
064-1019-00	VHF COMMUNICATIONS TRANSCEIVER
064-1019-01	VHF COMMUNICATIONS TRANSCEIVER
064-1019-02	VHF COMMUNICATIONS TRANSCEIVER
064-1019-04	VHF COMMUNICATIONS TRANSCEIVER
064-1019-05	VHF COMMUNICATIONS TRANSCEIVER
064-1019-06	VHF COMMUNICATIONS TRANSCEIVER
064-1019-07	VHF COMMUNICATIONS TRANSCEIVER
064-1019-10	VHF COMMUNICATIONS TRANSCEIVER
064-1019-11	VHF COMMUNICATIONS TRANSCEIVER
064-1019-12	VHF COMMUNICATIONS TRANSCEIVER
064-1019-20	VHF COMMUNICATIONS TRANSCEIVER
064-1019-22	VHF COMMUNICATIONS TRANSCEIVER
064-1021-01	VHF COMMUNICATIONS TRANSCEIVER
064-1021-05	VHF COMMUNICATIONS TRANSCEIVER
064-1021-10	VHF COMMUNICATIONS TRANSCEIVER
064-1021-11	VHF COMMUNICATIONS TRANSCEIVER
064-1021-20	VHF COMMUNICATIONS TRANSCEIVER
064-1023-00	VHF COMMUNICATIONS TRANSCEIVER
064-1023-01	VHF COMMUNICATIONS TRANSCEIVER
064-1023-02	VHF COMMUNICATIONS TRANSCEIVER
064-1023-03	VHF COMMUNICATIONS TRANSCEIVER
064-1023-04	VHF COMMUNICATIONS TRANSCEIVER
064-1023-05	VHF COMMUNICATIONS TRANSCEIVER
064-1023-06	VHF COMMUNICATIONS TRANSCEIVER
064-1023-07	VHF COMMUNICATIONS TRANSCEIVER
064-1023-08	VHF COMMUNICATIONS TRANSCEIVER
064-1023-09	VHF COMMUNICATIONS TRANSCEIVER

064-1023-10	VHF COMMUNICATIONS TRANSCEIVER
064-1023-11	VHF COMMUNICATIONS TRANSCEIVER
064-1023-12	VHF COMMUNICATIONS TRANSCEIVER
064-1023-13	VHF COMMUNICATIONS TRANSCEIVER
064-1023-14	VHF COMMUNICATIONS TRANSCEIVER
064-1023-15	VHF COMMUNICATIONS TRANSCEIVER
064-1051-10	VHF COMMUNICATIONS TRANSCEIVER
064-1051-30	VHF COMMUNICATIONS TRANSCEIVER
064-1051-50	VHF COMMUNICATIONS TRANSCEIVER
064-1051-51	VHF COMMUNICATIONS TRANSCEIVER
064-1051-60	VHF COMMUNICATIONS TRANSCEIVER
064-1051-61	VHF COMMUNICATIONS TRANSCEIVER
064-1051-70	VHF COMMUNICATIONS TRANSCEIVER
064-1052-10	VHF COMMUNICATIONS TRANSCEIVER
064-1052-30	VHF COMMUNICATIONS TRANSCEIVER
064-1052-50	VHF COMMUNICATIONS TRANSCEIVER
064-1052-51	VHF COMMUNICATIONS TRANSCEIVER
064-1052-60	VHF COMMUNICATIONS TRANSCEIVER
064-1052-61	VHF COMMUNICATIONS TRANSCEIVER
064-1052-70	VHF COMMUNICATIONS TRANSCEIVER
064-1053-10	VHF COMMUNICATIONS TRANSCEIVER
064-1053-11	VHF COMMUNICATIONS TRANSCEIVER
064-1053-12	VHF COMMUNICATIONS TRANSCEIVER
064-1053-30	VHF COMMUNICATIONS TRANSCEIVER
064-1053-31	VHF COMMUNICATIONS TRANSCEIVER
064-1053-32	VHF COMMUNICATIONS TRANSCEIVER
064-1053-60	VHF COMMUNICATIONS TRANSCEIVER
064-1054-10	VHF COMMUNICATIONS TRANSCEIVER
064-1054-11	VHF COMMUNICATIONS TRANSCEIVER
064-1054-12	VHF COMMUNICATIONS TRANSCEIVER
064-1054-30	VHF COMMUNICATIONS TRANSCEIVER
064-1054-31	VHF COMMUNICATIONS TRANSCEIVER
064-1054-32	VHF COMMUNICATIONS TRANSCEIVER
064-1054-40	VHF COMMUNICATIONS TRANSCEIVER
064-1054-41	VHF COMMUNICATIONS TRANSCEIVER
064-1054-42	VHF COMMUNICATIONS TRANSCEIVER
064-1054-50	VHF COMMUNICATIONS TRANSCEIVER
064-1054-60	VHF COMMUNICATIONS TRANSCEIVER
064-1084-0101	VHF COMMUNICATIONS TRANSCEIVER
064-1084-0201	VHF COMMUNICATIONS TRANSCEIVER
066-0015-00	DIRECTIONAL GYRO
066-01053-0000	TRANSPONDER
066-01053-0002	TRANSPONDER
066-01055-01	ISOLATION AMPLIFIER
066-01062-0000	ATCRBS TRANSPONDER
066-01062-0001	ATCRBS TRANSPONDER
066-01062-0002	ATCRBS TRANSPONDER

066-01062-0003	ATCRBS TRANSPONDER
066-01062-0010	ATCRBS TRANSPONDER
066-01062-0020	ATCRBS TRANSPONDER
066-01066-0025	NAVIGATION RECEIVER
066-01067-0000	NAVIGATION RECEIVER
066-01067-0001	NAVIGATION RECEIVER
066-01067-0002	NAVIGATION RECIEVER
066-01067-0003	NAVIGATION RECEIVER
066-01067-0004	NAVIGATION RECEIVER
066-01067-0005	NAVIGATION RECIEVER
066-01067-0010	NAVIGATION RECEIVER
066-01069-0000	DME INDICATOR
066-01069-0001	DME INDICATOR
066-01069-0002	DME INDICATOR
066-01069-0003	DME INDICATOR
066-01069-0004	DME INDICATOR
066-01069-0005	DME INDICATOR
066-01069-0006	DME INDICATOR
066-01069-0007	DME INDICATOR
066-01069-0008	DME INDICATOR
066-01069-0009	DME INDICATOR
066-01069-0010	DME INDICATOR
066-01069-0011	DME INDICATOR
066-01069-0012	DME INDICATOR
066-01069-0013	DME INDICATOR
066-01069-0014	DME INDICATOR
066-01069-0015	DME INDICATOR
066-01071-0000	TRANSPONDER
066-01072-000	ADF CONTROL
066-01072-0000	ADF CONTROL
066-01072-0001	ADF CONTROL
066-01072-0002	ADF CONTROL
066-01072-0003	ADF CONTROL
066-01072-0004	ADF CONTROL
066-01072-0005	ADF CONTROL
066-01072-0006	ADF CONTROL
066-01072-0007	ADF CONTROL
066-01072-001	ADF CONTROL
066-01072-0014	ADF CONTROL
066-01072-0015	ADF CONTROL
066-01072-0017	ADF CONTROL
066-01072-002	ADF CONTROL
066-01072-003	ADF CONTROL
066-01077-0000	ADF RECEIVER
066-01077-0001	ADF RECEIVER
066-01078-0010	NAVIGATION RECEIVER
066-01078-0011	NAVIGATION RECEIVER

066-01078-0012	NAVIGATION RECEIVER
066-01078-0013	NAVIGATION RECEIVER
066-01078-0014	NAVIGATION RECEIVER
066-01078-0015	NAVIGATION RECEIVER
066-01078-0016	NAVIGATION RECEIVER
066-01078-0017	NAVIGATION RECEIVER
066-01156-0101	TRANSPONDER
066-01156-0201	TRANSPONDER
066-03034-0018	NAVIGATION RECEIVER
066-03044-0000	RADAR ALTIMETER
066-03060-0001	RMI
066-03060-0002	RMI
066-03060-0003	RMI
066-03060-0004	RMI
066-03060-0005	RMI
066-03062-00 08	ENCODING ALTIMETER
066-03064-0001	ENCODING ALTIMETER
066-03064-0005	ENCODING ALTIMETER
066-03064-005	ENCODING ALTIMETER
066-04010-0000	NAVIGATION RECEIVER
066-04010-0001	NAVIGATION RECEIVER
066-04010-0002	NAVIGATION RECEIVER
066-04010-0003	NAVIGATION RECEIVER
066-04010-0004	NAVIGATION RECEIVER
066-04010-0010	NAVIGATION RECEIVER
066-04010-0011	NAVIGATION RECEIVER
066-04010-0012	NAVIGATION RECEIVER
066-04010-0013	NAVIGATION RECEIVER
066-04010-0014	NAVIGATION RECEIVER
066-04010-0015	NAVIGATION RECEIVER
066-04010-0016	NAVIGATION RECEIVER
066-04010-0017	NAVIGATION RECEIVER
066-04010-0018	NAVIGATION RECEIVER
066-04010-0019	NAVIGATION RECEIVER
066-04010-0020	NAVIGATION RECEIVER
066-04010-0021	NAVIGATION RECEIVER
066-04010-0030	NAVIGATION RECEIVER
066-04010-0031	NAVIGATION RECEIVER
066-04010-0032	NAVIGATION RECEIVER
066-04010-0033	NAVIGATION RECEIVER
066-04010-0034	NAVIGATION RECEIVER
066-04010-0035	NAVIGATION RECEIVER
066-04010-0036	NAVIGATION RECEIVER
066-04010-0037	NAVIGATION RECEIVER
066-04010-0038	NAVIGATION RECEIVER
066-04010-0039	NAVIGATION RECEIVER
066-04010-0040	NAVIGATION RECEIVER

066-04010-0060	NAVIGATION RECEIVER
066-04010-0061	NAVIGATION RECEIVER
066-04010-0062	NAVIGATION RECEIVER
066-04010-0063	NAVIGATION RECEIVER
066-04010-0064	NAVIGATION RECEIVER
066-04010-0065	NAVIGATION RECEIVER
066-04010-0066	NAVIGATION RECEIVER
066-04010-0067	NAVIGATION RECEIVER
066-04010-0068	NAVIGATION RECEIVER
066-04010-0069	NAVIGATION RECEIVER
066-04010-0070	NAVIGATION RECEIVER
066-04010-0071	NAVIGATION RECEIVER
066-1016-00	ADF RECEIVER
066-1021-01	MARKER BEACON RECEIVER
066-1021-02	MARKER BEACON RECEIVER
066-1024-01	BEACON MARKER RECEIVER
066-1025-05	VHF NAVICATION RECEIVER
066-1034-01	ATC TRANSPONDER
066-1034-02	ATC TRANSPONDER
066-1034-03	ATC TRANSPONDER
066-1034-04	ATC TRANSPONDER
066-1034-10	ATC TRANSPONDER
066-1037-08	DME INDICATOR
066-1041-00	ATC TRANSPONDER
066-1041-01	ATC TRANSPONDER
066-1044-00	MARKER BEACON RECEIVER
066-1044-01	MARKER BEACON RECEIVER
066-1047-01	ADF RECEIVER
066-1053-00	TRANSPONDER
066-1053-02	ATC TRANSPONDER
066-1055-00	AUDIO PANEL
066-1055-01	AUDIO PANEL
066-1055-02	AUDIO PANEL
066-1055-03	AUDIO PANEL
066-1055-50	AUDIO PANEL
066-1055-51	AUDIO PANEL
066-1055-52	AUDIO PANEL
066-1055-53	AUDIO PANEL
066-1055-54	AUDIO PANEL
066-1055-65	AUDIO PANEL
066-1055-68	AUDIO PANEL
066-1055-70	AUDIO PANEL
066-1055-71	AUDIO PANEL
066-1061-003	RADAR ALTIMETER
066-1061-01	RADAR ALTIMETER
066-1061-02	RADAR ALTIMETER
066-1061-03	RADAR ALTIMETER

066-1062-00	ATC TRANSPONDER
066-1062-01	ATC TRANSPONDER
066-1062-02	ATC TRANSPONDER
066-1062-03	ATC TRANSPONDER
066-1062-10	ATC TRANSPONDER
066-1062-20	ATC TRANSPONDER
066-1065-00	MARKER BEACON RECEIVER
066-1066-00	DME TRANSCEIVER
066-1066-01	DME TRANSCEIVER
066-1066-02	DME TRANSCEIVER
066-1066-11	DME TRANSCEIVER
066-1066-20	DME TRANSCEIVER
066-1066-21	DME TRANSCEIVER
066-1066-22	DME TRANSCEIVER
066-1066-23	DME TRANSCEIVER
066-1066-24	DME TRANSCEIVER
066-1066-25	DME TRANSCEIVER
066-1066-31	DME TRANSCEIVER
066-1067-00	NAVIGATION RECEIVER
066-1067-01	NAVIGATION RECEIVER
066-1067-02	NAVIGATION RECIEVER
066-1067-03	NAVIGATION RECEIVER
066-1067-04	NAVIGATION RECEIVER
066-1067-05	NAVIGATION RECIEVER
066-1067-10	NAVIGATION RECEIVER
066-1068-00	DME TRANSCEIVER
066-1068-01	DME TRANSCEIVER
066-1068-04	DME TRANSCEIVER
066-1069-00	DME INDICATOR
066-1069-01	DME INDICATOR
066-1069-02	DME INDICATOR
066-1069-03	DME INDICATOR
066-1069-04	DME INDICATOR
066-1069-05	DME INDICATOR
066-1069-06	DME INDICATOR
066-1069-07	DME INDICATOR
066-1069-08	DME INDICATOR
066-1069-09	DME INDICATOR
066-1069-10	DME INDICATOR
066-1069-11	DME INDICATOR
066-1069-12	DME INDICATOR
066-1069-13	DME INDICATOR
066-1069-14	DME INDICATOR
066-1069-15	DME INDICATOR
066-1070-01	DME INDICATOR
066-1071-00	TRANSPONDER
066-1072-00	ADF RECEIVER

066-1072-01	ADF RECEIVER
066-1072-02	ADF RECEIVER
066-1072-03	ADF RECEIVER
066-1072-04	ADF RECEIVER
066-1072-05	ADF RECEIVER
066-1072-06	ADF RECEIVER
066-1072-07	ADF RECEIVER
066-1072-14	ADF RECEIVER
066-1072-15	ADF RECEIVER
066-1072-17	ADF RECEIVER
066-1077-00	ADF RECEIVER
066-1077-01	ADF RECEIVER
066-1078-00	NAVIGATION RECEIVER
066-1078-01	NAVIGATION RECEIVER
066-1078-02	NAVIGATION RECEIVER
066-1078-03	NAVIGATION RECEIVER
066-1078-04	NAVIGATION RECEIVER
066-1078-05	NAVIGATION RECEIVER
066-1078-06	NAVIGATION RECEIVER
066-1078-07	NAVIGATION RECEIVER
066-1078-08	NAVIGATION RECEIVER
066-1078-10	NAVIGATION RECEIVER
066-1078-11	NAVIGATION RECEIVER
066-1078-12	NAVIGATION RECEIVER
066-1078-13	NAVIGATION RECEIVER
066-1078-14	NAVIGATION RECEIVER
066-1078-15	NAVIGATION RECEIVER
066-1078-16	NAVIGATION RECEIVER
066-1078-17	NAVIGATION RECEIVER
066-1088-00	DME INDICATOR
066-1088-01	DME INDICATOR
066-1216-12	NAV CONTROL UNIT
066-1216-13	NAV CONTROL UNIT
066-1216-15	NAV CONTROL UNIT
066-1216-16	NAV CONTROL UNIT
066-1216-17	NAV CONTROL UNIT
066-1216-18	NAV CONTROL UNIT
066-1216-20	NAV CONTROL UNIT
066-1216-21	NAV CONTROL UNIT
066-1216-22	NAV CONTROL UNIT
066-1216-23	NAV CONTROL UNIT
066-1216-25	NAV CONTROL UNIT
066-1216-26	NAV CONTROL UNIT
066-1216-27	NAV CONTROL UNIT
066-3012-00	MARKER LIGHT ASSEMBLY
066-3012-01	MARKER LIGHT ASSEMBLY
066-3012-010	MARKER BEACON RECEIVER

066-3024-40	HORIZONTAL SITUATION INDICATOR
066-3029-00	HORIZONTAL SITUATION INDICATOR
066-3029-01	HORIZONTAL SITUATION INDICATOR
066-3032-11	DME INDICATOR
066-3034-00	NAVIGATION INDICATOR
066-3034-01	NAVIGATION INDICATOR
066-3034-02	NAVIGATION INDICATOR
066-3034-03	NAVIGATION INDICATOR
066-3034-04	NAVIGATION INDICATOR
066-3034-05	NAVIGATION INDICATOR
066-3034-06	NAVIGATION INDICATOR
066-3034-07	NAVIGATION INDICATOR
066-3034-08	NAVIGATION INDICATOR
066-3034-09	NAVIGATION INDICATOR
066-3034-10	NAVIGATION INDICATOR
066-3034-11	NAVIGATION INDICATOR
066-3034-12	NAVIGATION INDICATOR
066-3034-13	NAVIGATION INDICATOR
066-3034-14	NAVIGATION INDICATOR
066-3034-15	NAVIGATION INDICATOR
066-3034-16	NAVIGATION INDICATOR
066-3034-17	NAVIGATION INDICATOR
066-3034-18	NAVIGATION INDICATOR
066-3034-19	NAVIGATION INDICATOR
066-3034-20	NAVIGATION INDICATOR
066-3034-21	NAVIGATION INDICATOR
066-3034-22	NAVIGATION INDICATOR
066-3034-23	NAVIGATION INDICATOR
066-3034-24	NAVIGATION INDICATOR
066-3034-25	NAVIGATION INDICATOR
066-3034-26	NAVIGATION INDICATOR
066-3038-00	RADIO MAGNETIC INDICATOR
066-3038-01	RADIO MAGNETIC INDICATOR
066-3039-00	VOR/LOC INDICATOR
066-3044-00	RADAR ALTIMETER INDICATOR
066-3044-01	RADAR ALTIMETER INDICATOR
066-3044-02	RADAR ALTIMETER INDICATOR
066-3044-03	RADAR ALTIMETER INDICATOR
066-3046-00	HORIZONTAL SITUATION INDICATOR
066-3046-01	HORIZONTAL SITUATION INDICATOR
066-3046-02	HORIZONTAL SITUATION INDICATOR
066-3046-03	HORIZONTAL SITUATION INDICATOR
066-3046-04	HORIZONTAL SITUATION INDICATOR
066-3046-05	HORIZONTAL SITUATION INDICATOR
066-3046-06	HORIZONTAL SITUATION INDICATOR
066-3046-07	HORIZONTAL SITUATION INDICATOR
066-3046-08	HORIZONTAL SITUATION INDICATOR

066-3051-00	ALTIMETER
066-3054-00	RADAR ALTIMETER INDICATOR
066-3054-01	RADAR ALTIMETER INDICATOR
066-3056-00	VOR/LOC CONVERTER/INDICATOR
066-3056-00	VOR/LOC CONVERTER/INDICATOR
066-3056-01	VOR/LOC CONVERTER/INDICATOR
066-3056-02	VOR/LOC CONVERTER/INDICATOR
066-3056-02	VOR/LOC CONVERTER/INDICATOR
066-3056-03	VOR/LOC CONVERTER/INDICATOR
066-3059-00	DUAL ADF INDICATOR
066-3059-01	DUAL ADF INDICATOR
066-3060-00	RADIO MAGNETIC INDICATOR
066-3060-01	RADIO MAGNETIC INDICATOR
066-3060-02	RADIO MAGNETIC INDICATOR
066-3060-03	RADIO MAGNETIC INDICATOR
066-3060-04	RADIO MAGNETIC INDICATOR
066-3060-05	RADIO MAGNETIC INDICATOR
066-3060-06	RADIO MAGNETIC INDICATOR
066-3062-00	ENCODING ALTIMETER
066-3062-01	ENCODING ALTIMETER
066-3062-02	ENCODING ALTIMETER
066-3062-03	ENCODING ALTIMETER
066-3062-08	ENCODING ALTIMETER
066-3063-00	ADF INDICATOR
066-3063-01	ADF INDICATOR
066-3064-005	ALTIMETER
066-3064-01	ALTIMETER
066-3064-05	ALTIMETER
066-3077-60	ALTITUDE VERTICAL SPEED INDICATOR
066-3081-00	HORIZONTAL SITUATION INDICATOR
066-4007-00	VOR RECEIVER
066-4009-00	VOR CONVERTER
066-4010-00	NAVIGATION RECEIVER
066-4010-01	NAVIGATION RECEIVER
066-4010-02	NAVIGATION RECEIVER
066-4010-03	NAVIGATION RECEIVER
066-4010-04	NAVIGATION RECEIVER
066-4010-10	NAVIGATION RECEIVER
066-4010-11	NAVIGATION RECEIVER
066-4010-12	NAVIGATION RECEIVER
066-4010-13	NAVIGATION RECEIVER
066-4010-14	NAVIGATION RECEIVER
066-4010-15	NAVIGATION RECEIVER
066-4010-16	NAVIGATION RECEIVER
066-4010-17	NAVIGATION RECEIVER
066-4010-18	NAVIGATION RECEIVER
066-4010-19	NAVIGATION RECEIVER

066-4010-20	NAVIGATION RECEIVER
066-4010-21	NAVIGATION RECEIVER
066-4010-30	NAVIGATION RECEIVER
066-4010-31	NAVIGATION RECEIVER
066-4010-32	NAVIGATION RECEIVER
066-4010-33	NAVIGATION RECEIVER
066-4010-34	NAVIGATION RECEIVER
066-4010-35	NAVIGATION RECEIVER
066-4010-36	NAVIGATION RECEIVER
066-4010-37	NAVIGATION RECEIVER
066-4010-38	NAVIGATION RECEIVER
066-4010-39	NAVIGATION RECEIVER
066-4010-40	NAVIGATION RECEIVER
066-4010-60	NAVIGATION RECEIVER
066-4010-61	NAVIGATION RECEIVER
066-4010-62	NAVIGATION RECEIVER
066-4010-63	NAVIGATION RECEIVER
066-4010-64	NAVIGATION RECEIVER
066-4010-65	NAVIGATION RECEIVER
066-4010-66	NAVIGATION RECEIVER
066-4010-67	NAVIGATION RECEIVER
066-4010-69	NAVIGATION RECEIVER
066-4010-70	NAVIGATION RECEIVER
066-4010-71	NAVIGATION RECEIVER
066-4010-80	NAVIGATION RECEIVER
066-4010-81	NAVIGATION RECEIVER
066-4010-82	NAVIGATION RECEIVER
066-4010-83	NAVIGATION RECEIVER
066-4010-84	NAVIGATION RECEIVER
066-4010-85	NAVIGATION RECEIVER
066-4010-86	NAVIGATION RECEIVER
066-4010-87	NAVIGATION RECEIVER
066-4010-88	NAVIGATION RECEIVER
066-4010-89	NAVIGATION RECEIVER
066-4010-90	NAVIGATION RECEIVER
069-01024-0000	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0001	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0002	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0003	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0004	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0005	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0006	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0007	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0008	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0009	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0010	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0011	VHF TRANSCEIVER/NAVIGATION RECEIVER

069-01024-0012	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0013	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0020	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0030	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0031	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0032	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0033	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0034	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0035	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0036	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0037	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0038	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0039	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0040	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0041	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0042	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-01024-0043	VHF TRANSCEIVER /NAVIGATION RECEIVER
069-01024-0099	VHF TRANSCEIVER /NAVIGATION RECEIVER
069-01025-0025	TRANSCEIVER
069-01028-0101	TRANSCEIVER
069-01033-0101	TRANSPONDER
069-01033-0201	TRANSCEIVER
069-1019-00	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1021-00	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-00	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-01	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-02	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-03	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-04	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-05	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-06	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-07	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-08	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-09	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-10	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-11	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-12	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-13	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-20	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-30	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-31	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-32	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-33	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-34	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-35	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-36	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-37	VHF TRANSCEIVER/NAVIGATION RECEIVER

069-1024-38	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-39	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-40	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-41	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-42	VHF TRANSCEIVER/NAVIGATION RECEIVER
069-1024-43	VHF TRANSCEIVER /NAVIGATION RECEIVER
069-1024-99	VHF TRANSCEIVER /NAVIGATION RECEIVER
069-1025-00	VHF COMMUNICATIONS TRANSCEIVER
069-1025-01	VHF COMMUNICATIONS TRANSCEIVER
069-1025-02	VHF COMMUNICATIONS TRANSCEIVER
069-1025-03	VHF COMMUNICATIONS TRANSCEIVER
069-1025-04	VHF COMMUNICATIONS TRANSCEIVER
069-1025-05	VHF COMMUNICATIONS TRANSCEIVER
069-1025-06	VHF COMMUNICATIONS TRANSCEIVER
069-1025-07	VHF COMMUNICATIONS TRANSCEIVER
069-1025-08	VHF COMMUNICATIONS TRANSCEIVER
069-1025-09	VHF COMMUNICATIONS TRANSCEIVER
069-1025-10	VHF COMMUNICATIONS TRANSCEIVER
069-1025-11	VHF COMMUNICATIONS TRANSCEIVER
069-1025-12	VHF COMMUNICATIONS TRANSCEIVER
069-1025-13	VHF COMMUNICATIONS TRANSCEIVER
069-1025-14	VHF COMMUNICATIONS TRANSCEIVER
069-1025-15	VHF COMMUNICATIONS TRANSCEIVER
069-1025-20	VHF COMMUNICATIONS TRANSCEIVER
069-1025-21	VHF COMMUNICATIONS TRANSCEIVER
069-1025-22	VHF COMMUNICATIONS TRANSCEIVER
069-1025-23	VHF COMMUNICATIONS TRANSCEIVER
069-1025-24	VHF COMMUNICATIONS TRANSCEIVER
069-1025-25	VHF COMMUNICATIONS TRANSCEIVER
069-1025-26	VHF COMMUNICATIONS TRANSCEIVER
069-1025-27	VHF COMMUNICATIONS TRANSCEIVER
06F9300	VOLTAGE REGULATOR
070-0609-001/1	BEACON ASSEMBLY
070-0609-001/2	BEACON ASSEMBLY
070-0609-001/3	BEACON ASSEMBLY
07031-64123-7A	VOLTAGE REGULATOR
07031-94123-7	VOLTAGE REGULATOR
07031-94123-7A	VOLTAGE REGULATOR
07031-94214A	VOLTAGE REGULATOR
071-0003-00	REMOTE LIGHT ADAPTER
071-00111-0000	NAV FILTER
071-01215-0024	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0025	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0026	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0027	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0029	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0030	VHF COMMUNICATIONS TRANSCEIVER

071-01215-0031	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0032	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0034	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0035	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0036	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0037	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0038	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0039	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0040	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0041	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0042	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0043	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0044	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0045	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0054	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0055	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0056	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0057	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0059	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0060	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0061	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0062	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0064	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0065	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0066	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0067	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0070	VHF COMMUNICATIONS TRANSCEIVER
071-01215-0071	VHF COMMUNICATIONS TRANSCEIVER
071-01242-0000	SLAVING ACCESSORY
071-01242-0001	SLAVING ACCESSORY
071-01242-0002	SLAVING ACCESSORY
071-01242-0003	SLAVING ACCESSORY
071-01242-0004	SLAVING ACCESSORY
071-01242-0005	SLAVING ACCESSORY
071-01242-0006	SLAVING ACCESSORY
071-01242-0007	SLAVING ACCESSORY
071-01242-0008	SLAVING ACCESSORY
071-01242-0009	SLAVING ACCESSORY
071-01242-0010	SLAVING ACCESSORY
071-01242-0011	SLAVING ACCESSORY
071-01242-0012	SLAVING ACCESSORY
071-01242-0013	SLAVING ACCESSORY
071-01242-0014	SLAVING ACCESSORY
071-01242-0099	SLAVING ACCESSORY
071-01276-0008	VOR CONTROL UNIT
071-01282-0065	VHF COMMUNICATIONS CONTROL
071-01282-0080	VHF COMMUNICATIONS CONTROL

071-01283-0027	NAVIGATION CONTROL
071-01284-0009	NAVIGATION CONTROL
071-01546-0101	UHF COMMUNICATION CONTROL
071-1012-13	VHF COMMUNICATION CONTROL
071-1041-01	VOLTAGE CONVERTER
071-1043-02	ATC TRANSPONDER
071-1052-00	FLUX VALVE
071-1053-00	SLAVING ACCESSORY
071-1053-01	SLAVING ACCESSORY
071-1053-02	SLAVING ACCESSORY
071-1053-03	SLAVING ACCESSORY
071-1053-04	SLAVING ACCESSORY
071-1053-05	SLAVING ACCESSORY
071-1054-00	NAVIGATION CONTROL
071-1054-01	NAVIGATION CONTROL
071-1054-02	NAVIGATION CONTROL
071-1066-01	ADF CONTROL
071-1076-00	RMI CONVERTER
071-1192-00	ATC TRANSPONDER
071-1192-01	ATC TRANSPONDER
071-1192-02	ATC TRANSPONDER
071-1192-03	ATC TRANSPONDER
071-1192-04	ATC TRANSPONDER
071-1192-05	ATC TRANSPONDER
071-1192-06	ATC TRANSPONDER
071-1192-07	ATC TRANSPONDER
071-1192-08	ATC TRANSPONDER
071-1192-09	ATC TRANSPONDER
071-1192-10	ATC TRANSPONDER
071-1192-11	ATC TRANSPONDER
071-1192-13	ATC TRANSPONDER
071-1192-14	ATC TRANSPONDER
071-1192-15	ATC TRANSPONDER
071-1192-16	ATC TRANSPONDER
071-1192-18	ATC TRANSPONDER
071-1192-22	ATC TRANSPONDER
071-1192-26	ATC TRANSPONDER
071-1210-00	ADF CONTROL
071-1210-04	ADF CONTROL
071-1210-05	ADF CONTROL
071-1210-06	ADF CONTROL
071-1210-07	ADF CONTROL
071-1210-08	ADF CONTROL
071-1210-09	ADF CONTROL
071-1210-10	ADF CONTROL
071-1210-11	ADF CONTROL
071-1210-12	ADF CONTROL

071-1210-13	ADF CONTROL
071-1210-14	ADF CONTROL
071-1210-15	ADF CONTROL
071-1210-16	ADF CONTROL
071-1210-17	ADF CONTROL
071-1215-24	VHF COMMUNICATIONS TRANSCEIVER
071-1215-25	VHF COMMUNICATIONS TRANSCEIVER
071-1215-26	VHF COMMUNICATIONS TRANSCEIVER
071-1215-27	VHF COMMUNICATIONS TRANSCEIVER
071-1215-29	VHF COMMUNICATIONS TRANSCEIVER
071-1215-30	VHF COMMUNICATIONS TRANSCEIVER
071-1215-31	VHF COMMUNICATIONS TRANSCEIVER
071-1215-32	VHF COMMUNICATIONS TRANSCEIVER
071-1215-34	VHF COMMUNICATIONS TRANSCEIVER
071-1215-35	VHF COMMUNICATIONS TRANSCEIVER
071-1215-36	VHF COMMUNICATIONS TRANSCEIVER
071-1215-37	VHF COMMUNICATIONS TRANSCEIVER
071-1215-38	VHF COMMUNICATIONS TRANSCEIVER
071-1215-39	VHF COMMUNICATIONS TRANSCEIVER
071-1215-40	VHF COMMUNICATIONS TRANSCEIVER
071-1215-41	VHF COMMUNICATIONS TRANSCEIVER
071-1215-42	VHF COMMUNICATIONS TRANSCEIVER
071-1215-43	VHF COMMUNICATIONS TRANSCEIVER
071-1215-44	VHF COMMUNICATIONS TRANSCEIVER
071-1215-45	VHF COMMUNICATIONS TRANSCEIVER
071-1215-54	VHF COMMUNICATIONS TRANSCEIVER
071-1215-55	VHF COMMUNICATIONS TRANSCEIVER
071-1215-56	VHF COMMUNICATIONS TRANSCEIVER
071-1215-57	VHF COMMUNICATIONS TRANSCEIVER
071-1215-59	VHF COMMUNICATIONS TRANSCEIVER
071-1215-60	VHF COMMUNICATIONS TRANSCEIVER
071-1215-61	VHF COMMUNICATIONS TRANSCEIVER
071-1215-62	VHF COMMUNICATIONS TRANSCEIVER
071-1215-64	VHF COMMUNICATIONS TRANSCEIVER
071-1215-65	VHF COMMUNICATIONS TRANSCEIVER
071-1215-66	VHF COMMUNICATIONS TRANSCEIVER
071-1215-67	VHF COMMUNICATIONS TRANSCEIVER
071-1215-70	VHF COMMUNICATIONS TRANSCEIVER
071-1215-71	VHF COMMUNICATIONS TRANSCEIVER
071-1216-12	NAV CONTROL UNIT
071-1216-13	NAV CONTROL UNIT
071-1216-15	NAV CONTROL UNIT
071-1216-16	NAV CONTROL UNIT
071-1216-17	NAV CONTROL UNIT
071-1216-18	NAV CONTROL UNIT
071-1216-20	NAV CONTROL UNIT
071-1216-21	NAV CONTROL UNIT

071-1216-22	NAV CONTROL UNIT
071-1216-23	NAV CONTROL UNIT
071-1216-25	NAV CONTROL UNIT
071-1216-26	NAV CONTROL UNIT
071-1216-27	NAV CONTROL UNIT
071-1242-00	SLAVING ACCESSORY
071-1242-01	SLAVING ACCESSORY
071-1242-02	SLAVING ACCESSORY
071-1242-03	SLAVING ACCESSORY
071-1242-04	SLAVING ACCESSORY
071-1242-05	SLAVING ACCESSORY
071-1242-06	SLAVING ACCESSORY
071-1242-07	SLAVING ACCESSORY
071-1242-08	SLAVING ACCESSORY
071-1242-09	SLAVING ACCESSORY
071-1242-10	SLAVING ACCESSORY
071-1242-11	SLAVING ACCESSORY
071-1242-12	SLAVING ACCESSORY
071-1242-13	SLAVING ACCESSORY
071-1242-14	SLAVING ACCESSORY
071-1242-99	SLAVING ACCESSORY
071-1276-08	ATC TRANSPONDER
071-1276-09	ATC TRANSPONDER
071-1276-10	ATC TRANSPONDER
071-1276-11	ATC TRANSPONDER
071-1276-13	ATC TRANSPONDER
071-1276-14	ATC TRANSPONDER
071-1276-15	ATC TRANSPONDER
071-1276-16	ATC TRANSPONDER
071-1276-18	ATC TRANSPONDER
071-1276-19	ATC TRANSPONDER
071-1276-20	ATC TRANSPONDER
071-1276-21	ATC TRANSPONDER
071-1276-22	ATC TRANSPONDER
071-1276-23	ATC TRANSPONDER
071-1276-24	ATC TRANSPONDER
071-1276-25	ATC TRANSPONDER
071-1276-26	ATC TRANSPONDER
071-1282-24	VHF COMMUNICATIONS TRANSCEIVER
071-1282-25	VHF COMMUNICATIONS TRANSCEIVER
071-1282-26	VHF COMMUNICATIONS TRANSCEIVER
071-1282-27	VHF COMMUNICATIONS TRANSCEIVER
071-1282-29	VHF COMMUNICATIONS TRANSCEIVER
071-1282-30	VHF COMMUNICATIONS TRANSCEIVER
071-1282-31	VHF COMMUNICATIONS TRANSCEIVER
071-1282-32	VHF COMMUNICATIONS TRANSCEIVER
071-1282-34	VHF COMMUNICATIONS TRANSCEIVER

071-1282-35	VHF COMMUNICATIONS TRANSCEIVER
071-1282-36	VHF COMMUNICATIONS TRANSCEIVER
071-1282-37	VHF COMMUNICATIONS TRANSCEIVER
071-1282-38	VHF COMMUNICATIONS TRANSCEIVER
071-1282-39	VHF COMMUNICATIONS TRANSCEIVER
071-1282-40	VHF COMMUNICATIONS TRANSCEIVER
071-1282-41	VHF COMMUNICATIONS TRANSCEIVER
071-1282-42	VHF COMMUNICATIONS TRANSCEIVER
071-1282-43	VHF COMMUNICATIONS TRANSCEIVER
071-1282-44	VHF COMMUNICATIONS TRANSCEIVER
071-1282-45	VHF COMMUNICATIONS TRANSCEIVER
071-1282-46	VHF COMMUNICATIONS TRANSCEIVER
071-1282-47	VHF COMMUNICATIONS TRANSCEIVER
071-1282-48	VHF COMMUNICATIONS TRANSCEIVER
071-1282-49	VHF COMMUNICATIONS TRANSCEIVER
071-1282-50	VHF COMMUNICATIONS TRANSCEIVER
071-1282-51	VHF COMMUNICATIONS TRANSCEIVER
071-1282-52	VHF COMMUNICATIONS TRANSCEIVER
071-1282-53	VHF COMMUNICATIONS TRANSCEIVER
071-1282-54	VHF COMMUNICATIONS TRANSCEIVER
071-1282-55	VHF COMMUNICATIONS TRANSCEIVER
071-1282-56	VHF COMMUNICATIONS TRANSCEIVER
071-1282-64	VHF COMMUNICATIONS TRANSCEIVER
071-1282-65	VHF COMMUNICATIONS TRANSCEIVER
071-1282-66	VHF COMMUNICATIONS TRANSCEIVER
071-1282-67	VHF COMMUNICATIONS TRANSCEIVER
071-1282-69	VHF COMMUNICATIONS TRANSCEIVER
071-1282-70	VHF COMMUNICATIONS TRANSCEIVER
071-1282-71	VHF COMMUNICATIONS TRANSCEIVER
071-1282-72	VHF COMMUNICATIONS TRANSCEIVER
071-1282-74	VHF COMMUNICATIONS TRANSCEIVER
071-1282-75	VHF COMMUNICATIONS TRANSCEIVER
071-1282-76	VHF COMMUNICATIONS TRANSCEIVER
071-1282-77	VHF COMMUNICATIONS TRANSCEIVER
071-1282-80	VHF COMMUNICATIONS TRANSCEIVER
071-1282-81	VHF COMMUNICATIONS TRANSCEIVER
071-1282-86	VHF COMMUNICATIONS TRANSCEIVER
071-1282-87	VHF COMMUNICATIONS TRANSCEIVER
071-1282-88	VHF COMMUNICATIONS TRANSCEIVER
071-1282-89	VHF COMMUNICATIONS TRANSCEIVER
071-1282-90	VHF COMMUNICATIONS TRANSCEIVER
071-1282-91	VHF COMMUNICATIONS TRANSCEIVER
071-1282-92	VHF COMMUNICATIONS TRANSCEIVER
071-1282-93	VHF COMMUNICATIONS TRANSCEIVER
071-1282-94	VHF COMMUNICATIONS TRANSCEIVER
071-1282-95	VHF COMMUNICATIONS TRANSCEIVER
071-1282-96	VHF COMMUNICATIONS TRANSCEIVER

071-1283-12	NAV CONTROL UNIT
071-1283-13	NAV CONTROL UNIT
071-1283-15	NAV CONTROL UNIT
071-1283-16	NAV CONTROL UNIT
071-1283-17	NAV CONTROL UNIT
071-1283-18	NAV CONTROL UNIT
071-1283-20	NAV CONTROL UNIT
071-1283-21	NAV CONTROL UNIT
071-1283-22	NAV CONTROL UNIT
071-1283-23	NAV CONTROL UNIT
071-1283-25	NAV CONTROL UNIT
071-1283-26	NAV CONTROL UNIT
071-1283-27	NAV CONTROL UNIT
071-1283-28	NAV CONTROL UNIT
071-1283-29	NAV CONTROL UNIT
071-1283-30	NAV CONTROL UNIT
071-1283-31	NAV CONTROL UNIT
071-1283-32	NAV CONTROL UNIT
071-1283-33	NAV CONTROL UNIT
071-1283-38	NAV CONTROL UNIT
071-1283-39	NAV CONTROL UNIT
071-1283-40	NAV CONTROL UNIT
071-1283-41	NAV CONTROL UNIT
071-1283-42	NAV CONTROL UNIT
071-1283-43	NAV CONTROL UNIT
071-1284-04	ADF CONTROL
071-1284-05	ADF CONTROL
071-1284-06	ADF CONTROL
071-1284-07	ADF CONTROL
071-1284-08	ADF CONTROL
071-1284-09	ADF CONTROL
071-1284-10	ADF CONTROL
071-1284-11	ADF CONTROL
071-1284-12	ADF CONTROL
071-1284-13	ADF CONTROL
071-1284-14	ADF CONTROL
071-1284-15	ADF CONTROL
071-1284-16	ADF CONTROL
071-1284-17	ADF CONTROL
071-1284-19	ADF CONTROL
071-1284-20	ADF CONTROL
071-1284-21	ADF CONTROL
071-1284-22	ADF CONTROL
071-1284-23	ADF CONTROL
071-1284-24	ADF CONTROL
071-1284-29	ADF CONTROL
071-1284-30	ADF CONTROL

071-1284-31	ADF CONTROL
071-1284-32	ADF CONTROL
071-1284-33	ADF CONTROL
071-1284-34	ADF CONTROL
071-1284-35	ADF CONTROL
071-2008-00	ISOLATION AMPLIFIER
07148-11126-2	HEATED WINDSHIELD CONTROL UNIT
07639-1829-3	VOLTAGE REGULATOR
07639-CSV 1829-3	VOLTAGE REGULATOR
07639-CSV 1829-7	VOLTAGE REGULATOR
07639-CSV 1893-7	VOLTAGE REGULATOR
07639-CSV1152-12A	VOLTAGE REGULATOR
07639-CVS 1829-7	VOLTAGE REGULATOR
086-14003-01	DME INDICATOR
099-799-100	SEARCHLIGHT
099-799-150	SEARCHLIGHT
099-800-003	SEARCHLIGHT
099-800-101	SEARCHLIGHT
100-0027-01	TURN RATE INDICATOR ASSEMBLY
100-0027-02	TURN RATE INDICATOR ASSEMBLY
100-0027-05	TURN RATE INDICATOR ASSEMBLY
100-0030-01	TURN RATE INDICATOR ASSEMBLY
100-0030-02	TURN RATE INDICATOR ASSEMBLY
100-0034-01	TACHOMETER INDICATOR
100-0034-03	TACHOMETER INDICATOR
100-0034-06	TACHOMETER INDICATOR
100-0034-16	TACHOMETER INDICATOR
100-0034-20	TACHOMETER INDICATOR
100-0034-22	TACHOMETER INDICATOR
100-0034-28	TACHOMETER INDICATOR
100-0034-29	TACHOMETER INDICATOR
100-0034-57	TACHOMETER INDICATOR
100-0034-58	TACHOMETER INDICATOR
100-0043-01	TACHOMETER INDICATOR
100-0043-02	TACHOMETER INDICATOR
100-0043-03	TACHOMETER INDICATOR
100-0043-04	TACHOMETER INDICATOR
100-0043-05	TACHOMETER INDICATOR
100-0051-002	TACHOMETER INDICATOR
100-0051-01	TACHOMETER INDICATOR
100-0051-03	TACHOMETER INDICATOR
100-0051-04	TACHOMETER INDICATOR
100-0051-05	TACHOMETER INDICATOR
100-0051-06	TACHOMETER INDICATOR
1000-2001	AIRSPEED INDICATOR
1-001-0102-0083	STATIC INVERTER
1-001-0102-0084	STATIC INVERTER

1-001-0102-0085	STATIC INVERTER
1-001-0102-0086	STATIC INVERTER
1-001-0102-0095	STATIC INVERTER
1-001-0102-0129	STATIC INVERTER
1-001-0102-0296	STATIC INVERTER
1-001-0102-0597	STATIC INVERTER
10014-0000-02	FUEL QUANTITY INDICATOR
1-002-0102-0434	STATIC INVERTER
1-002-0102-0901	STATIC INVERTER
1-002-0102-0912	STATIC INVERTER
1-002-0102-1001	STATIC INVERTER
1-002-0102-1033	STATIC INVERTER
1-002-0102-1657	STATIC INVERTER
1-002-0102-2044	STATIC INVERTER
10028-101	PRESSURE SWITCH
10028-102	PRESSURE SWITCH
10028-103	PRESSURE SWITCH
10028-104	PRESSURE SWITCH
10028-105	PRESSURE SWITCH
10-03305	CLOCK
10035-11244	ALTIMETER
10035-11326	ALTIMETER
10035-11424	ALTIMETER
10035-2176	ALTIMETER
10035-81996	ALTIMETER
100-384042	AMMETER
100-384042-1	AMMETER
100-384048-1	SYNCHRO INDICATOR
100-384048-15	SYNCHRO INDICATOR
100-384048-17	SYNCHRO INDICATOR
100-384048-3	SYNCHRO INDICATOR
100-384048-5	SYNCHRO INDICATOR
100-384050-1	SYNCHRO INDICATOR
100-384050-3	SYNCHRO INDICATOR
100-384050-5	SYNCHRO INDICATOR
100-384116-5	SYNCHRO INDICATOR
100-389007	TORQUE TRANSMITTER
100-601607-001	TORQUE AND TURBINE GAS TEMPERATURE INDICATOR
1007KCA1	COMPASS
101025-11104	ALTIMETER
10-1098-1	ANTI-COLLISION LIGHT
1012297A01-00	AIRSPEED INDICATOR
10125-11104	ALTIMETER
101-384008-3	SYNCHRO INDICATOR
101-384074-7	AIRSPEED INDICATOR
101-384-150-7	FUEL QUANTITY INDICATOR
101-384151-3	FUEL QUANTITY INDICATOR

101-384151-5	FUEL QUANTITY INDICATOR
101-389044-3	TORQUE TRANSMITTER
101420-01205	ENCODING ALTIMETER
101420-01206	ENCODING ALTIMETER
101420-01223	ENCODING ALTIMETER
101420-01224	ENCODING ALTIMETER
101420-01249	ENCODING ALTIMETER
101420-01250	ENCODING ALTIMETER
101420-01255	ENCODING ALTIMETER
101420-01256	ENCODING ALTIMETER
101420-11207	ENCODING ALTIMETER
101420-11225	ENCODING ALTIMETER
101423-01229	ENCODING ALTIMETER
101435-01211	ENCODING ALTIMETER
101435-01212	ENCODING ALTIMETER
101435-01229	ENCODING ALTIMETER
101435-01230	ENCODING ALTIMETER
101435-01261	ENCODING ALTIMETER
101435-01262	ENCODING ALTIMETER
101435-01267	ENCODING ALTIMETER
101435-01268	ENCODING ALTIMETER
101435-111104	ALTIMETER ENCODER
101450-01217	ENCODING ALTIMETER
101450-01218	ENCODING ALTIMETER
101450-01235	ENCODING ALTIMETER
101450-01236	ENCODING ALTIMETER
101450-01273	ENCODING ALTIMETER
101450-01274	ENCODING ALTIMETER
101450-01279	ENCODING ALTIMETER
101450-01280	ENCODING ALTIMETER
101450-31243	ENCODING ALTIMETER
101617-01339	ENCODING ALTIMETER
101617-01340	ENCODING ALTIMETER
101617-01349	ENCODING ALTIMETER
101617-11372	ENCODING ALTIMETER
101617-11373	ENCODING ALTIMETER
101617-11374	ENCODING ALTIMETER
101627-01343	ENCODING ALTIMETER
101627-01344	ENCODING ALTIMETER
101627-01375	ENCODING ALTIMETER
101627-01696	ENCODING ALTIMETER
101627-11376	ENCODING ALTIMETER
101627-11377	ENCODING ALTIMETER
101627-11378	ENCODING ALTIMETER
101627-11705	ENCODING ALTIMETER
101635-01358	ENCODING ALTIMETER
101635-01359	ENCODING ALTIMETER

101635-01379	ENCODING ALTIMETER
101635-01380	ENCODING ALTIMETER
101635-01381	ENCODING ALTIMETER
101635-01382	ENCODING ALTIMETER
101635-11380	ENCODING ALTIMETER
101635-11381	ENCODING ALTIMETER
101635-11382	ENCODING ALTIMETER
101635-11839	ENCODING ALTIMETER
10169N01R00	RPM INDICATOR
101720-01354	ALTIMETER
101720-01355	ALTIMETER
101720-01356	ALTIMETER
101720-01357	ALTIMETER
101720-01383	ALTIMETER
101720-01387	ALTIMETER
101720-01393	ALTIMETER
101720-01461	ALTIMETER
101720-01545	ALTIMETER
101720-01546	ALTIMETER
101720-01547	ALTIMETER
101720-01562	ALTIMETER
101720-11384	ALTIMETER
101720-11385	ALTIMETER
101720-11386	ALTIMETER
101720-11397	ALTIMETER
101720-11564	ALTIMETER
101720-11810	ALTIMETER
101730-01356	ALTIMETER
101730-01357	ALTIMETER
101730-01387	ALTIMETER
101730-01388	ALTIMETER
101730-01419	ALTIMETER
101730-01455	ALTIMETER
101730-11387	ALTIMETER
101730-11388	ALTIMETER
101730-11389	ALTIMETER
101730-11390	ALTIMETER
101735-011002	ALTIMETER
101735-01455	ALTIMETER
101735-01456	ALTIMETER
101735-01495	ALTIMETER
101735-01500	ALTIMETER
101735-01563	ALTIMETER
101735-01695	ALTIMETER
101735-01723	ALTIMETER
101735-01727	ALTIMETER
101735-11726	ALTIMETER

101735-11728	ALTIMETER
101735-11807	ALTIMETER
101735-11940	ALTIMETER
101750-01710	ALTIMETER
10180N01T00	TURBINE OUTLET TEMPERATURE INDICATOR
101A100	VOLTMETER
102-0001-01	ATTITUDE INDICATOR
102-0002-01	ATTITUDE INDICATOR
102-0003-01	ATTITUDE INDICATOR
102-0006-01	ATTITUDE INDICATOR
102-0007-01	ATTITUDE INDICATOR
102-0009-01	ATTITUDE INDICATOR
102-0017-01	ATTITUDE INDICATOR
102-0020-01	ATTITUDE INDICATOR
102-0025-01	ATTITUDE INDICATOR
102-0026-01	ATTITUDE INDICATOR
102-0029-01	ATTITUDE INDICATOR
102-0031-01	ATTITUDE INDICATOR
102-0042-01	ATTITUDE INDICATOR
102-0045-01	GYRO HORIZON
102-0045-02	GYRO HORIZON
102-0047-01	GYRO HORIZON
102-0047-02	GYRO HORIZON
102-0047-03	GYRO HORIZON
102-0048-01	GYRO HORIZON
102-0049-01	GYRO HORIZON
102-0050-01	GYRO HORIZON
102-0050-02	GYRO HORIZON
102-0051-01	GYRO HORIZON
102-0051-02	GYRO HORIZON
102-0051-04	GYRO HORIZON
102-0052-01	GYRO HORIZON
102-0052-02	GYRO HORIZON
102-0053-01	GYRO HORIZON
102-0053-02	GYRO HORIZON
102-0053-03	GYRO HORIZON
102-0054-01	GYRO HORIZON
102-0054-02	GYRO HORIZON
102-0054-03	GYRO HORIZON
102-0054-04	GYRO HORIZON
102-0054-05	GYRO HORIZON
102-0054-06	GYRO HORIZON
102-0054-07	GYRO HORIZON
102-0057-01	GYRO HORIZON
102-0057-02	GYRO HORIZON
102-0057-03	GYRO HORIZON
102-0057-04	GYRO HORIZON

102-0059-01	GYRO HORIZON
102-0059-02	GYRO HORIZON
102-0060-01	GYRO HORIZON
102-0060-02	GYRO HORIZON
102-0060-03	GYRO HORIZON
102-0060-04	GYRO HORIZON
102-0061-01	GYRO HORIZON
102-0061-02	GYRO HORIZON
102-0064-01	GYRO HORIZON
102-0064-02	GYRO HORIZON
102-0065-01	GYRO HORIZON
102-0066-01	GYRO HORIZON
102-0066-02	GYRO HORIZON
102-0067-02	GYRO HORIZON
102-0070-02	GYRO HORIZON
102-0072-01	GYRO HORIZON
102-0072-02	GYRO HORIZON
102-0074-03	GYRO HORIZON
102-0075 D	TRANSMITTER
102-0076-01	GYRO HORIZON
102-0076-02	GYRO HORIZON
102-0079-01	GYRO HORIZON
102200-01818	ALTIMETER
102200-111116	ENCODING ALTIMETER
102200-11815	ALTIMETER
102200-11829	ENCODING ALTIMETER
102200-11850	ALTIMETER
102200-81997	ALTIMETER
102220-11886	ALTIMETER
10261G01W00	TORQUE INDICATOR
102A100	AMMETER
103-0001-01	DIRECTIONAL GYRO
103-0002-01	DIRECTIONAL GYRO
103-0022-01	DIRECTIONAL GYRO
103-0022-02	DIRECTIONAL GYRO
103-0023-01	DIRECTIONAL GYRO
103-0030-01	DIRECTIONAL GYRO
103-0030-02	DIRECTIONAL GYRO
10355N01T00	INTER TURBINE TEMPERATURE INDICATOR
10355N02T00	INTER TURBINE TEMPERATURE INDICATOR
10355N04T00	INTER TURBINE TEMPERATURE INDICATOR
10355N05T00	INTER TURBINE TEMPERATURE INDICATOR
10355N06T00	INTER TURBINE TEMPERATURE INDICATOR
10355N07T00	INTER TURBINE TEMPERATURE INDICATOR
10355N08T00	INTER TURBINE TEMPERATURE INDICATOR
10420-01224	ALTIMETER
10420-11968E	ALTIMETER

104-384012-3	SYNCHRO INDICATOR
104-38401-5	SYNCHRO INDICATOR
104-384059-1	TEMPERATURE & PRESSURE INDICATOR
104435-111104	ALTIMETER
10446N01W00	TORQUE INDICATOR
10446N02W00	TORQUE INDICATOR
10447N01T00	TURBINE OUTLET TEMPERATURE INDICATOR
10450-11110	ALTIMETER
10450-11139	ALTIMETER
10450-31105	ALTIMETER
10450-31327	ALTIMETER
105020-6501	ALTIMETER
10-51002-3	MACH AIRSPEED INDICATOR
10571N01W00	TORQUE INDICATOR
105-90726	AMMETER
105-90845	TACHOMETER INDICATOR
105-90863	TRIPLE TACHOMETER INDICATOR
105-90864	TRIPLE TACHOMETER INDICATOR
105-90871	FUEL PRESSURE INDICATOR
105-90872	OIL TEMPERATURE INDICATOR
105-90873	TRIPLE OIL PRESSURE INDICATOR
105-90880	AIRSPEED INDICATOR
105-90882	TEMPERATURE INDICATOR
105-90941	DUAL TORQUE INDICATOR
105-90942	TURBINE OUTLET TEMPERATURE INDICATOR
105-90943	TURBINE OUTLET TEMPERATURE INDICATOR
105-90946	TORQUE INDICATOR
105-90947	TURBINE OUTLET TEMPERATURE INDICATOR
105-90948	GAS PRODUCER TACHOMETER INDICATOR
105-90950	DUAL TORQUE INDICATOR
105-90951	TORQUE INDICATOR
105-93921	ANTI-ICE LINEAR ACTUATOR
105-956851	TACHOMETER INDICATOR
105-956891	TORQUE INDICATOR
105-956911	OIL TEMPERATURE INDICATOR
105-957161A	TEMPERATURE INDICATOR
105-957201	TRIPLE TACHOMETER INDICATOR
105-957411	DUAL TORQUE INDICATOR
105-98213	HANDGRIP
10-60722-11	LIQUID QUANTITY ENGINE OIL TRANSMITTER
10-60755-6	RATE OF CLIMB INDICATOR
10-60757-28	TEMPERATURE INDICATOR
10611T01Y00	FUEL PROBE
10611T02Y00	FUEL PROBE
10611T03Y00	FUEL PROBE
10-61255-1	HYDRAULIC PRESSURE TRANSMITTER
10-61255-24	HYDRAULIC PRESSURE TRANSMITTER

10-61255-32	HYDRAULIC PRESSURE TRANSMITTER
10-61255-33	HYDRAULIC PRESSURE TRANSMITTER
10612B02Y02	FUEL SIGNAL CONDITIONER
10612B03Y01	FUEL SIGNAL CONDITIONER
10612B03Y03	FUEL SIGNAL CONDITIONER
10-61991-1	TACHOMETER INDICATOR
10-61991-2	TACHOMETER INDICATOR
10-62028-2	TACHOMETER INDICATOR
10-62028-3	TACHOMETER INDICATOR
10-62031-1	TACHOMETER INDICATOR
10-62032-2	TEMPERATURE INDICATOR
10-62032-3	TEMPERATURE INDICATOR
10-62032-5	TEMPERATURE INDICATOR
10-62067-1	VIBRATION MONITOR INDICATOR
10623/18	TURBINE OUTLET TEMPERATURE INDICATOR
10635-111129	ALTIMETER
109-0020-66-1	HANDGRIP
109-0020-66-3	HANDGRIP
109-0729-01-1	VOLTMETER
109-0729-02-1	VOLTMETER
109-0729-08-3	TACHOMETER INDICATOR
109-0729-13-1	TURBINE OUTLET TEMPERATURE INDICATOR
109-0729-27-1	TEMPERATURE & PRESSURE INDICATOR
109-0729-30-1	TORQUE INDICATOR
109-0729-30-3	TORQUE INDICATOR
109-0729-32-1	TURBINE OUTLET TEMPERATURE INDICATOR
109-0729-32-3	TURBINE OUTLET TEMPERATURE INDICATOR
109-0729-34-1	ALTIMETER
109-0729-38-3	VOLTMETER
109-0729-39-1	DUAL AMMETER
109-0730-16-1	TRIPLE TACHOMETER INDICATOR
109-0730-16-113	TRIPLE TACHOMETER INDICATOR
1092T100-MBB	LINEAR ACTUATOR
10ZZ210M	MASTER ALARM AND INDICATION PANEL
1100-14(0)	GYRO HORIZON
1100-14(11)	GYRO HORIZON
1100-14(12)	GYRO HORIZON
1100-14(14)	GYRO HORIZON
1100-14(5)	GYRO HORIZON
1100-14(5)DIA	GYRO HORIZON
1100-14(8)	GYRO HORIZON
1100-14L(0D)	GYRO HORIZON
1100-14L(11D)	GYRO HORIZON
1100-14L(12D)	GYRO HORIZON
1100-14L(14D)	GYRO HORIZON
1100-14L(5D)	GYRO HORIZON
1100-14L(8D)	GYRO HORIZON

1100-14LS(0D)	GYRO HORIZON
1100-14LS(12D)	GYRO HORIZON
1100-14LS(14D)	GYRO HORIZON
1100-14S(0)	GYRO HORIZON
1100-14S(11)	GYRO HORIZON
1100-14S(12)	GYRO HORIZON
1100-14S(14)	GYRO HORIZON
1100-14S(5)	GYRO HORIZON
1100-14S(5D)	GYRO HORIZON
110014S(8)	GYRO HORIZON
1100-14S(8D)	GYRO HORIZON
1100-28(0)	GYRO HORIZON
1100-28(0)CES	GYRO HORIZON
1100-28(11)	GYRO HORIZON
1100-28(12)	GYRO HORIZON
1100-28(5)	GYRO HORIZON
1100-28(8)	GYRO HORIZON
1100-28K(10)	GYRO HORIZON
1100-28L	GYRO HORIZON
1100-28L(0F)	GYRO HORIZON
1100-28L(0F)DIA	GYRO HORIZON
1100-28L(10F)	GYRO HORIZON
1100-28L(11F)	GYRO HORIZON
1100-28L(12F)	GYRO HORIZON
1100-28L(14F)	GYRO HORIZON
1100-28L(15B)	GYRO HORIZON
1100-28L(15F)	GYRO HORIZON
1100-28L(16F)	GYRO HORIZON
1100-28L(20B)	GYRO HORIZON
1100-28L(6F)	GYRO HORIZON
1100-28L(7F)	GYRO HORIZON
1100-28L(8F)	GYRO HORIZON
1100-28LK(0F)DIA	GYRO HORIZON
1100-28LK(2F)	GYRO HORIZON
1100-28LK(5F)	GYRO HORIZON
1100-28LK(8E)	GYRO HORIZON
1100-28LS	ATTITUDE INDICATOR
1100-28LS(0F)	GYRO HORIZON
1100-28LS(11B)	GYRO HORIZON
1100-28LS(11F)	GYRO HORIZON
1100-28LS(12F)	GYRO HORIZON
1100-28LS(14E)	GYRO HORIZON
1100-28LS(14F)	ATTITUDE INDICATOR
1100-28LS(4F)	GYRO HORIZON
1100-28LS(5F)	GYRO HORIZON
1100-28LS(7F)	GYRO HORIZON
1100-28LS(8F)	GYRO HORIZON

1100-28LSK(0F)	GYRO HORIZON
1100-28S(0)	GYRO HORIZON
1100-28S(11)	GYRO HORIZON
1100-28S(12)	GYRO HORIZON
1100-28S(14)	GYRO HORIZON
1100-28S(5)	GYRO HORIZON
1100-28S(8)	GYRO HORIZON
1100-28SL(15F)	GYRO HORIZON
110-137-1	RELAY
110-406 NAV	EMERGENCY LOCATOR TRANSMITTER
110-406HM NAV	EMERGENCY LOCATOR TRANSMITTER
111302-5	HORIZONTAL SITUATION INDICATOR
111302-8	HORIZONTAL SITUATION INDICATOR
111303-4	ATTITUDE DIRECTOR INDICATOR
111G	INDICATOR
11223-03	FUEL QUANTITY INDICATOR
1-1223-03	INDICATOR
113540-3	ATTITUDE DIRECTOR INDICATOR
11450-11139	ALTIMETER
115.201-1	POWER MODULE
115.201-3	HYDRAULIC PRESSURE INDICATOR
115.201-4	HYDRAULIC SIGNAL CONDITION
115.201-5	HYDRAULIC PRESSURE INDICATOR
116595-01	ATTITUDE INDICATOR
117-12654-01	OIL PRESSURE SWITCH
117-12656-01	OIL PRESSURE TRANSDUCER
117-384019-3	FUEL QUANTITY INDICATOR
117-41115-51	CYCLIC GRIP
117-460381	SERVO MOTOR
117-61312-03	SWITCH
117-61313-01	PRESSURE TRANSDUCER
117-64151-01	FUEL BOOST PUMP
117-64151-03	FUEL BOOST PUMP
117-64152-01	FUEL QUANTITY TRANSMITTER
117-64152-03	FUEL QUANTITY TRANSMITTER
117-64153-01	LOW LEVEL SWITCH
117-64569-03	SWITCH
117-69005-03	DUAL TORQUE INDICATOR
117-69005-03(H5)	DUAL TORQUE INDICATOR
117-89131-01	FUEL QUANTITY TRANSMITTER
117-902031	TURBINE OUTLET TEMPERATURE INDICATOR
117-902041	OIL TEMPERATURE & PRESSURE INDICAT0R
117-902051	RPM WARNING BOX
117-902061	DUAL AMMETER
117-902101	N1 TACHOMETER INDICATOR
117-902111	TRIPLE TACHOMETER INDICATOR
117-902121B	TORQUE INDICATOR

117-9039-03	POWER SUPPLY
117-92031-01	LIGHT CONTROL UNIT
117-92031-03	LIGHT CONTROL UNIT
117-92031-05	LIGHT CONTROL UNIT
117-92031-07	LIGHT CONTROL UNIT
117-92039-01	EMERGENCY LIGHTS PWS
117-92039-03	EMERGENCY LIGHTS PWS
117-92049-01	POWER SUPPLY
117-94032-01	GAS PRODUCER TACHOMETER INDICATOR
117-94033-01	TURBINE OUTLET TEMPERATURE INDICATOR
117-94034-01	ENGINE OIL TEMPERATURE INDICATOR
117-94035-01	TEMPERATURE INDICATOR
117-94035-03	TEMPERATURE INDICATOR
117-94035-05	TEMPERATURE INDICATOR
117-94036-01	TRANSMISSION OIL PRESSURE INDICATOR
117-94036-03	TRANSMISSION OIL PRESSURE INDICATOR
117-94036-05	TRANSMISSION OIL PRESSURE INDICATOR
117-94040-01	DC AMMETER
117-94040-03	DC AMMETER
117-94040-05	DC AMMETER
117-94040-07	DC AMMETER
117-94042-03	AIRSPEED INDICATOR
117-94042-05	AIRSPEED INDICATOR
117-94047-01	RPM WARNING BOX
117-940471	AIRSPEED INDICATOR
117-94049-03	DC AMMETER
117-94049-05	DC AMMETER
117-94049-07	DC AMMETER
117-94051-01	TURBINE OUTLET TEMPERATURE INDICATOR
117-94051-03	TURBINE OUTLET TEMPERATURE INDICATOR
117-94051-05	TURBINE OUTLET TEMPERATURE INDICATOR
117-94051-07	TURBINE OUTLET TEMPERATURE INDICATOR
117-94052-01	ANNUNCIATOR PANEL
117-94052-03	ANNUNCIATOR PANEL
117-94052-05	ANNUNCIATOR PANEL
117-94052-07	ANNUNCIATOR PANEL
117-94052-09	ANNUNCIATOR PANEL
117-940521	AIRSPEED INDICATOR
117-94052-11	ANNUNCIATOR PANEL
117-94052-13	ANNUNCIATOR PANEL
117-94053-03	TRIPLE TACHOMETER INDICATOR
117-94054-01	FUEL QUANTITY INDICATOR
117-94054-03	FUEL QUANTITY INDICATOR
117-94055-01	VOLTMETER
117-94056-01	GAS PRODUCER TACHOMETER INDICATOR
117-94056-03	GAS PRODUCER TACHOMETER INDICATOR
117-940571-01	TURBINE OUTLET TEMPERATURE INDICATOR

117-94058-01	ENGINE OIL TEMPERATURE INDICATOR
117-94058-03	ENGINE OIL TEMPERATURE INDICATOR
117-94058-05	ENGINE OIL TEMPERATURE INDICATOR
117-94058-07	ENGINE OIL TEMPERATURE INDICATOR
117-94059-01	DC AMMETER
117-94059-03	DUAL AMMETER
117-94059-05	DUAL AMMETER
117-94059-07	AMMETER
117-94061-01	RPM WARNING BOX
117-94062-01	HYDRAULIC PRESSURE INDICATOR
117-940691	DUAL TORQUE INDICATOR
117-94133	CLOCK
117-96135	ANTI-COLLISION LIGHT
119-32-07-002	TURBINE OUTLET TEMPERATURE INDICATOR
119-3207-005	TEMPERATURE & PRESSURE INDICATOR
1200-1F(0D)	GYRO HORIZON
1200-1FK(20B)	GYRO HORIZON
1200-1R(0B)	GYRO HORIZON
1200-1R(0D)	GYRO HORIZON
1200-1R(10D)	GYRO HORIZON
1200-1R(11D)	GYRO HORIZON
1200-1R(12B)	GYRO HORIZON
1200-1R(12D)	GYRO HORIZON
1200-1R(14D)	GYRO HORIZON
1200-1R(15A)	GYRO HORIZON
1200-1R(15B)	GYRO HORIZON
1200-1R(15D)	GYRO HORIZON
1200-1R(17D)	GYRO HORIZON
1200-1R(18D)	GYRO HORIZON
1200-1R(20D)	GYRO HORIZON
1200-1R(5D)	GYRO HORIZON
1200-1R(7A)	GYRO HORIZON
1200-1R(8D)	GYRO HORIZON
1200-1RK(10D)	GYRO HORIZON
1200-1RS(11D)	GYRO HORIZON
1200-1RS(12D)	GYRO HORIZON
1200-1RS(14D)	GYRO HORIZON
1200-1RS(15D)	GYRO HORIZON
1200-1RS(18D)	GYRO HORIZON
1200-1RS(5D)	GYRO HORIZON
1200-1RS(8D)	GYRO HORIZON
1200-1RSK(10D)	GYRO HORIZON
12002-0105	ALTIMETER
12002-0106	ALTIMETER
1200-2F(0C)	GYRO HORIZON
1200-2F(10C)	GYRO HORIZON
1200-2F(15D)	GYRO HORIZON

1200-2F(8D)	GYRO HORIZON
1200-2FS(0D)	GYRO HORIZON
1200-2FS(15D)	GYRO HORIZON
1200-2R(0C)	GYRO HORIZON
1200-2R(0D)	GYRO HORIZON
1200-2R(20B)	GYRO HORIZON
1200-2R(20D)	GYRO HORIZON
1200-2R(8F)	GYRO HORIZON
1200-2RS(0D)	GYRO HORIZON
1200-2RS(12D)	GYRO HORIZON
1200-2RS(15D)	GYRO HORIZON
1200-2RS(19C)	GYRO HORIZON
1200-2RS(22B)	GYRO HORIZON
1200-2RS(22E)	GYRO HORIZON
1200-2RS(7D)	GYRO HORIZON
12003M	ALTIMETER
1200-5R(15B)	GYRO HORIZON
1200-6R(10B)	GYRO HORIZON
1200-6R(5B)	GYRO HORIZON
1200-7R(6D)	GYRO HORIZON
1200-7RS(0D)	GYRO HORIZON
12008-13	ALTIMETER
12008-9	ALTIMETER
1200-8R(0B)	GYRO HORIZON
12009-1000	ALTIMETER
12009-2000	ALTIMETER
1200-9F(10B)	GYRO HORIZON
1201617-11373-5	ALTIMETER
1201F2A1A1A	TRANSDUCER
120-IN-0067	T4 TEMPERATURE INDICATOR
12-1100-1	AMMETER
12-1100-2	AMMETER
12-1100-3	AMMETER
12-1100-4	AMMETER
12-1200-09L	AMMETER
12-1200-1	AMMETER
12-1200-2	AMMETER
12-1200-3	AMMETER
12-1200-4	AMMETER
12-1200-5	AMMETER
121672-01-15	DISPLACEMENT GYRO
121672-01-16	DISPLACEMENT GYRO
121672-01-17	ROLL AND PITCH DISPLACEMENT GYRO
121F4502	SOLENOID VALVE
122.444-10	TURBINE OUTLET CONTROL INDICATOR
12-2004-1	VOLT/AMMETER
12-2004-10	VOLT/AMMETER

12-2004-11	VOLT/AMMETER
12-2004-13	VOLT/AMMETER
12-2004-14	VOLT/AMMETER
12-2004-15	VOLT/AMMETER
12-2004-16	VOLT/AMMETER
12-2004-17	VOLT/AMMETER
12-2004-18	VOLT/AMMETER
12-2004-19	VOLT/AMMETER
12-2004-2	VOLT/AMMETER
12-2004-20	VOLT/AMMETER
12-2004-21	VOLT/AMMETER
12-2004-24	VOLT/AMMETER
12-2004-3	VOLT/AMMETER
12-2004-4	VOLT/AMMETER
12-2004-5	VOLT/AMMETER
12-2004-6	VOLT/AMMETER
12-2004-7	VOLT/AMMETER
12-2004-8	VOLT/AMMETER
12-2004-9	VOLT/AMMETER
12-2006-01	VOLT/AMMETER
1221L1	AIRSPEED TRANSDUCER
122Y025	OIL TEMPERATURE & PRESSURE INDICATOR
122Y026	OIL TEMPERATURE & PRESSURE INDICATOR
1234T100	TURN AND BANK INDICATOR
1234T100-1	TURN AND BANK INDICATOR
1234T100-1A	TURN AND BANK INDICATOR
1234T100-1B	TURN AND BANK INDICATOR
1234T100-1BE	TURN AND BANK INDICATOR
1234T100-1BT	TURN AND BANK INDICATOR
1234T100-1BTE	TURN AND BANK INDICATOR
1234T100-1T	TURN AND BANK INDICATOR
1234T100-1TE	TURN AND BANK INDICATOR
1234T100-3	TURN AND BANK INDICATOR
1234T100-3A	TURN AND BANK INDICATOR
1234T100-3AT	TURN AND BANK INDICATOR
1234T100-3ATE	TURN AND BANK INDICATOR
1234T100-3ATY	TURN AND BANK INDICATOR
1234T100-3ATZ	TURN AND BANK INDICATOR
1234T100-3T	TURN AND BANK INDICATOR
1234T100-3TE	TURN AND BANK INDICATOR
1234T100-3TY	TURN AND BANK INDICATOR
1234T100-3TZ	TURN AND BANK INDICATOR
1234T100-5 (A)	TURN AND BANK INDICATOR
1234T100-5 (L)	TURN AND BANK INDICATOR
1234T100-5 (P)	TURN AND BANK INDICATOR
1234T100-5 (T)	TURN AND BANK INDICATOR
1234T100-5 AT	TURN AND BANK INDICATOR

1234T100-5 ATE	TURN AND BANK INDICATOR
1234T100-5 LT	TURN AND BANK INDICATOR
1234T100-5 LTE	TURN AND BANK INDICATOR
1234T100-5 PT	TURN AND BANK INDICATOR
1234T100-5 PTE	TURN AND BANK INDICATOR
1234T100-5 TE	TURN AND BANK INDICATOR
1234T100-7ATZ	TURN AND BANK INDICATOR
1234T100-7TZ	TURN AND BANK INDICATOR
1234T100-8ATZ	TURN & SLIP INDICATOR
1234T100-AT	TURN AND BANK INDICATOR
1234T100-ATE	TURN AND BANK INDICATOR
1234T100-BTY	TURN AND BANK INDICATOR
1234T100-BTZ	TURN AND BANK INDICATOR
1234T100-TY	TURN AND BANK INDICATOR
124.014-1	FUEL PRESSURE & LOAD METER
124.014-2	FUEL PRESSURE & LOAD METER
124.014-23	OIL TEMPERATURE & PRESSURE INDICATOR
124.014-25	OIL TEMPERATURE & PRESSURE INDICATOR
124.014-3	FUEL PRESSURE & LOAD METER
124.014-4	FUEL PRESSURE & LOAD METER
124.014-5	FUEL PRESSURE & LOAD METER
124.039-3	DUAL AMMETER
124.039-6	AMP INDICATOR
124.040-1	VOLTMETER
124.041-1	OIL TEMPERATURE & PRESSURE INDICATOR
124.041-12	OIL TEMPERATURE & PRESSURE INDICATOR
124.041-2	OIL TEMPERATURE & PRESSURE INDICATOR
124.041-3	OIL TEMPERATURE & PRESSURE INDICATOR
124.043-1	OIL TEMPERATURE & PRESSURE INDICATOR
124.044-2	FUEL PRESSURE INDICATOR
124.044-3	FUEL PRESSURE INDICATOR
124.067-2	INTER TURBINE TEMPERATURE INDICATOR
124.1012.5	OIL TEMPERATURE & PRESSURE INDICATOR
124.1012.7	OIL TEMPERATURE & PRESSURE INDICATOR
124.1012-1	OIL TEMPERATURE & PRESSURE INDICATOR
124.1012-3	OIL TEMPERATURE & PRESSURE INDICATOR
124.1012-5	OIL TEMPERATURE & PRESSURE INDICATOR
124.1012-7	OIL TEMPERATURE & PRESSURE INDICATOR
124.1013-1	OIL TEMPERATURE & PRESSURE INDICATOR
124.1013-2	OIL TEMPERATURE & PRESSURE INDICAT0R
124.1014-1	FUEL PRESSURE & LOAD METER
124.1014-2	FUEL PRESSURE & LOAD METER
124.1014-3	FUEL PRESSURE & LOAD METER
124.1014-4	FUEL PRESSURE & LOAD METER
124.1014-5	FUEL PRESSURE & LOAD METER
124.1128-1	DUAL AMMETER
124.1129-1	DUAL AMMETER

124.1129-3	DUAL AMMETER
124.1130-1	DC VOLTMETER
124.1130-2	VOLTMETER
124.115-1	OIL TEMPERATURE & PRESSURE INDICATOR
124.115-3	OIL TEMPERATURE & PRESSURE INDICATOR
124.115-5	OIL TEMPERATURE & PRESSURE INDICATOR
124.120-3	INTER TURBINE TEMPERATURE INDICATOR
124.243-11	TEMPERATURE & PRESSURE INDICATOR
124.244-1	VOLTMETER
124.244-102	VOLTMETER
124.244-11	VOLTMETER
124.244-2	VOLTMETER
124.272-1	INTER TURBINE TEMPERATURE INDICATOR
124.273-5	TEMPERATURE & PRESSURE INDICATOR
124.324-5	INTER TURBINE TEMPERATURE INDICATOR
124.331-3	INTER TURBINE TEMPERATURE INDICATOR
124.412-2	INDICATOR
124.444-0	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-10	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-12	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-14	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-16	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-18	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-2	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-20	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-4	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-6	TURBINE OUTLET TEMPERATURE INDICATOR
124.444-8	TURBINE OUTLET TEMPERATURE INDICATOR
124.480.3	INTER TURBINE TEMPERATURE INDICATOR
124.480-1	INTER TURBINE TEMPERATURE INDICATOR
124.480-3	INTER TURBINE TEMPERATURE INDICATOR
124.498-	ENGINE OIL TEMPERATURE INDICATOR
124.498-1	ENGINE OIL TEMPERATURE INDICATOR
124.498-2	ENGINE OIL TEMPERATURE INDICATOR
124.498-3	ENGINE OIL TEMPERATURE INDICATOR
124.498-4	ENGINE OIL TEMPERATURE INDICATOR
124.498-5	ENGINE OIL TEMPERATURE INDICATOR
124.498-6	ENGINE OIL TEMPERATURE INDICATOR
124.499-	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-0	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-1	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-10	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-2	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-4	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-5	TURBINE OUTLET TEMPERATURE INDICATOR
124.499-6	TURBINE OUTLET TEMPERATURE INDICATOR
124.500-1	TEMPERATURE INDICATOR

124.500-2	TEMPERATURE INDICATOR
124.500-3	TEMPERATURE INDICATOR
124.500-4	TEMPERATURE INDICATOR
124.500-5	TEMPERATURE INDICATOR
124.500-6	TEMPERATURE INDICATOR
124.501-1	VOLTMETER
124.501-2	VOLTMETER
124.503-	TRANSMISSION OIL PRESSURE INDICATOR
124.503-1	TRANSMISSION OIL PRESSURE INDICATOR
124.503-2	TRANSMISSION OIL PRESSURE INDICATOR
124.503-3	TRANSMISSION OIL PRESSURE INDICATOR
124.507-	DC AMMETER
124.507-1	DC AMMETER
124.507-2	DC AMMETER
124.507-3	DC AMMETER
124.507-4	DC AMMETER
124.507-5	DC AMMETER
124.511-1	TORQUE INDICATOR
124.511-2	TORQUE INDICATOR
124.514-1	EGT INDICATOR
124.514-10	EGT INDICATOR
124.514-12	EGT INDICATOR
124.514-2	EGT INDICATOR
124.514-6	EGT INDICATOR
124.550-1	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
124.550-3	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
124.617.2	ELEVATOR POSITION INDICATOR
124.617-1	ELEVATOR POSITION INDICATOR
124.617-2	ELEVATOR POSTION INDICATOR
124.677-1	TEMPERATURE & PRESSURE INDICATOR
124.678-1	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
124.679-1	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
124.714-1	TEMPERATURE & PRESSURE INDICATOR
124.854-7	OIL TEMPERATURE INDICATOR
124.933A	DUAL AMMETER
124.934A	VOLTMETER
124.972A	TEMPERATURE & PRESSURE INDICATOR
124-00005	ALTIMETER
124-014-23	TEMPERATURE & PRESSURE INDICATOR
124040-1	VOLTAGE INDICATOR
124-043	TEMPERATURE & PRESSURE INDICATOR
124-044	FUEL PRESSURE INDICATOR
124-045	TEMPERATURE & PRESSURE INDICATOR
124-069	FUEL PRESSURE INDICATOR
124-1012-5	TEMPERATURE & PRESSURE INDICATOR
124-1012-7	TEMPERATURE & PRESSURE INDICATOR
124623-01-14	DISPLACEMENT GYRO

124-933A	DUAL AMMETER
124-935A	OIL TEMPERATURE & PRESSURE INDICAT0R
124-972A	OIL TEMPERATURE & PRESSURE INDICATOR
124L039-6	DUAL AMMETER
124L507-6	DUAL AMMETER
124Q1348	FUEL QUANTITY INDICATOR
124Q1349	FUEL QUANTITY INDICATOR
124T1340	INTER TURBINE TEMPERATURE INDICATOR
124T1345	INTER TURBINE TEMPERATURE INDICATOR
124T499-7	TURBINE OUTLET TEMPERATURE INDICATOR
124Y498-7	TEMPERATURE & PRESSURE INDICATOR
12-5000-1	VOLTMETER
12-5000-2	VOLTMETER
12-5000-3	VOLTMETER
12-5000-4	VOLTMETER
12-5000-5	VOLTMETER
12-5000-6L	VOLTMETER
125810-11	HORIZONTAL SITUATION INDICATOR
126.067-2	INTER TURBINE TEMPERATURE INDICATOR
126.306-5	FUEL QUANTITY INDICATOR
126.306-7	FUEL QUANTITY INDICATOR
126.307-5	FUEL QUANTITY INDICATOR
127-23006-01	PANEL
127-23008-01	PANEL
127-23009-01	PANEL
127-23011-01	PANEL
127-23012-01	PANEL
127-23013-01	PANEL
127-23031-01	PANEL
127-23032-01	PANEL
127-23033-01	PANEL
129544-001	SELECTOR ASSEMBLY
1296U-4-0194	AIRSPEED INDICATOR
1296U-4-0207	AIRSPEED INDICATOR
1300-0001	ALTIMETER
130005C	MOTOR DRIVEN VALVE
1300-1001	ALTIMETER
1300-102	ALTIMETER
1300-2001	ALTIMETER
130-020-1	FUEL PRESSURE TRANSMITTER
130-020-3	FUEL PRESSURE TRANSMITTER
1301-1001	ALTIMETER
1301-1002	ALTIMETER
1301-102	ALTIMETER
1301-2001	ALTIMETER
130-380044-7	TURBINE RPM INDICATOR
131348-3	TURBINE SPEED INDICATOR

131-9043-1003	OIL PRESSURE INDICATOR
13452-1100	ALTIMETER
1346-28-09	PANEL
13502-0201	ALTIMETER
13502-0202	ALTIMETER
13503M	ALTIMETER
13508-1	ALTIMETER
13508-5	ALTIMETER
13522-1000	ALTIMETER
13522-1100	ALTIMETER
1372-1-101	RPM LIMIT DETECTOR
1372-1-5	RPM LIMIT DETECTOR
138740-15	HORIZONTAL SITUATION INDICATOR
138740-17	HORIZONTAL SITUATION INDICATOR
138740-19	HORIZONTAL SITUATION INDICATOR
138740-23	HORIZONTAL SITUATION INDICATOR
138740-25	HORIZONTAL SITUATION INDICATOR
138740-5	HORIZONTAL SITUATION INDICATOR
138740-9	HORIZONTAL SITUATION INDICATOR
138AS	AIRSPEED INDICATOR
1394T100-1	TURN AND SLIP INDICATOR
1394T100-11	TURN AND SLIP INDICATOR
1394T100-11E	TURN AND SLIP INDICATOR
1394T100-13	TURN AND SLIP INDICATOR
1394T100-13E	TURN AND SLIP INDICATOR
1394T100-13P	TURN AND SLIP INDICATOR
1394T100-13PE	TURN AND SLIP INDICATOR
1394T100-13PY	TURN AND SLIP INDICATOR
1394T100-13Y	TURN AND SLIP INDICATOR
1394T100-15Z	TURN AND SLIP INDICATOR
1394T100-1E	TURN AND SLIP INDICATOR
1394T100-1W	TURN AND SLIP INDICATOR
1394T100-1WE	TURN AND SLIP INDICATOR
1394T100-1WV	TURN AND SLIP INDICATOR
1394T100-1WVE	TURN AND SLIP INDICATOR
1394T100-3	TURN AND SLIP INDICATOR
1394T100-313P	TURN AND SLIP INDICATOR
1394T100-313PE	TURN AND SLIP INDICATOR
1394T100-35	TURN AND SLIP INDICATOR
1394T100-35E	TURN AND SLIP INDICATOR
1394T100-35P	TURN AND SLIP INDICATOR
1394T100-35PE	TURN AND SLIP INDICATOR
1394T100-37	TURN AND SLIP INDICATOR
1394T100-37E	TURN AND SLIP INDICATOR
1394T100-39	TURN AND SLIP INDICATOR
1394T100-39E	TURN AND SLIP INDICATOR
1394T100-3E	TURN AND SLIP INDICATOR

1394T100-3W	TURN AND SLIP INDICATOR
1394T100-3Z	TURN AND SLIP INDICATOR
1394T100-5W	TURN AND SLIP INDICATOR
1394T100-7Z	TURN AND SLIP INDICATOR
1394T100-VWY	TURN AND SLIP INDICATOR
1394T100-WVZ	TURN AND SLIP INDICATOR
1394T100-WY	TURN AND SLIP INDICATOR
1394T100-WZ	TURN AND SLIP INDICATOR
13DC02A	TORQUE INDICATOR
140100-01-01	ATTITUDE INDICATOR
140540-01-01	RATE GYRO TRANSMITTER
141-20339-001	ANNUNCIATOR PANEL
141400-01-01	ATTITUDE INDICATOR
1426-1Z-A1	AIRSPEED INDICATOR
143100-01-02	ATTITUDE INDICATOR
144700-01-01	ATTITUDE INDICATOR
14550-729-2	MACH AIRSPEED INDICATOR
145974-01-03	VERTICAL GYRO
14602-1J-A1	ATTITUDE INDICATOR
14602-1J-B1	ATTITUDE INDICATOR
14602-1J-C1	ATTITUDE INDICATOR
14602-1J-D1	ATTITUDE INDICATOR
14602-1J-E1	ATTITUDE INDICATOR
14602-1J-F1	ATTITUDE INDICATOR
14608-1AP-B1	ATTITUDE INDICATOR
14608-1APB1-M	ATTITUDE INDICATOR
14608-1AZ-B1	GYRO HORIZON
14609-1AW-C1	GYRO HORIZON
14609-1S-A1	GYRO HORIZON
14609-1S-B1	GYRO HORIZON
14609-1S-C1	GYRO HORIZON
14613-1AK-A2	ATTITUDE INDICATOR
14613-1AK-A3	ATTITUDE INDICATOR
14613-1AK-A4	ATTITUDE INDICATOR
14613-1AK-A5	ATTITUDE INDICATOR
14613-1AK-A6	ATTITUDE INDICATOR
14-73903-5	HANDGRIP
147B13	TEMPERATURE INDICATOR
147B13A	TEMPERATURE INDICATOR
147B30	TEMPERATURE INDICATOR
147B30A	TEMPERATURE INDICATOR
147B31	TEMPERATURE INDICATOR
147B31A	TEMPERATURE INDICATOR
147B31A2	TEMPERATURE INDICATOR
147B31A3	TEMPERATURE INDICATOR
147B31A4	TEMPERATURE INDICATOR
147B31B	TEMPERATURE INDICATOR

147B31C	TEMPERATURE INDICATOR
147B7	TEMPERATURE INDICATOR
147B7A	TEMPERATURE INDICATOR
147B8	TEMPERATURE INDICATOR
148-13000-06	SEARCHLIGHT
148700-01-01	ATTITUDE INDICATOR
149190-01-02	ATTITUDE GYRO
149AC2	RPM INDICATOR
15 DA01R-TYP 1557	TACHOMETER INDICATOR
15020-6501	ALTIMETER
15025-2105	ALTIMETER
151-906-001	FUEL FLOW TRANSDUCER
152.201-2	HYDRAULIC PRESSURE INDICATOR
1523-20683-2	INTER TURBINE TEMPERATURE INDICATOR
152BL2D	TEMPERATURE INDICATOR
152BL702	TEMPERATURE INDICATOR
152BL702A	TEMPERATURE INDICATOR
152BL702C	TEMPERATURE INDICATOR
152BL702D	TEMPERATURE INDICATOR
152BL702E	TEMPERATURE INDICATOR
152BL703	TEMPERATURE INDICATOR
152BL704	TEMPERATURE INDICATOR
152BL706	TEMPERATURE INDICATOR
152BL708	TEMPERATURE INDICATOR
152BL708A	TEMPERATURE INDICATOR
152BL708B	TEMPERATURE INDICATOR
152BL708H	TEMPERATURE INDICATOR
152BL709	TEMPERATURE INDICATOR
152BL709A	TEMPERATURE INDICATOR
152BL722	TEMPERATURE INDICATOR
152BL801	TEMPERATURE INDICATOR
152BL801A	TEMPERATURE INDICATOR
152BL801B	TEMPERATURE INDICATOR
152BL801C	TEMPERATURE INDICATOR
152BL801D	TEMPERATURE INDICATOR
152BL801E	TEMPERATURE INDICATOR
152BL802A	TEMPERATURE INDICATOR
152BL802B	TEMPERATURE INDICATOR
152BL802C	TEMPERATURE INDICATOR
152BL802D	TEMPERATURE INDICATOR
152BL803	TEMPERATURE INDICATOR
152BL803A	TEMPERATURE INDICATOR
152BL803B	TEMPERATURE INDICATOR
152BL803C	TEMPERATURE INDICATOR
152C2D	TEMPERATURE INDICATOR
152C305	TEMPERATURE INDICATOR
152HL2W	TEMPERATURE INDICATOR

152HL2W3	TEMPERATURE INDICATOR
155010-1	ENCODING ALTIMETER
155010-1-LX	ENCODING ALTIMETER
155010-2	ENCODING ALTIMETER
155010-2-LX	ENCODING ALTIMETER
1560-0458-114-1	LANDING LIGHT
1560-OH58-114-1	LANDING LIGHT
1564T100-5	ACTUATOR
1564T100-9	LINEAR ACTUATOR
1588-2-F	VOLTAGE REGULATOR
1588-3-B	VOLTAGE REGULATOR
1589-1	VOLTAGE REGULATOR
1589-1F	VOLTAGE REGULATOR
1589-1-F	VOLTAGE REGULATOR
1589-7-B	VOLTAGE REGULATOR
1592-00059	OAT GAUGE
15DA01A-TYP1204	TACHOMETER INDICATOR
15DA03B	TRIPLE TACHOMETER INDICATOR
15DA03-TYP1277	TRIPLE TACHOMETER INDICATOR
15E-413	AMMETER
16007-11	ENCODING ALTIMETER
16007-12	ENCODING ALTIMETER
16007-13	ENCODING ALTIMETER
16007-14	ENCODING ALTIMETER
16007-15	ENCODING ALTIMETER
16007-16	ENCODING ALTIMETER
16007-348	ENCODING ALTIMETER
162B2	ELECTRICAL RESISTANCE THERMOMETER
162B203	OIL TEMPERATURE INDICATOR
162B2D	ELECTRICAL RESISTANCE THERMOMETER
162B3	OIL TEMPERATURE INDICATOR
162B3A	ELECTRICAL RESISTANCE THERMOMETER
162B4	ELECTRICAL RESISTANCE THERMOMETER
162BL101A	TEMPERATURE INDICATOR
16340 / 475-1	VOLTAGE REGULATOR
16340-473-1	VOLTAGE REGULATOR
1636-6H-B1	CLIMB GAUGE
164-1	LIQUID OXYGEN INDICATOR
164A168-1	FUEL PUMP
165000-3	LIGHT DIMMER
16650-1150	ALTIMETER
1680-4U-A2	CABIN RATE OF CLIMB INDICATOR
1680-4U-A3	CABIN RATE OF CLIMB INDICATOR
169BR-909-1LBW	CLUSTER GAUGE
169BR-910-1-1LBW	CLUSTER GAUGE
169BR-910-2-1LBW	CLUSTER GAUGE
169BR-910-2L	OIL PRESSURE INDICATOR

169BR-910-2LBW	CLUSTER GAUGE
169BR-910-3LBW	CLUSTER GAUGE
169P909-1L	LOADMETER
169P909-1LBW	LOADMETER
169P910-22L	FUEL QUANTITY INDICATOR
169P910-22L-2BW	FUEL QUANTITY INDICATOR
169P910-5L	OIL PRESSURE INDICATOR
169P910-5L1	OIL TEMPERATURE & PRESSURE INDICATOR
169P-910-5L1BW5	TEMPERATURE INDICATOR
169P910-5L-2BW	OIL PRESSURE INDICATOR
169P910-5L-3BW	OIL TEMPERATURE & PRESSURE INDICATOR
169P914-5L	OIL PRESSURE INDICATOR
169P914-5L1	OIL PRESSURE INDICATOR
169P914-5L-2BW	OIL PRESSURE INDICATOR
169P914-5L-3BW	OIL PRESSURE INDICATOR
169P914-6L	FUEL PRESSURE INDICATOR
169P914-6L-1BW	FUEL PRESSURE INDICATOR
169P914-6L-2BW	FUEL PRESSURE INDICATOR
1704-1001-2	RPM LIMIIT DETECTOR
1704-1009-1	RPM LIMIIT DETECTOR
1704-1014-1A	RPM LIMIIT DETECTOR
171BS101-1	POWER SUPPLY
171BS101-2	POWER SUPPLY
171BS101-M	POWER SUPPLY
17343-771-310F	DETECTOR
1783755-615	COMPASS
17AT10B	THERMOCOUPLE THERMOMETER INDICATOR
17AT4BN	THERMOCOUPLE THERMOMETER INDICATOR
17AT4P	THERMOCOUPLE THERMOMETER INDICATOR
17B2A	THERMOCOUPLE THERMOMETER INDICATOR
17B3	THERMOCOUPLE THERMOMETER INDICATOR
18-1000-1	ENGINE GAGE UNIT
18-1000-2	ENGINE GAGE UNIT
18-1000-3	ENGINE GAGE UNIT
18-1000-4	ENGINE GAGE UNIT
18-1105	HYDRAULIC PRESSURE INDICATOR
18-1278	OIL PRESSURE INDICATOR
18-1700	PRESSURE INDICATOR
18-1732-1	COURSE INDICATOR
18-1838-11	DUAL TORQUE INDICATOR
18-1838-15	DUAL TORQUE INDICATOR
18-1838-17	DUAL TORQUE INDICATOR
18-1838-21	DUAL TORQUE INDICATOR
18-1838-22	DUAL TORQUE INDICATOR
18-1842.7	PRESSURE TRANSMITTER
18-1874	COURSE INDICATOR
18-1958-10	FLAP POSITION TRANSMITTER

18-1958-11	FLAP POSITION TRANSMITTER
18-1958-12	FLAP POSITION TRANSMITTER
18-1958-13	FLAP POSITION TRANSMITTER
18-1958-14	FLAP POSITION TRANSMITTER
18-1958-15	FLAP POSITION TRANSMITTER
18-1958-16	FLAP POSITION TRANSMITTER
18-1958-17	FLAP POSITION TRANSMITTER
18-1958-19	FLAP POSITION TRANSMITTER
18-1958-20	FLAP POSITION TRANSMITTER
18-1969-12	FLAP POSITION TRANSMITTER
18-1969-17	FLAP POSITION TRANSMITTER
18-1969-18	FLAP POSITION TRANSMITTER
1829-3	VOLTAGE REGULATOR
18-380021	DIRECTIONAL GYRO
1845X-4-03	ALTIMETER
18C100-1	ENGINE GAGE UNIT
18C452-1	ENGINE GAGE UNIT
18V100-1	ENGINE GAGE UNIT
19-0035	AMMETER
1913HT	INDICATOR
19654-0	FLUX VALVE
19710-R10A	ACTUATOR
1978191-1	ATTITUDE GYRO
19A2178	FAN
19A2501	FAN VANEAXIAL
19A2593	FAN VANEAXIAL
19A827	FAN
1A125-1A	STATIC INVERTER
1A125-1B-1	STATIC INVERTER
1A125-1C-1	STATIC INVERTER
1A250	STATIC INVERTER
1A250(-ID)	STATIC INVERTER
1A250-1D	STATIC INVERTER
1A50-1A	STATIC INVERTER
1A50-1B-1	STATIC INVERTER
1A50-1C-1	STATIC INVERTER
1B1000-1D-1	STATIC INVERTER
1B1000-1G	STATIC INVERTER
1B1000-1G-AM-912	STATIC INVERTER
1B1000-1GJ-2044	STATIC INVERTER
1B1000-1G-RR-1657	STATIC INVERTER
1B1000-1G-RR-901	STATIC INVERTER
1B1000-1GS	STATIC INVERTER
1B250-1A	STATIC INVERTER
1B250-1B-1	STATIC INVERTER
1B250-1B-1/B1642	STATIC INVERTER
1B250-1B1-DB	STATIC INVERTER

1B250-1B-1PS	STATIC INVERTER
1B250-1C	STATIC INVERTER
1B250-1D-1	STATIC INVERTER
1B250-1E-1	STATIC INVERTER
1B250-1F-1	STATIC INVERTER
1B250-B212-1661	STATIC INVERTER
1B350-1A	STATIC INVERTER
1B350-1B-1	STATIC INVERTER
1B350-1B-1-3	STATIC INVERTER
1B350-1B-2	STATIC INVERTER
1B350-1B-FK-1008	STATIC INVERTER
1B350-1C-1	STATIC INVERTER
1B350-1D	STATIC INVERTER
1B800-1D-1	STATIC INVERTER
1B800-1G	STATIC INVERTER
1B800-1GLN-1001	STATIC INVERTER
1B800-1GN-1001	STATIC INVERTER
1C64-1	FUEL BOOST PUMP
1D250A/ARN	COURSE INDICATOR
1D851	CHIP DETECTOR
1K426-90090007-01	OIL TEMPERATURE & PRESSURE INDICAT0R
1U149-001-1	GYRO HORIZON
1U149-001-2	GYRO HORIZON
1U149-001-3	GYRO HORIZON
1U149-002	GYRO HORIZON
1U149-002-1	GYRO HORIZON
1U149-002-2	GYRO HORIZON
1U149-002-3	GYRO HORIZON
1U149-005	GYRO HORIZON
1U149-010	GYRO HORIZON
1U254-001-4	DIRECTIONAL GYRO
1U254-001-6	DIRECTIONAL GYRO
1U254-001-7	DIRECTIONAL GYRO
1U262-001-1	DIRECTIONAL GYRO
1U262-001-10	DIRECTIONAL GYRO
1U262-001-11	DIRECTIONAL GYRO
1U262-001-13	DIRECTIONAL GYRO
1U262-001-16	DIRECTIONAL GYRO
1U262-001-18	DIRECTIONAL GYRO
1U262-001-2	DIRECTIONAL GYRO
1U262-001-21	DIRECTIONAL GYRO
1U262-001-22	DIRECTIONAL GYRO
1U262-001-24	DIRECTIONAL GYRO
1U262-001-25	DIRECTIONAL GYRO
1U262-001-27	DIRECTIONAL GYRO
1U262-001-29	DIRECTIONAL GYRO
1U262-001-3	DIRECTIONAL GYRO

1U262-001-4	DIRECTIONAL GYRO
1U262-001-5	DIRECTIONAL GYRO
1U262-001-6	DIRECTIONAL GYRO
1U262-001-7	DIRECTIONAL GYRO
1U262-001-9	DIRECTIONAL GYRO
1U262-002-17	DIRECTIONAL GYRO
1U262-002-32	DIRECTIONAL GYRO
1U262-002-8	DIRECTIONAL GYRO
1U378	ENGINE GAUGE
1U569-001	CLUSTER GAUGE
1U569-002	CLUSTER GAUGE
1U569-1	CLUSTER GAUGE
1ZL122M01	MASTER ALARM AND INDICATION PANEL
1ZZ205M	POWER SUPPLY
1ZZ210M	MASTER ALARM AND INDICATION PANEL
200 SERIES	DIRECTIONAL GYRO
200-10	DIRECTIONAL GYRO
200-10BL	DIRECTIONAL GYRO
200-11	DIRECTIONAL GYRO
20015-11187	AIRSPEED INDICATOR
20015-11245	AIRSPEED INDICATOR
20015-11283	AIRSPEED INDICATOR
20016-11232	AIRSPEED INDICATOR
20016-11292	AIRSPEED INDICATOR
20018-01104	AIRSPEED INDICATOR
20018-11233	AIRSPEED INDICATOR
20018-11292	AIRSPEED INDICATOR
20018-11332	AIRSPEED INDICATOR
20020-11212	AIRSPEED INDICATOR
20020-11293	AIRSPEED INDICATOR
20020-11365	AIRSPEED INDICATOR
20020-11388	AIRSPEED INDICATOR
20020-11409	AIRSPEED INDICATOR
20022-0000-0101	FUEL QUANTITY TANK UNIT
20022-0000-0102	FUEL QUANTITY TANK UNIT
20022-0000-0103	FUEL QUANTITY TANK UNIT
20022-0000-0104	FUEL QUANTITY TANK UNIT
20022-0000-0105	FUEL QUANTITY TANK UNIT
20022-0000-0106	FUEL QUANTITY TANK UNIT
20022-0000-0107	FUEL QUANTITY TANK UNIT
20022-0000-0108	FUEL QUANTITY TANK UNIT
20-035008-300	FIRE & OVERHEAT DETECTION CONTROL UNIT
20036-0000-0101	FUEL PROBE
20036-0000-0102	FUEL QUANTITY TRANSMITTER
20036-0000-0103	FUEL PROBE
20037-0000-01	FUEL QUANTITY TRANSMITTER
20038-0000-01	FUEL QUANTITY TRANSMITTER

20040-0113	AIRSPEED INDICATOR
20040-0145	AIRSPEED INDICATOR
20040-0186	AIRSPEED INDICATOR
20041-0000-03	LIQUID QUANTITY ENGINE OIL TRANSMITTER
20042-0000-01	FUEL PROBE
200-6	DIRECTIONAL GYRO
20067-0000-0101	FUEL QUANTITY TANK UNIT
20068-0000-0101	FUEL QUANTITY TANK UNIT
200-914-001	FUEL QUANTITY INDICATOR
200-914-002	FUEL QUANTITY INDICATOR
20096-0203	FUEL PROBE
200-9C	DIRECTIONAL GYRO
200-9C3	DIRECTIONAL GYRO
200-9M	DIRECTIONAL GYRO
200-9M3	DIRECTIONAL GYRO
200DC	DIRECTIONAL GYRO
200DC (BELL)	DIRECTIONAL GYRO
200DC Bell	DIRECTIONAL GYRO
200DC(14)	DIRECTIONAL GYRO
200DC(28)	DIRECTIONAL GYRO
200DC(BELL)	DIRECTIONAL GYRO
200DC28	DIRECTIONAL GYRO
200DCBELL	DIRECTIONAL GYRO
200DCFM	DIRECTIONAL GYRO
200DCL	DIRECTIONAL GYRO
200DCL(28)	DIRECTIONAL GYRO
200E	DIRECTIONAL GYRO
200ED	DIRECTIONAL GYRO
200EDC	DIRECTIONAL GYRO
200H	DIRECTIONAL GYRO
201-0001	TORQUE CONVERTER
201-004-001	TORQUE INDICATOR
20140-01210	AIRSPEED INDICATOR
20-2000	TURN AND BANK INDICATOR
20-224-01	INDICATOR
20-226-01	TOTALIZER FUEL QUANTITY INDICATOR
20242005-104	COMPASS CONTROL INDICATOR
203-021-003	FUEL QUANTITY INDICATOR
203-022-008	TRANSMISSION OIL TEMPERATURE INDICATOR
203-022-009	OIL PRESSURE INDICATOR
203-023-003	HYDRAULIC PRESSURE INDICATOR
20-380	TURN AND SLIP INDICATOR
204-001-376-001	MAGNETIC BRAKE
204-001-376-003	MAGNETIC BRAKE
204-001-376-1	MAGNETIC BRAKE
204-001-376-103	MAGNETIC BRAKE
204-001-376-105	MAGNETIC BRAKE

204-001-376-3	MAGNETIC BRAKE
204-040-376-003	TRANSMISSION OIL PRESSURE SWITCH
204-040-376-3	TRANSMISSION OIL PRESSURE SWITCH
204-060-006	PTIT INDICATOR
204-060-683-005	FUEL QUANTITY INDICATOR
204-060-683-5	FUEL QUANTITY INDICATOR
204-060-762-001	ACTUATOR
204-060-762-005	ACTUATOR
204-060-762-009	ACTUATOR
204-060-762-011	ACTUATOR
204-060-762-013	ACTUATOR
204-060-762-1	ACTUATOR
204-060-762-103	ACTUATOR
204-060-762-11	ACTUATOR
204-060-762-13	ACTUATOR
204-060-762-5	ACTUATOR
204-060-762-9	ACTUATOR
204-061-606-001	TRANSMITTER
204-061-606-1	TRANSMITTER
204-062-520-003	SHUT OFF VALVE
204-062-520-3	SHUT OFF VALVE
204-070-155-001	DUAL TACHOMETER INDICATOR
204-070-155-1	DUAL TACHOMETER INDICATOR
204-070-482-001	SELECTOR ASSEMBLY
204-070-482-1	SELECTOR ASSEMBLY
204-070-907-001	WIPER MOTOR
204-070-907-002	MOTOR AND CONVERTOR ASSY LH
204-070-907-1	MOTOR CONVERTER
204-070-907-101	WIPER MOTOR
204-070-907-102	WIPER MOTOR
204-070-907-103	MOTOR AND CONVERTER ASSEMBLY
204-070-907-104	WIPER MOTOR
204-070-907-2	MOTOR AND CONVERTOR
204-072-129-001	DUAL TACHOMETER INDICATOR
204-072-129-003	DUAL TACHOMETER INDICATOR
204-072-129-005	DUAL TACHOMETER INDICATOR
204-072-129-1	DUAL TACHOMETER INDICATOR
204-072-129-101	DUAL TACHOMETER INDICATOR
204-072-129-3	DUAL TACHOMETER INDICATOR
204-072-129-5	DUAL TACHOMETER INDICATOR
204-072-166-001	FREE AIR TEMPERATURE
204-072-184-001	TORQUE PRESSURE INDICATOR
204-075-222-001	HYDRAULIC CONTROL PANEL
204-075-527-101	LIGHT ASSEMBLY
204-075-705-003	MASTER CAUTION PANEIL
204-075-705-045	MASTER CAUTION PANEIL
204-075-705-047	MASTER CAUTION PANEIL

204-075-705-073	MASTER CAUTION PANEIL
204-075-705-101	MASTER CAUTION PANEIL
204-075-705-103	MASTER CAUTION PANEIL
204-075-705-3	MASTER CAUTION PANEIL
204-075-705-45	MASTER CAUTION PANEIL
204-1A	EXHAUST GAS TEMPERATURE INDICATOR
205-001-042-001	GRIP ASSEMBLY
205-001-042-1	GRIP ASSEMBLY
205-001-046-001	GRIP ASSEMBLY
205-001-046-003	GRIP ASSEMBLY
205-001-046-1	GRIP ASSEMBLY
205-001-046-101	GRIP ASSEMBLY
205-001-046-103	GRIP ASSEMBLY
205-001-046-105	GRIP ASSEMBLY
205-001-046-115	GRIP ASSEMBLY
205-001-046-121	GRIP ASSEMBLY
205-001-046-3	GRIP ASSEMBLY
205-001-406-101	GRIP ASSEMBLY
205-016-001	FUEL QUANTITY INDICATOR
205-060-606-003	FUEL PUMP
205-060-606-3	FUEL PUMP
205-060-612-003	MOTOR DRIVEN VALVE
205-060-612-101	MOTOR DRIVEN VALVE
205-060-612-3	MOTOR DRIVEN VALVE
205-061-633-007	FUEL QUANTITY INDICATOR
205-061-633-009	FUEL PROBE
205-061-633-011	FUEL PROBE
205-061-633-013	FUEL PROBE
205-061-633-11	FUEL PROBE
205-061-633-13	FUEL PROBE
205-061-633-7	FUEL QUANTITY INDICATOR
205-061-635-001	FUEL FLOW SWITCH
205-061-635-003	FUEL FLOW SWITCH
205-061-635-005	FUEL FLOW SWITCH
205-061-635-1	FUEL FLOW SWITCH
205-061-635-3	FUEL FLOW SWITCH
205-061-635-5	FUEL FLOW SWITCH
205-063-633-011	FUEL PROBE
205-070-282-003	LOADMETER
205-070-283-001	TACHOMETER INDICATOR
205-070-283-003	TACHOMETER INDICATOR
205-070-283-1	TACHOMETER INDICATOR
205-070-283-3	TACHOMETER INDICATOR
205-070-284-003	TEMPERATURE INDICATOR
205-070-284-3	TEMPERATURE INDICATOR
205-072-277-009	MIXING VALVE
205-074-001-001	RPM LIMIIT DETECTOR

205-074-001-1	RPM LIMIIT DETECTOR
205-074-026-001	RPM LIMIIT DETECTOR
205-074-026-1	RPM LIMIIT DETECTOR
205-075-158-001	OIL PRESSURE INDICATOR
205-075-158-1	OIL PRESSURE INDICATOR
205-075-170-001	TORQUE PRESSURE INDICATOR
205-075-170-1	TORQUE PRESSURE INDICATOR
205-075-259-001	HYDRAULIC CONTROL PANEL
205-075-315-001	IMPEDANCE MATCHING NETWORK
205-075-388-001	RPM LIMIIT DETECTOR
205-075-388-003	RPM LIMIIT DETECTOR
205-075-388-005	RPM LIMIIT DETECTOR
205-075-388-007	RPM LIMIIT DETECTOR
205-075-388-009	RPM LIMIIT DETECTOR
205-075-388-011	RPM LIMIIT DETECTOR
205-075-388-013	RPM LIMIIT DETECTOR
205-075-388-015	RPM LIMIT DETECTOR
205-075-388-017	RPM LIMIIT DETECTOR
205-075-388-1	RPM LIMIIT DETECTOR
205-075-388-11	RPM LIMIIT DETECTOR
205-075-388-13	RPM LIMIIT DETECTOR
205-075-388-15	RPM LIMIT DETECTOR
205-075-388-17	RPM LIMIIT DETECTOR
205-075-388-3	RPM LIMIIT DETECTOR
205-075-388-5	RPM LIMIIT DETECTOR
205-075-388-7	RPM LIMIIT DETECTOR
205-075-388-9	RPM LIMIIT DETECTOR
205-075-625-003	CONTROL PANEL ASSEMBLY
205-075-625-005	CONTROL PANEL ASSEMBLY
205-075-626-001	CONTROL PANEL ASSEMBLY
205-075-626-101	CONTROL PANEL ASSEMBLY
205-075-631-005	PANEL
205-075-631-5	PANEL
205-075-636-003	ENGINE CONTROL PANEL
205-075-642-001	RELAY
205-075-642-1	RELAY
205-075-657-101	TORQUE INDICATOR
205-075-807-001	FUEL PRESSURE INDICATOR
205-1A	DIRECTIONAL GYRO
205-1AL	DIRECTIONAL GYRO
205-1B	DIRECTIONAL GYRO
205-1BC	DIRECTIONAL GYRO
205-1BF	DIRECTIONAL GYRO
2051BL	DIRECTIONAL GYRO
205-1BL	DIRECTIONAL GYRO
205-1BLF	DIRECTIONAL GYRO
205-1C	DIRECTIONAL GYRO

205-1CL	DIRECTIONAL GYRO
205-1D	DIRECTIONAL GYRO
2051VL	DIRECTIONAL GYRO
205-1VL	DIRECTIONAL GYRO
205-2A	DIRECTIONAL GYRO
205-2B	DIRECTIONAL GYRO
205-2BL	DIRECTIONAL GYRO
205-2C	DIRECTIONAL GYRO
205-2CL	DIRECTIONAL GYRO
205-375-002-101	TEMPERATURE INDICATOR
205-375-002-103	INTER TURBINE TEMPERATURE INDICATOR
205-375-003-101	TORQUE INDICATOR
205-375-004-101	TEMPERATURE & PRESSURE INDICATOR
205-375-004-103	TEMPERATURE & PRESSURE INDICATOR
205-375-005-101	TEMPERATURE & PRESSURE INDICATOR
205-375-005-103	OIL TEMPERATURE & PRESSURE INDICAT0R
205-6BL	DIRECTIONAL GYRO
205-7BL	DIRECTIONAL GYRO
206-001-026-001	HANDGRIP
206-001-026-1	HANDGRIP
206-001-359-01	HANDGRIP
206-001-365-003	HANDGRIP
206-001-365-3	HANDGRIP
206-003-002	FUEL QUANTITY TRANSMITTER
206-062-502-101	OIL COOLER BLOWER
206-062-504-001	MOTOR DRIVEN VALVE
206-062-504-1	MOTOR DRIVEN VALVE
206-062-625-003	ACTUATOR
206-062-625-3	ACTUATOR
206-062-627-001	TACH GENERATOR
206-062-627-003	TACH GENERATOR
206-062-627-1	TACH GENERATOR
206-062-627-3	TACH GENERATOR
206-062-687-101	FUEL BOOST PUMP
206-062-721-001	LINEAR ACTUATOR
206-062-721-007	LINEAR ACTUATOR
206-062-721-011	LINEAR ACTUATOR
206-062-721-015	LINEAR ACTUATOR
206-062-721-1	LINEAR ACTUATOR
206-062-721-103	LINEAR ACTUATOR
206-062-721-105	LINEAR ACTUATOR
206-062-721-107	LINEAR ACTUATOR
206-062-721-109	LINEAR ACTUATOR
206-062-721-11	LINEAR ACTUATOR
206-062-721-111	LINEAR ACTUATOR
206-062-721-113	LINEAR ACTUATOR
206-062-721-115	LINEAR ACTUATOR

206-062-721-117	LINEAR ACTUATOR
206-062-721-15	LINEAR ACTUATOR
206-062-721-7	LINEAR ACTUATOR
206-063-633-001	FUEL QUANTITY INDICATOR
206-063-633-003	FUEL QUANTITY INDICATOR
206-063-633-1	FUEL QUANTITY INDICATOR
206-063-633-101	FUEL QUANTITY INDICATOR
206-063-633-103	FUEL QUANTITY INDICATOR
206-063-633-106	FUEL QUANTITY INDICATOR
206-063-633-3	FUEL QUANTITY INDICATOR
206-063-640-001	MOTOR DRIVEN VALVE
206-063-640-003	FUEL VALVE
206-063-640-1	MOTOR DRIVEN VALVE
206-063-640-101	MOTOR DRIVEN VALVE
206-063-640-103	MOTOR DRIVEN VALVE
206-063-640-105	MOTOR DRIVEN VALVE
206-063-640-107	MOTOR DRIVEN VALVE
206-063-640-109	MOTOR DRIVEN VALVE
206-063-656-001	FUEL QUANTITY TANK UNIT
206-063-656-003	FUEL QUANTITY TANK UNIT
206-063-656-005	FUEL QUANTITY TANK UNIT
206-063-656-1	FUEL QUANTITY TANK UNIT
206-063-656-3	FUEL QUANTITY TANK UNIT
206-063-656-5	FUEL QUANTITY TANK UNIT
206-063-657-001	FUEL PROBE
206-063-657-003	FUEL PROBE
206-063-657-005	FUEL PROBE
206-063-657-1	FUEL PROBE
206-063-657-101	FUEL PROBE
206-063-657-3	FUEL PROBE
206-063-657-5	FUEL PROBE
206-063-658-001	FUEL PROBE
206-063-658-003	FUEL PROBE
206-063-658-005	FUEL PROBE
206-063-658-1	FUEL PROBE
206-063-658-3	FUEL PROBE
206-063-658-5	FUEL PROBE
206-064-618-001	FUEL PROBE
206-064-618-1	FUEL PROBE
206-064-635-101	FUEL QUANTITY TANK UNIT
206-064-635-103	FUEL QUANTITY TANK UNIT
206-064-636-101	FUEL PROBE
206-064-636-103	FUEL PROBE
206-064-637-101	FUEL PROBE
206-064-637-103	FUEL PROBE
206-070-185-001	TORQUE INDICATOR
206-070-185-003	TORQUE INDICATOR

206-070-185-005	TORQUE INDICATOR
206-070-185-007	TORQUE INDICATOR
206-070-185-1	TORQUE INDICATOR
206-070-185-101	TORQUE INDICATOR
206-070-185-103	TORQUE INDICATOR
206-070-185-105	TORQUE INDICATOR
206-070-185-3	TORQUE INDICATOR
206-070-185-5	TORQUE INDICATOR
206-070-185-7	TORQUE INDICATOR
206-070-241-001	DUAL TACHOMETER INDICATOR
206-070-241-1	DUAL TACHOMETER INDICATOR
206-070-242-001	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-242-003	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-242-1	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-242-3	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-243-001	GAS PRODUCER TACHOMETER INDICATOR
206-070-243-003	GAS PRODUCER TACHOMETER INDICATOR
206-070-243-1	GAS PRODUCER TACHOMETER INDICATOR
206-070-243-3	GAS PRODUCER TACHOMETER INDICATOR
206-070-263-001	ALTIMETER
206-070-263-003	ALTIMETER
206-070-263-005	ALTIMETER
206-070-263-007	ALTIMETER
206-070-263-009	ALTIMETER
206-070-263-1	ALTIMETER
206-070-263-101	ALTIMETER
206-070-263-105	ALTIMETER INDICATOR
206-070-263-3	ALTIMETER
206-070-263-5	ALTIMETER
206-070-263-7	ALTIMETER
206-070-263-9	ALTIMETER
206-070-264-001	AIRSPEED INDICATOR
206-070-264-003	AIRSPEED INDICATOR
206-070-264-005	AIRSPEED INDICATOR
206-070-264-007	AIRSPEED INDICATOR
206-070-264-1	AIRSPEED INDICATOR
206-070-264-3	AIRSPEED INDICATOR
206-070-264-5	AIRSPEED INDICATOR
206-070-264-7	AIRSPEED INDICATOR
206-070-265-001	DUAL TACHOMETER INDICATOR
206-070-265-003	DUAL TACHOMETER INDICATOR
206-070-265-005	DUAL TACHOMETER INDICATOR
206-070-265-007	DUAL TACHOMETER INDICATOR
206-070-265-009	DUAL TACHOMETER INDICATOR
206-070-265-011	DUAL TACHOMETER INDICATOR
206-070-265-1	DUAL TACHOMETER INDICATOR
206-070-265-101	DUAL TACHOMETER INDICATOR

206-070-265-103	DUAL TACHOMETER INDICATOR
206-070-265-11	DUAL TACHOMETER INDICATOR
206-070-265-3	DUAL TACHOMETER INDICATOR
206-070-265-5	DUAL TACHOMETER INDICATOR
206-070-265-7	DUAL TACHOMETER INDICATOR
206-070-265-9	DUAL TACHOMETER INDICATOR
206-070-266-001	TACHOMETER INDICATOR
206-070-266-003	TACHOMETER INDICATOR
206-070-266-005	TACHOMETER INDICATOR
206-070-266-007	TACHOMETER INDICATOR
206-070-266-009	TACHOMETER INDICATOR
206-070-266-011	TACHOMETER INDICATOR
206-070-266-013	TACHOMETER INDICATOR
206-070-266-1	TACHOMETER INDICATOR
206-070-266-11	TACHOMETER INDICATOR
206-070-266-13	TACHOMETER INDICATOR
206-070-266-3	TACHOMETER INDICATOR
206-070-266-5	TACHOMETER INDICATOR
206-070-266-7	TACHOMETER INDICATOR
206-070-266-9	TACHOMETER INDICATOR
206-070-267-001	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-003	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-005	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-007	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-009	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-011	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-013	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-015	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-1	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-11	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-13	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-15	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-3	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-5	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-7	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-267-9	TURBINE OUTLET TEMPERATURE INDICATOR
206-070-268-001	TORQUE INDICATOR
206-070-268-003	TORQUE INDICATOR
206-070-268-005	TORQUE INDICATOR
206-070-268-007	TORQUE INDICATOR
206-070-268-009	TORQUE INDICATOR
206-070-268-011	TORQUE INDICATOR
206-070-268-013	TORQUE INDICATOR
206-070-268-1	TORQUE INDICATOR
206-070-268-11	TORQUE INDICATOR
206-070-268-13	TORQUE INDICATOR
206-070-268-3	TORQUE INDICATOR

206-070-268-5	TORQUE INDICATOR
206-070-268-7	TORQUE INDICATOR
206-070-268-9	TORQUE INDICATOR
206-070-269-009	DUAL INDICATOR
206-070-269-9	DUAL INDICATOR
206-070-274-001	TURN AND SLIP INDICATOR
206-070-274-005	TURN AND SLIP INDICATOR
206-070-274-1	TURN AND SLIP INDICATOR
206-070-274-101	TURN AND SLIP INDICATOR
206-070-274-5	TURN AND SLIP INDICATOR
206-070-275-001	CLOCK
206-070-275-003	CLOCK
206-070-275-005	CLOCK
206-070-275-1	CLOCK
206-070-275-3	CLOCK
206-070-275-5	CLOCK
206-070-278-001	VERTICAL SPEED INDICATOR
206-070-278-005	VERTICAL SPEED INDICATOR
206-070-278-1	VERTICAL SPEED INDICATOR
206-070-278-5	VERTICAL SPEED INDICATOR
206-070-307-1A	OIL TEMPERATURE INDICATOR
206-070-307-2A	OIL PRESSURE INDICATOR
206-070-307-3A	DC AMMETER
206-070-307-4	FUEL QUANTITY INDICATOR
206-070-307-4A	FUEL QUANTITY INDICATOR
206-070-320-003	ATTITUDE GYRO
206-070-320-3	ATTITUDE GYRO
206-070-339-001	TORQUE INDICATOR
206-070-339-1	TORQUE INDICATOR
206-070-351-001	INSTRUMENT CLUSTER
206-070-351-003	INSTRUMENT CLUSTER
206-070-351-1	INSTRUMENT CLUSTER
206-070-351-3	INSTRUMENT CLUSTER
206-070-360-001	TORQUE INDICATOR
206-070-360-1	TORQUE INDICATOR
206-070-399-001	TORQUE INDICATOR
206-070-399-003	TORQUE INDICATOR
206-070-399-1	TORQUE INDICATOR
206-070-399-3	TORQUE INDICATOR
206-070-473-001	INSTRUMENT CLUSTER
206-070-473-003	INSTRUMENT CLUSTER
206-070-473-005	INSTRUMENT CLUSTER
206-070-473-007	INSTRUMENT CLUSTER
206-070-473-1	INSTRUMENT CLUSTER
206-070-473-3	INSTRUMENT CLUSTER
206-070-473-5	INSTRUMENT CLUSTER
206-070-473-7	INSTRUMENT CLUSTER

206-070-475-003	FAN
206-070-475-005	BLOWER ASSEMBLY
206-070-475-3	FAN
206-070-475-5	FAN VANEAXIAL
206-070-988-001	INSTRUMENT CLUSTER
206-070-988-1	INSTRUMENT CLUSTER
206-070-989-001	TORQUE INDICATOR
206-070-989-1	TORQUE INDICATOR
206-070-990-001	VERTICAL SPEED INDICATOR
206-070-990-1	VERTICAL SPEED INDICATOR
206-073-913-001	VANEAXIAL FAN
206-073-913-1	VANEAXIAL FAN
206-074-447-007	VOLTAGE REGULATOR
206-074-447-7	VOLTAGE REGULATOR
206-075-109-005	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-109-5	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-183-003	FUEL PRESSURE AND LOAD INDICATOR
206-075-183-3	FUEL PRESSURE AND LOAD INDICATOR
206-075-185-001	TORQUE INDICATOR
206-075-185-003	TORQUE INDICATOR
206-075-185-005	TORQUE INDICATOR
206-075-185-1	TORQUE INDICATOR
206-075-185-101	TORQUE INDICATOR
206-075-185-103	TORQUE INDICATOR
206-075-185-105	TORQUE INDICATOR
206-075-185-3	TORQUE INDICATOR
206-075-185-5	TORQUE INDICATOR
206-075-186-001	FUEL PRESSURE & LOAD METER
206-075-186-003	FUEL PRESSURE & LOAD METER
206-075-186-005	FUEL PRESSURE & LOAD METER
206-075-186-1	FUEL PRESSURE & LOAD METER
206-075-186-3	FUEL PRESSURE & LOAD METER
206-075-186-5	FUEL PRESSURE & LOAD METER
206-075-187-001	TEMPERATURE & PRESSURE INDICATOR
206-075-187-003	TEMPERATURE & PRESSURE INDICATOR
206-075-187-1	TEMPERATURE & PRESSURE INDICATOR
206-075-187-3	TEMPERATURE & PRESSURE INDICATOR
206-075-188-001	TEMPERATURE & PRESSURE INDICATOR
206-075-188-003	TEMPERATURE & PRESSURE INDICATOR
206-075-188-005	TEMPERATURE & PRESSURE INDICATOR
206-075-188-1	TEMPERATURE & PRESSURE INDICATOR
206-075-188-3	TEMPERATURE & PRESSURE INDICATOR
206-075-188-5	TEMPERATURE & PRESSURE INDICATOR
206-075-189-001	FUEL QUANTITY INDICATOR
206-075-189-003	FUEL QUANTITY INDICATOR
206-075-189-1	FUEL QUANTITY INDICATOR
206-075-189-101	FUEL QUANTITY INDICATOR

206-075-189-3	FUEL QUANTITY INDICATOR
206-075-190-001	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-003	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-005	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-007	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-1	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-3	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-5	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-190-7	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-234-001	PANEL
206-075-234-1	PANEL
206-075-364-005	INVERTER
206-075-364-5	INVERTER
206-075-440-009	PANEL
206-075-440-9	PANEL
206-075-447-001	VOLTAGE REGULATOR
206-075-447-003	VOLTAGE REGULATOR
206-075-447-007	VOLTAGE REGULATOR
206-075-447-1	VOLTAGE REGULATOR
206-075-447-101	VOLTAGE REGULATOR
206-075-447-3	VOLTAGE REGULATOR
206-075-447-7	VOLTAGE REGULATOR
206-075-456-007	ANNUNCIATOR PANEL
206-075-456-101	CAUTION LIGHT ANNUNCIATOR AND CONTROL PANEL
206-075-456-7	ANNUNCIATOR PANEL
206-075-606-101	DIRECTIONAL GYRO
206-075-606-103	DIRECTIONAL GYRO
206-075-606-107	DIRECTIONAL GYRO
206-075-606-109	DIRECTIONAL GYRO
206-075-607-101	GYRO HORIZON
206-075-607-103	GYRO HORIZON
206-075-607-105	GYRO HORIZON
206-075-607-107	GYRO HORIZON
206-075-624-001	THERMOSTAT
206-075-624-1	OAT GAUGE
206-075-675-119	PRESSURE & LOAD METER
206-075-676-001	FUEL PRESS/LOAD METER
206-075-676-003	FUEL PRESSURE/LOAD METER
206-075-676-1	FUEL PRESSURE/LOAD METER
206-075-676-101	FUEL PRESSURE/LOAD METER
206-075-676-103	FUEL PRESSURE/LOAD METER
206-075-676-105	FUEL PRESSURE/LOAD METER
206-075-676-107	FUEL PRESSURE/LOAD METER
206-075-676-109	FUEL PRESSURE/LOAD METER
206-075-676-111	FUEL PRESSURE/LOAD METER
206-075-676-113	FUEL PRESSURE/LOAD METER
206-075-676-115	FUEL PRESSURE/LOAD METER

206-075-676-117	FUEL PRESSURE/LOAD METER
206-075-676-119	FUEL PRESSURE/LOAD METER
206-075-676-3	FUEL PRESSURE/LOAD METER
206-075-677-101	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-677-103	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-677-105	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-678-101	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-678-103	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-678-105	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-678-107	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-680-101	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-680-103	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-680-105	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-680-107	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-681-001	DUAL TACHOMETER INDICATOR
206-075-681-003	DUAL TACHOMETER INDICATOR
206-075-681-013	DUAL TACHOMETER INDICATOR
206-075-681-1	DUAL TACHOMETER INDICATOR
206-075-681-101	DUAL TACHOMETER INDICATOR
206-075-681-103	DUAL TACHOMETER INDICATOR
206-075-681-105	DUAL TACHOMETER INDICATOR
206-075-681-107	DUAL TACHOMETER INDICATOR
206-075-681-109	DUAL TACHOMETER INDICATOR
206-075-681-111	DUAL TACHOMETER INDICATOR
206-075-681-113	DUAL TACHOMETER INDICATOR
206-075-681-115	DUAL TACHOMETER INDICATOR
206-075-681-117	DUAL TACHOMETER INDICATOR
206-075-681-119	DUAL TACHOMETER INDICATOR
206-075-681-121	DUAL TACHOMETER INDICATOR
206-075-681-123	DUAL TACHOMETER INDICATOR
206-075-681-3	DUAL TACHOMETER INDICATOR
206-075-682-001	TACHOMETER INDICATOR
206-075-682-1	TACHOMETER INDICATOR
206-075-682-101	TACHOMETER INDICATOR
206-075-682-103	TACHOMETER INDICATOR
206-075-682-105	TACHOMETER INDICATOR
206-075-682-107	TACHOMETER INDICATOR
206-075-682-109	TACHOMETER INDICATOR
206-075-691-001	PANEL
206-075-691-1	PANEL
206-075-705-001	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-705-1	OIL TEMPERATURE & PRESSURE INDICATOR
206-075-706-001	TRANSMISSION OIL PRESSURE INDICATOR
206-075-706-1	TRANSMISSION OIL PRESSURE INDICATOR
206-075-707-001	FUEL QUANTITY INDICATOR
206-075-707-1	FUEL QUANTITY INDICATOR
206-075-708-001	TURBINE OUTLET TEMPERATURE INDICATOR

206-075-708-1	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-710-001	DC AMMETER
206-075-710-1	DC AMMETER
206-075-711-001	TORQUE INDICATOR
206-075-711-1	TORQUE INDICATOR
206-075-712-001	AIRSPEED INDICATOR
206-075-712-1	AIRSPEED INDICATOR
206-075-713-001	TACHOMETER INDICATOR
206-075-713-003	TACHOMETER INDICATOR
206-075-713-1	TACHOMETER INDICATOR
206-075-713-101	TACHOMETER INDICATOR
206-075-713-3	TACHOMETER INDICATOR
206-075-714-001	GYRO HORIZON
206-075-714-1	GYRO HORIZON
206-075-714-101	GYRO HORIZON
206-075-715-001	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-715-003	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-715-1	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-715-3	TURBINE OUTLET TEMPERATURE INDICATOR
206-075-721-001	PANEL
206-075-721-1	PANEL
206-075-725-001	AIRSPEED INDICATOR
206-075-725-1	AIRSPEED INDICATOR
206-075-725-101	AIRSPEED INDICATOR
206-075-725-103	AIRSPEED INDICATOR
206-075-725-105	AIRSPEED INDICATOR
206-075-725-107	AIRSPEED INDICATOR
206-075-725-109	AIRSPEED INDICATOR
206-075-725-111	AIRSPEED INDICATOR
206-075-739-101	TORQUE INDICATOR
206-075-739-103	TORQUE INDICATOR
206-075-739-105	TORQUE INDICATOR
206-075-739-107	TORQUE INDICATOR
206-075-739-109	TORQUE INDICATOR
206-075-739-111	TORQUE INDICATOR
206-075-739-113	TORQUE INDICATOR
206-075-739-115	TORQUE INDICATOR
206-075-739-117	TORQUE INDICATOR
206-075-739-119	TORQUE INDICATOR
206-075-739-121	TORQUE INDICATOR
206-075-739-123	TORQUE INDICATOR
206-075-739-125	TORQUE INDICATOR
206-075-739-127	TORQUE INDICATOR
206-075-739-129	TORQUE INDICATOR
206-075-739-131	TORQUE INDICATOR
206-075-739-133	TORQUE INDICATOR
206-075-739-135	TORQUE INDICATOR

206-075-739-137	TORQUE INDICATOR
206-075-740-101	FUEL QUANTITY INDICATOR
206-075-740-103	FUEL QUANTITY INDICATOR
206-075-740-105	FUEL QUANTITY INDICATOR
206-075-740-107	FUEL QUANTITY INDICATOR
206-075-740-109	FUEL QUANTITY INDICATOR
206-075-740-111	FUEL QUANTITY INDICATOR
206-075-740-113	FUEL QUANTITY INDICATOR
206-075-740-115	FUEL QUANTITY INDICATOR
206-075-753-107	PANEL
206-075-770-103	PANEL
206-075-770-107	PANEL
206-076-373-001	TACH GENERATOR
206-076-373-1	TACH GENERATOR
206-1A	EXHAUST GAS TEMPERATURE INDICATOR
206-301-052-103	ACTUATOR
206-351-0001	INSTRUMENT CLUSTER
206-364-601-101	FUEL QUANTITY TRANSMITTER
206-373-901-101	VALVE ASSEMBLY
206-373-901-103	SHUT OFF VALVE
206-375-005-101	TEMPERATURE INDICATOR
206-375-005-103	TURBINE OUTLET TEMPERATURE INDICATOR
206-375-006-101	TURBINE OUTLET TEMPERATURE INDICATOR
206-375-007-101	TURBINE OUTLET TEMPERATURE INDICATOR
206-375-007-103	TURBINE OUTLET TEMPERATURE INDICATOR
206-375-009-101	TURBINE OUTLET TEMPERATURE INDICATOR
206-375-011-101	GAS PRODUCER TACHOMETER INDICATOR
206-375-013-101	TORQUE INDICATOR
206-375-051-105	PANEL
206-375-200-103	TACH GENERATOR
206-375-202-101	TACH GENERATOR
206-961-129-011	HANDGRIP
206-961-129-11	HANDGRIP
208-906-001	INTER TURBINE TEMPERATURE INDICATOR
209-001-010-001	HANDGRIP
209-001-010-003	HANDGRIP
209-001-010-1	HANDGRIP
209-001-010-3	HANDGRIP
209-001-059-001	HANDGRIP
209-001-059-1	HANDGRIP
209-062-002-001	DIFFERENTIAL PRESSURE INDICATOR
209-062-002-1	DIFFERENTIAL PRESSURE INDICATOR
209-062-214-001	ELECTROMECHANICAL LINEAR ACTUATOR
209-062-214-1	ELECTROMECHANICAL LINEAR ACTUATOR
209-062-214-101	ELECTROMECHANICAL LINEAR ACTUATOR
209-062-502-101	BLOWER ASSEMBLY
209-062-601-001	MOTOR DRIVEN VALVE

209-062-601-003	MOTOR DRIVEN VALVE
209-062-601-1	MOTOR DRIVEN VALVE
209-062-601-101	MOTOR DRIVEN VALVE
209-062-601-3	MOTOR DRIVEN VALVE
209-062-780-001	LINEAR ACTUATOR
209-062-780-1	LINEAR ACTUATOR
209-062-780-101	LINEAR ACTUATOR
209-064-640-101	MOTOR DRIVEN VALVE
209-070-178-001	AIRSPEED INDICATOR
209-070-178-003	AIRSPEED INDICATOR
209-070-178-1	AIRSPEED INDICATOR
209-070-178-3	AIRSPEED INDICATOR
209-070-243-001	TACHOMETER INDICATOR
209-070-243-003	TACHOMETER INDICATOR
209-070-243-1	TACHOMETER INDICATOR
209-070-243-3	TACHOMETER INDICATOR
209-070-262-001	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-003	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-007	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-009	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-1	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-101	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-103	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-105	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-107	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-109	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-111	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-113	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-115	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-3	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-7	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-262-9	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-263-001	VOLTMETER
209-070-263-003	OIL TEMPERATURE & PRESSURE INDICATOR
209-070-263-007	VOLTMETER
209-070-263-009	VOLTMETER
209-070-263-011	VOLTMETER
209-070-263-1	VOLTMETER
209-070-263-101	VOLTMETER
209-070-263-103	VOLTMETER
209-070-263-11	VOLTMETER
209-070-263-3	DUAL VOLTMETER INDICATOR
209-070-263-7	VOLTMETER
209-070-263-9	VOLTMETER
209-070-264-001	DUAL AMMETER
209-070-264-003	AMMETER
209-070-264-1	DUAL AMMETER

209-070-264-105	DUAL AMMETER
209-070-264-109	DUAL AMMETER
209-070-264-3	AMMETER
209-070-275-001	FUEL PRESSURE INDICATOR
209-070-278-001	ATTITUDE INDICATOR
209-070-278-1	ATTITUDE INDICATOR
209-070-280-005	EMERGENCY FIRE CONTROL SWITCH
209-070-280-007	EMERGENCY FIRE CONTROL SWITCH
209-070-280-101	EMERGENCY FIRE CONTROL SWITCH
209-070-280-103	EMERGENCY FIRE CONTROL SWITCH
209-075-228-001	VOLTAGE REGULATOR
209-075-228-1	VOLTAGE REGULATOR
209-075-325-009	ANNUNCIATOR CAUTION PANEL
209-075-325-011	ANNUNCIATOR CAUTION PANEL
209-075-325-015	ANNUNCIATOR CAUTION PANEL
209-075-325-033	ANNUNCIATOR CAUTION PANEL
209-075-325-045	ANNUNCIATOR CAUTION PANEL
209-075-325-063	ANNUNCIATOR CAUTION PANEL
209-075-325-071	ANNUNCIATOR CAUTION PANEL
209-075-325-101	ANNUNCIATOR CAUTION PANEL
209-075-325-107	ANNUNCIATOR CAUTION PANEL
209-075-325-109	ANNUNCIATOR CAUTION PANEL
209-075-325-11	ANNUNCIATOR CAUTION PANEL
209-075-325-111	ANNUNCIATOR CAUTION PANEL
209-075-325-113	ANNUNCIATOR CAUTION PANEL
209-075-325-145	ANNUNCIATOR CAUTION PANEL
209-075-325-155	ANNUNCIATOR CAUTION PANEL
209-075-325-161	ANNUNCIATOR CAUTION PANEL
209-075-325-165	ANNUNCIATOR CAUTION PANEL
209-075-325-33	ANNUNCIATOR CAUTION PANEL
209-075-325-45	ANNUNCIATOR CAUTION PANEL
209-075-325-63	ANNUNCIATOR CAUTION PANEL
209-075-325-71	ANNUNCIATOR CAUTION PANEL
209-075-325-9	ANNUNCIATOR CAUTION PANEL
209-075-326-001	RPM LIMIT DETECTOR
209-075-326-005	RPM LIMIT DETECTOR
209-075-326-1	RPM LIMIT DETECTOR
209-075-326-101	RPM LIMIT DETECTOR
209-075-326-5	RPM LIMIT DETECTOR
209-075-365-001	GYRO HORIZON
209-075-365-003	GYRO HORIZON
209-075-365-1	GYRO HORIZON
209-075-365-101	GYRO HORIZON
209-075-365-3	GYRO HORIZON
209-075-387-001	POWER SUPPLY
209-075-387-1	POWER SUPPLY
209-075-395-001	FIRE CONTROL UNIT

209-075-395-1	FIRE CONTROL UNIT
209-075-618-001	DUAL TACHOMETER INDICATOR
209-075-618-1	DUAL TACHOMETER INDICATOR
209-075-651-003	GAS TEMPERATURE INDICATOR
209-075-651-3	GAS TEMPERATURE INDICATOR
209-075-652-001	TACHOMETER INDICATOR
209-075-652-003	TACHOMETER INDICATOR
209-075-652-005	TACHOMETER INDICATOR
209-075-652-007	TACHOMETER INDICATOR
209-075-652-009	TACHOMETER INDICATOR
209-075-652-1	TACHOMETER INDICATOR
209-075-652-101	TACHOMETER INDICATOR
209-075-652-103	TACHOMETER INDICATOR
209-075-652-3	TACHOMETER INDICATOR
209-075-652-5	TACHOMETER INDICATOR
209-075-652-7	TACHOMETER INDICATOR
209-075-652-9	TACHOMETER INDICATOR
209-075-653-007	TORQUE INDICATOR
209-075-653-7	TORQUE INDICATOR
209-075-654-005	TORQUE INDICATOR
209-075-654-101	TORQUE INDICATOR
209-075-654-5	TORQUE INDICATOR
209-075-655-001	DUAL TACHOMETER INDICATOR
209-075-655-003	DUAL TACHOMETER INDICATOR
209-075-655-005	DUAL TACHOMETER INDICATOR
209-075-655-1	DUAL TACHOMETER INDICATOR
209-075-655-101	DUAL TACHOMETER INDICATOR
209-075-655-103	DUAL TACHOMETER INDICATOR
209-075-655-3	DUAL TACHOMETER INDICATOR
209-075-655-5	DUAL TACHOMETER INDICATOR
209-075-656-001	TEMPERATURE & PRESSURE INDICATOR
209-075-656-1	TEMPERATURE & PRESSURE INDICATOR
209-075-657-101	TORQUE INDICATOR
209-075-658-001	TEMPERATURE & PRESSURE INDICATOR
209-075-658-1	TEMPERATURE & PRESSURE INDICATOR
209-075-659-003	VOLTMETER
209-075-659-103	VOLTMETER
209-075-659-3	VOLTMETER
209-075-663-001	VERTICAL SPEED INDICATOR
209-075-663-1	VERTICAL SPEED INDICATOR
209-075-665-001	AIRSPEED INDICATOR
209-075-665-1	INDICATOR
209-075-666-003	ATTITUDE INDICATOR
209-075-666-3	ATTITUDE INDICATOR
209-075-722-001	TRIPLE TACHOMETER INDICATOR
209-075-722-003	TRIPLE TACHOMETER INDICATOR
209-075-722-1	TRIPLE TACHOMETER INDICATOR

209-075-722-101	TRIPLE TACHOMETER INDICATOR
209-075-722-3	TRIPLE TACHOMETER INDICATOR
209-075-766-001	PANEL
209-075-766-1	PANEL
209-175-308-001	POWER SUPPLY
209-175-308-1	POWER SUPPLY
209-175-334-001	PANEL
209-175-334-1	PANEL
209-373-001-101	MOTOR DRIVEN VALVE
209-375-006-101	TURBINE OUTLET TEMPERATURE INDICATOR
209-375-007-101	TURBINE OUTLET TEMPERATURE INDICATOR
209-375-007-103	TURBINE OUTLET TEMPERATURE INDICATOR
209-375-009-101	TURBINE OUTLET TEMPERATURE INDICATOR
209-375-022-101	OIL TEMPERATURE & PRESSURE INDICATOR
209-375-028-101	PANEL
209-375-045-101	AIRSPEED INDICATOR
209-375-047-101	TRIPLE TACHOMETER INDICATOR
209-375-049-101	PANEL
209-375-054-115	PANEL
209-375-057-101	PANEL
209-375-061-103	PANEL
2100904-1	BLOWER MOTOR
210-095-00	LOAD INDICATOR
210-1A	EXHAUST GAS TEMPERATURE INDICATOR
210-5A	DIRECTIONAL GYRO
21140-1134-2	AIRSPEED INDICATOR
21140-1150	AIRSPEED INDICATOR
211C223-471	PRESSURE SWITCH
212-040-122-101	CHIP DETECTOR
212-040-122-103	CHIP DETECTOR
212-040-184-001	OIL PUMP
212-045-067-119	INTER TURBINE TEMPERATURE INDICATOR
212-061-614-001	MOTOR DRIVEN VALVE
212-061-614-1	MOTOR DRIVEN VALVE
212-070-108-003	TRIPLE TACHOMETER INDICATOR
212-070-108-005	TRIPLE TACHOMETER INDICATOR
212-070-108-007	TRIPLE TACHOMETER INDICATOR
212-070-108-009	TRIPLE TACHOMETER INDICATOR
212-070-108-011	TRIPLE TACHOMETER INDICATOR
212-070-108-101	TRIPLE TACHOMETER INDICATOR
212-070-108-103	TRIPLE TACHOMETER INDICATOR
212-070-108-107	TRIPLE TACHOMETER INDICATOR
212-070-108-11	TRIPLE TACHOMETER INDICATOR
212-070-108-3	TRIPLE TACHOMETER INDICATOR
212-070-108-5	TRIPLE TACHOMETER INDICATOR
212-070-108-7	TRIPLE TACHOMETER INDICATOR
212-070-108-9	TRIPLE TACHOMETER INDICATOR

212-070-116-001	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-003	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-005	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-007	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-009	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-011	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-013	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-015	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-017	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-019	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-021	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-023	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-025	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-1	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-101	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-103	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-105	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-107	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-11	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-13	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-15	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-17	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-19	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-21	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-23	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-25	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-3	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-5	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-7	OIL TEMPERATURE & PRESSURE INDICATOR
212-070-116-9	TEMPERATURE & PRESSURE INDICATOR
212-070-122	AIRSPEED INDICATOR
212-070-122-001	AIRSPEED INDICATOR
212-070-122-003	AIRSPEED INDICATOR
212-070-122-005	AIRSPEED INDICATOR
212-070-122-009	AIRSPEED INDICATOR
212-070-122-011	AIRSPEED INDICATOR
212-070-122-013	AIRSPEED INDICATOR
212-070-122-015	AIRSPEED INDICATOR
212-070-122-017	AIRSPEED INDICATOR
212-070-122-019	AIRSPEED INDICATOR
212-070-122-021	AIRSPEED INDICATOR
212-070-122-1	AIRSPEED INDICATOR
212-070-122-101	AIRSPEED INDICATOR
212-070-122-105	AIRSPEED INDICATOR
212-070-122-11	AIRSPEED INDICATOR
212-070-122-13	AIRSPEED INDICATOR
212-070-122-15	AIRSPEED INDICATOR

212-070-122-17	AIRSPEED INDICATOR
212-070-122-19	AIRSPEED INDICATOR
212-070-122-21	AIRSPEED INDICATOR
212-070-122-3	AIRSPEED INDICATOR
212-070-122-5	AIRSPEED INDICATOR
212-070-122-9	AIRSPEED INDICATOR
212-070-129-009	PANEL
212-070-160-001	DUAL TORQUE INDICATOR
212-070-160-003	DUAL TORQUE INDICATOR
212-070-160-005	DUAL TORQUE INDICATOR
212-070-160-007	DUAL TORQUE INDICATOR
212-070-160-011	DUAL TORQUE INDICATOR
212-070-160-015	DUAL TORQUE INDICATOR
212-070-160-017	DUAL TORQUE INDICATOR
212-070-160-1	DUAL TORQUE INDICATOR
212-070-160-101	DUAL TORQUE INDICATOR
212-070-160-103	DUAL TORQUE INDICATOR
212-070-160-105	DUAL TORQUE INDICATOR
212-070-160-107	DUAL TORQUE INDICATOR
212-070-160-109	DUAL TORQUE INDICATOR
212-070-160-11	DUAL TORQUE INDICATOR
212-070-160-111	DUAL TORQUE INDICATOR
212-070-160-113	DUAL TORQUE INDICATOR
212-070-160-115	DUAL TORQUE INDICATOR
212-070-160-117	DUAL TORQUE INDICATOR
212-070-160-119	DUAL TORQUE INDICATOR
212-070-160-121	DUAL TORQUE INDICATOR
212-070-160-123	DUAL TORQUE INDICATOR
212-070-160-125	DUAL TORQUE INDICATOR
212-070-160-127	DUAL TORQUE INDICATOR
212-070-160-129	DUAL TORQUE INDICATOR
212-070-160-131	DUAL TORQUE INDICATOR
212-070-160-15	DUAL TORQUE INDICATOR
212-070-160-17	DUAL TORQUE INDICATOR
212-070-160-21	DUAL TORQUE INDICATOR
212-070-160-3	DUAL TORQUE INDICATOR
212-070-160-5	DUAL TORQUE INDICATOR
212-070-160-7	DUAL TORQUE INDICATOR
212-070-176-003	PANEL
212-070-176-3	PANEL
212-070-180-001	COURSE INDICATOR
212-070-180-003	COURSE INDICATOR
212-070-180-1	COURSE INDICATOR
212-070-180-3	COURSE INDICATOR
212-070-182-001	HYDRAULIC PRESSURE INDICATOR
212-070-182-1	HYDRAULIC PRESSURE INDICATOR
212-070-183-003	PANEL

212-070-238-001	ALTIMETER
212-070-238-003	ALTIMETER
212-070-238-005	ALTIMETER
212-070-238-007	ALTIMETER
212-070-238-1	ALTIMETER
212-070-238-103	ALTIMETER
212-070-238-3	ALTIMETER
212-070-238-5	ALTIMETER
212-070-238-7	ALTIMETER
212-070-239-001	VERTICAL SPEED INDICATOR
212-070-239-003	VERTICAL SPEED INDICATOR
212-070-239-1	VERTICAL SPEED INDICATOR
212-070-239-101	VERTICAL SPEED INDICATOR
212-070-239-103	VERTICAL SPEED INDICATOR
212-070-239-3	VERTICAL SPEED INDICATOR
212-070-240-001	TEMPERATURE INDICATOR
212-070-240-1	TEMPERATURE INDICATOR
212-070-241-001	TEMPERATURE INDICATOR
212-070-241-1	TEMPERATURE INDICATOR
212-070-242-001	TACHOMETER INDICATOR
212-070-242-003	TACHOMETER INDICATOR
212-070-242-005	TACHOMETER INDICATOR
212-070-242-007	TACHOMETER INDICATOR
212-070-242-009	TACHOMETER INDICATOR
212-070-242-011	TACHOMETER INDICATOR
212-070-242-1	TACHOMETER INDICATOR
212-070-242-101	TACHOMETER INDICATOR
212-070-242-11	TACHOMETER INDICATOR
212-070-242-3	TACHOMETER INDICATOR
212-070-242-5	TACHOMETER INDICATOR
212-070-242-7	TACHOMETER INDICATOR
212-070-242-9	TACHOMETER INDICATOR
212-070-444-001	SENSOR
212-070-714-001	ATTITUDE GYRO
212-070-714-1	ATTITUDE GYRO
212-073-927-001	POSITIONING MOTOR
212-073-927-003	SERVO CONTROL
212-073-927-1	POSITIONING MOTOR
212-073-927-3	SERVO CONTROL
212-075-036-101	TEMPERATURE & PRESSURE INDICATOR
212-075-036-103	OIL TEMPERATURE & PRESSURE INDICATOR
212-075-036-105	OIL TEMPERATURE & PRESSURE INDICATOR
212-075-036-107	OIL TEMPERATURE & PRESSURE INDICATOR
212-075-036-109	OIL TEMPERATURE & PRESSURE INDICAT0R
212-075-037-101	TACHOMETER INDICATOR
212-075-037-103	TACHOMETER INDICATOR
212-075-037-105	TACHOMETER INDICATOR

212-075-037-107	TACHOMETER INDICATOR
212-075-037-109	GAS PRODUCER TACHOMETER INDICATOR
212-075-037-111	TACHOMETER INDICATOR
212-075-037-113	TACHOMETER INDICATOR
212-075-037-115	TACHOMETER INDICATOR
212-075-037-117	TACHOMETER INDICATOR
212-075-037-119	TACHOMETER INDICATOR
212-075-067-101	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-103	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-105	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-107	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-109	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-111	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-113	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-115	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-117	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-119	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-121	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-123	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-125	INTER TURBINE TEMPERATURE INDICATOR
212-075-067-127	INTER TURBINE TEMPERATURE INDICATOR
212-075-087-123	INTER TURBINE TEMPERATURE INDICATOR
212-075-139-001	LANDING LIGHT
212-075-139-1	LANDING LIGHT
212-075-168-003	PANEL
212-075-168-3	PANEL
212-075-199-001	START RELAY
212-075-199-1	START RELAY
212-075-216-001	PANEL
212-075-216-1	PANEL
212-075-222-003	PANEL
212-075-222-3	PANEL
212-075-237-001	PHASE ADAPTER
212-075-237-1	PHASE ADAPTER
212-075-238-5	ALTIMETER
212-075-359-001	PANEL
212-075-359-1	PANEL
212-075-371-001	HYDRAULIC CONTROL PANEL
212-075-371-1	HYDRAULIC CONTROL PANEL
212-075-372-001	PANEL
212-075-372-1	PANEL
212-075-387-001	PANEL
212-075-387-1	PANEL
212-075-387-101	PANEL
212-075-391-101	PANEL
212-075-391-105	PANEL
212-075-394-003	PANEL

212-075-394-3	PANEL
212-075-396-005	PANEL
212-075-396-5	PANEL
212-075-399-001	PANEL
212-075-407-001	PANEL
212-075-407-1	PANEL
212-075-413-001	PANEL
212-075-413-1	PANEL
212-075-418-001	ACTUATOR
212-075-418-003	ACTUATOR
212-075-418-1	ACTUATOR
212-075-418-101	ACTUATOR
212-075-418-103	ACTUATOR
212-075-418-105	ACTUATOR
212-075-418-107	ACTUATOR
212-075-418-3	ACTUATOR
212-075-420-001	INTER TURBINE TEMPERATURE INDICATOR
212-075-420-003	INTER TURBINE TEMPERATURE INDICATOR
212-075-420-1	INTER TURBINE TEMPERATURE INDICATOR
212-075-420-3	INTER TURBINE TEMPERATURE INDICATOR
212-075-458-001	PANEL
212-075-458-1	PANEL
212-075-459-001	PANEL
212-075-459-1	PANEL
212-075-461-001	PANEL
212-075-461-1	PANEL
212-075-509-003	PANEL
212-075-509-3	PANEL
212-075-510-003	PANEL
212-075-510-3	PANEL
212-075-514-001	CLOCK
212-075-514-1	CLOCK
212-075-514-101	CLOCK
212-075-562-001	INTER TURBINE TEMPERATURE INDICATOR
212-075-562-003	INTER TURBINE TEMPERATURE INDICATOR
212-075-562-3	INTER TURBINE TEMPERATURE INDICATOR
212-075-782-001	RELAY
212-075-782-1	RELAY
212-075-962-001	LIGHT DIMMER
212-075-962-1	LIGHT DIMMER
212-076-008-001	VALVE ASSEMBLY
212-076-015-001	CHECK VALVE
212-076-015-1	CHECK VALVE
212-077-163-001	COMPASS CONTROL PANEL
212-077-163-1	COMPASS CONTROL PANEL
212-077-163-101	COMPASS CONTROL PANEL
212-077-163-103	COMPASS CONTROL PANEL

212-077-165-001	PANEL
212-077-165-1	PANEL
212-077-167-001	NAV CONTROL
212-077-169-001	PANEL
212-077-169-1	PANEL
212-077-200-001	COMMUNICATION CONTROL
212-077-200-003	COMMUNICATION CONTROL
212-077-200-1	CONTROL COMMUNICATION
212-077-200-101	CONTROL COMMUNICATION
212-077-200-105	COMMUNICATION CONTROL
212-077-200-3	COMMUNICATION CONTROL
212-175-278-101	ALTIMETER
21225-9	GRIP ASSEMBLY
212-374-003-101	ACCLEROMETER
212-830-018-001	EGT INDICATOR
212-830-019-001	DUAL TORQUE INDICATOR
212-830-019-003	DUAL TORQUE INDICATOR
212-830-019-1	DUAL TORQUE INDICATOR
212-830-019-3	DUAL TORQUE INDICATOR
212-899-245-001	FUEL QUANTITY INDICATOR
212-899-245-1	FUEL QUANTITY INDICATOR
212-899-268-147	PANEL, EDGE LIT
212-899-473-105	PANEL
214-001-346-001	HANDGRIP
214-001-346-002	HANDGRIP
214-001-346-003	HANDGRIP
214-001-346-007	HANDGRIP
214-001-346-1	HANDGRIP
214-001-346-101	HANDGRIP
214-001-346-103	HANDGRIP
214-001-346-105	HANDGRIP
214-001-346-2	HANDGRIP
214-001-346-3	HANDGRIP
214-001-346-7	HANDGRIP
214-001-347-001	ACTUATOR
214-001-347-005	ACTUATOR
214-001-347-007	ACTUATOR
214-001-347-1	ACTUATOR
214-001-347-101	ACTUATOR
214-001-347-103	ACTUATOR
214-001-347-105	ACTUATOR
214-001-347-107	ACTUATOR
214-001-347-109	ACTUATOR
214-001-347-5	ROTARY ACTUATOR
214-001-347-7	ACTUATOR
214-001-370-101	SERVOMOTOR
214-001-370-103	SERVOMOTOR

214-001-423-109	STEP ACTUATOR
214-001-550-105	SERVO MOTOR
214-001-970-111	ACTUATOR
214-040-805-001	THERMO SWITCH
214-040-865-101	FAN PERFORMANCE MONITOR
214-060-056-001	STARTER
214-060-056-1	STARTER
214-060-056-103	STARTER
214-060-056-107	DC STARTER
214-060-056-109	STARTER
214-066-030-005	FUEL QUANTITY INDICATOR
214-066-030-007	FUEL QUANTITY INDICATOR
214-066-030-5	FUEL QUANTITY INDICATOR
214-066-030-7	FUEL QUANTITY INDICATOR
214-066-212-101	FUEL PROBE
214-066-212-103	FUEL PROBE
214-066-212-105	FUEL PROBE
214-066-212-111	FUEL PROBE
214-066-213-103	FUEL SIGNAL CONDITIONER
214-066-226-103	FLOW SWITCH
214-070-567-101	PANEL
214-070-567-102	PANEL
214-070-568-101	PANEL
214-070-568-118	PANEL
214-073-902-011	MOTOR CONVERTER ASSEMBLY LH WINDSHIELD WIPER
214-073-902-012	MOTOR CONVERTER ASSEMBLY RH WINDSHIELD WIPER
214-073-912-001	FAN PERFORMANCE MONITOR
214-074-104-101	DUAL RATE SENSOR
214-074-108-101	DUAL ELEMENT TRANSDUCER
214-074-149-101	TRANSDUCER
214-074-152-101	AIRSPEED TRANSDUCER
214-074-153-101	TRANSDUCER - SINGLE ELEMENT
214-074-200-105	CHIP INDICATOR
214-074-280-107	DETECTOR RPM
214-074-300-101	AFCS ANNUNCIATOR PANEL
214-074-300-105	AFCS ANNUNCIATOR PANEL
214-074-305-105	AMPLIFIER
214-075-100-015	CAUTION PANEL
214-075-139-001	LANDING LIGHT
214-075-139-1	LANDING LIGHT
214-075-150-001	RELAY
214-075-150-1	RELAY
214-075-186-001	TEMPERATURE CONTROLLER
214-075-186-1	TEMPERATURE CONTROLLER
214-075-187-001	VOLTAGE REGULATOR
214-075-187-003	VOLTAGE REGULATOR
214-075-187-1	VOLTAGE REGULATOR

214-075-187-3	VOLTAGE REGULATOR
214-075-215-001	TEMPERATURE INDICATOR
214-075-219-005	EGT INDICATOR
214-075-219-5	EGT INDICATOR
214-075-220-001	COURSE INDICATOR
214-075-220-1	COURSE INDICATOR
214-075-221-001	DUAL TACHOMETER INDICATOR
214-075-221-003	DUAL TACHOMETER INDICATOR
214-075-221-1	DUAL TACHOMETER INDICATOR
214-075-221-3	DUAL TACHOMETER INDICATOR
214-075-222-005	TEMPERATURE & PRESSURE INDICATOR
214-075-222-5	TEMPERATURE & PRESSURE INDICATOR
214-075-231-005	COURSE DEVIATION INDICATOR
214-075-231-007	COURSE DEVIATION INDICATOR
214-075-231-5	COURSE DEVIATION INDICATOR
214-075-234-003	POWER SUPPLY
214-075-234-3	POWER SUPPLY
214-075-239-011	TORQUE INDICATOR
214-075-239-11	TORQUE INDICATOR
214-075-242-001	TACHOMETER INDICATOR
214-075-242-003	TACHOMETER INDICATOR
214-075-242-005	TACHOMETER INDICATOR
214-075-242-1	TACHOMETER INDICATOR
214-075-242-3	TACHOMETER INDICATOR
214-075-242-5	TACHOMETER INDICATOR
214-075-243-003	ATTITUDE INDICATOR
214-075-243-3	ATTITUDE INDICATOR
214-075-244-001	RATE GYRO
214-075-244-1	RATE GYRO
214-075-244-101	RATE GYRO
214-075-244-103	RATE GYRO
214-075-252-001	AMMETER
214-075-252-1	AMMETER
214-075-253-001	FUEL PRESSURE INDICATOR
214-075-253-1	FUEL PRESSURE INDICATOR
214-075-261-001	EGT INDICATOR
214-075-261-1	EGT INDICATOR
214-075-261-101	INDICATOR
214-075-268-101	STANDBY ATTITUDE INDICATOR
214-075-268-102	STANDBY ATTITUDE INDICATOR
214-075-302-011	TEMPERATURE & PRESSURE INDICATOR
214-075-302-11	TEMPERATURE & PRESSURE INDICATOR
214-075-316-001	STANDBY COMPASS
214-075-332-003	FUEL QUANTITY INDICATOR
214-075-456-001	ANTI-COLLISION LIGHT
214-075-456-003	ANTI-COLLISION LIGHT
214-076-016-001	HYDRAULIC PRESSURE TRANSMITTER

214-076-016-1	FUEL QUANTITY INDICATOR
214-175-104-101	STATIC INVERTER
214-175-122-105	FAULT FUNCTION PANEL
214-175-122-107	PANEL, FAULT-FUNCTION
214-175-122-111	PANEL, FAULT-FUNCTION INDICATOR-CAUTION ADVISORY
214-175-122-113	MASTER CAUTION PANEL
214-175-122-115	MASTER CAUTION PANEL
214-175-122-117	MASTER CAUTION PANEL
214-175-122-119	MASTER CAUTION PANEL
214-175-122-121	MASTER CAUTION PANEL
214-175-122-123	MASTER CAUTION PANEL
214-175-122-125	MASTER CAUTION PANEL
214-175-122-127	MASTER CAUTION PANEL
214-175-122-131	MASTER CAUTION PANEL
214-175-122-133	MASTER CAUTION PANEL
214-175-126-101	LIGHT
214-175-126-103	ANTI-COLLISION LIGHT
214-175-127-103	POWER SUPPLY
214-175-140-101	RECHARGEABLE BATTERY POWER SUPPLY
214-175-140-103	RECHARGEABLE BATTERY POWER SUPPLY
214-175-143-101	NAV/AFCS PANEL
214-175-144-101	RELAY
214-175-145-103	ANNUNCIATOR PANEL
214-175-150-105	DC GENERATOR
214-175-150-107	GENERATOR
214-175-153-103	VOLTAGE REGULATOR
214-175-153-105	VOLTAGE REGULATOR
214-175-153-107	VOLTAGE REGULATOR
214-175-155-103	RELAY
214-175-167-103	MASTER CAUTION PANEL
214-175-173-101	TEMPERATURE CONTROL PANEL
214-175-241-101	DISPLACEMENT GYRO
214-175-248-103	GAS TEMPERATURE INDICATOR
214-175-248-105	GAS TEMPERATURE INDICATOR
214-175-248-107	GAS TEMPERATURE INDICATOR
214-175-248-109	GAS TEMPERATURE INDICATOR
214-175-248-111	GAS TEMPERATURE INDICATOR
214-175-249-101	TURBINE OUTLET TEMPERATURE INDICATOR
214-175-249-103	GAS PRODUCER TACHOMETER INDICATOR
214-175-249-105	GAS PRODUCER TACHOMETER INDICATOR
214-175-249-107	GAS PRODUCER TACHOMETER INDICATOR
214-175-249-109	GAS PRODUCER TACHOMETER INDICATOR
214-175-250-101	DUAL TORQUE INDICATOR
214-175-250-103	DUAL TORQUE INDICATOR
214-175-250-105	DUAL TORQUE INDICATOR
214-175-251-101	TRIPLE TACHOMETER INDICATOR
214-175-251-103	TRIPLE TACHOMETER INDICATOR

214-175-251-105	TRIPLE TACHOMETER INDICATOR
214-175-251-107	TRIPLE TACHOMETER INDICATOR
214-175-251-109	TRIPLE TACHOMETER INDICATOR
214-175-251-111	TRIPLE TACHOMETER INDICATOR
214-175-251-111FM	TRIPLE TACHOMETER INDICATOR
214-175-252-101	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-253-103	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-253-105	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-254-101	DUAL AMMETER
214-175-254-103	DUAL AMMETER
214-175-254-105	DUAL AMMETER INDICATOR
214-175-254-107	DUAL AMMETER
214-175-255-101	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-255-103	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-256-101	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-256-103	GEARBOX OIL TEMPERATURE & PRESSURE INDICATOR
214-175-256-105	HYDRAULIC TEMPERATURE & PRESSURE INDICATOR
214-175-257-101	FUEL QUANTITY INDICATOR
214-175-257-103	FUEL QUANTITY INDICATOR
214-175-257-105	FUEL QUANTITY INDICATOR
214-175-257-107	FUEL QUANTITY INDICATOR
214-175-257-109	FUEL QUANTITY INDICATOR
214-175-258-101	VOLTMETER
214-175-258-103	VOLTMETER
214-175-258-105	DC VOLTMETER
214-175-258-107	VOLTMETER
214-175-259-101	ELEVATOR POSITION INDICATOR
214-175-259-103	ELEVATOR POSITION INDICATOR
214-175-271-103	AIRSPEED INDICATOR
214-175-271-105	AIRSPEED INDICATOR
214-175-271-107	AIRSPEED INDICATOR
214-175-276-101	PANEL
214-175-278-101	ALTIMETER
214-175-278-103	ALTIMETER
214-175-299-101	AIRSPEED INDICATOR
214-175-299-103	AIRSPEED INDICATOR
214-175-299-105	AIRSPEED INDICATOR
214-175-299-107	AIRSPEED INDICATOR
214-175-299-107 FM	AIRSPEED INDICATOR
214-175-352-101	PANEL
214-175-382-101	PANEL
214-175-384-103	PANEL ASSEMBLY ENGINE GOVONOR
214-175-384-105	PANEL ASSEMBLY
214-175-421-101	AIR DATA COMPUTER
214-375-214-103	MGT INDICATOR
214-899-811-101	PANEL
21562/475-1	VOLTAGE REGULATOR

217-00141	OIL PRESSURE INDICATOR
217-01161	TORQUE PRESSURE INDICATOR
217-02111	FUEL PRESSURE INDICATOR
217-08151	OIL PRESSURE INDICATOR
217-21242	OIL PRESSURE INDICATOR
217A100	OIL PRESSURE INDICATOR
217A100A	OIL PRESSURE INDICATOR
21885-4	GRIP ASSEMBLY
2200-3	ENGINE POWER WARNING UNIT
22-111-02	TORQUE INDICATOR
22-169-018LBW5	INSTRUMENT CLUSTER
222-005-030-101	RPM LIMIIT DETECTOR
222-005-030-103	RPM SENSOR
222-005-030-107	RPM LIMIIT DETECTOR
222-005-030-111	RPM LIMIT DETECTOR
222-066-708-101	FUEL PUMP
222-075-139-101	LANDING GEAR CONTROL PANEL
222-075-139-103	LANDING GEAR CONTROL PANEL
222-075-139-105	LANDING GEAR CONTROL PANEL
222-075-139-109	LANDING GEAR CONTROL PANEL
222-075-139-111	LANDING GEAR CONTROL PANEL
222-305-003-101	FLIGHT DIRECTOR MODE SELECTOR
222-305-005-101	ALTITUDE SENSOR
222-305-006-101	AIRSPEED SENSOR
222-365-509-101	OIL MONITOR
222-366-615-101	MOTOR DRIVEN VALVE
222-366-680-103	MOTOR DRIVEN VALVE
222-366-680-105	MOTOR DRIVEN VALVE
222-366-680-107	MOTOR DRIVEN VALVE
222-366-681-103	FUEL PUMP
222-366-683-103	PROBE, UPPER
222-366-684-103	PROBE, LOWER
222-366-685-101	FUEL SIGNAL CONDITIONER
222-370-086-101	PANEL
222-375-007-101	FIRE CONTROL PANEL
222-375-010-003	ANNUCIATOR PANEL
222-375-010-043	ANNUCIATOR PANEL
222-375-010-103	ANNUCIATOR PANEL
222-375-010-107	ANNUCIATOR PANEL
222-375-010-115	AFCS CAUTION INDICATOR
222-375-010-117	ANNUNCIATOR PANEL
222-375-010-119	ANNUNCIATOR PANEL
222-375-010-131	ANNUNCIATOR PANEL
222-375-010-139	ANNUNCIATOR PANEL
222-375-010-151FM	ANNUNCIATOR PANEL
222-375-010-153	ANNUNCIATOR PANEL
222-375-010-153FM	ANNUNCIATOR PANEL

222-375-010-163	LIGHT ASSEMBLY
222-375-010-165	LIGHT ASSEMBLY
222-375-012-101	LIGHT DIMMER
222-375-016-101	OIL TEMPERATURE & PRESSURE INDICATOR
222-375-017-101	OIL TEMPERATURE & PRESSURE INDICATOR
222-375-018-101	OIL TEMPERATURE & PRESSURE INDICATOR
222-375-018-103	OIL TEMPERATURE & PRESSURE INDICATOR
222-375-018-105	OIL TEMPERATURE & PRESSURE INDICATOR
222-375-018-109	OIL TEMPERATURE & PRESSURE INDICATOR
222-375-019-005	OIL PRESSURE TRANSMITTER
222-375-019-009	PRESSURE TRANSDUCER
222-375-019-013	PRESSURE TRANSMITTER
222-375-019-105	PRESSURE TRANSMITTER
222-375-020-003	TACHOMETER INDICATOR
222-375-020-005	TACHOMETER INDICATOR
222-375-020-103	TRIPLE TORQUE INDICATOR
222-375-020-105	TRIPLE TORQUE INDICATOR
222-375-020-3	TACHOMETER INDICATOR
222-375-020-5	TACHOMETER INDICATOR
222-375-021-101	TRIPLE TACHOMETER INDICATOR
222-375-021-103	TRIPLE TACHOMETER INDICATOR
222-375-021-105	TRIPLE TACHOMETER INDICATOR
222-375-021-109	TACHOMETER INDICATOR
222-375-021-111	TRIPLE TACHOMETER INDICATOR
222-375-021-113	TRIPLE TACHOMETER INDICATOR
222-375-022-101	GAS PRODUCER TACHOMETER INDICATOR
222-375-022-103	GAS PRODUCER TACHOMETER INDICATOR
222-375-022-105	GAS PRODUCER TACHOMETER INDICATOR
222-375-022-109	GAS PRODUCER TACHOMETER INDICATOR
222-375-022-111	GAS PRODUCER TACHOMETER INDICATOR
222-375-023-103	TEMPERATURE INDICATOR
222-375-023-105	TEMPERATURE INDICATOR
222-375-023-107	MGT INDICATOR
222-375-023-111	MGT INDICATOR
222-375-024-101	DUAL FUEL QUANTITY INDICATOR
222-375-025-101	DUAL AMMETER
222-375-025-103	DUAL AMMETER
222-375-025-105	DUAL AMMETER
222-375-025-107	DUAL AMMETER
222-375-025-109	DUAL AMMETER
222-375-025-111	DUAL AMMETER
222-375-027-101	AIRSPEED INDICATOR
222-375-027-105	AIRSPEED INDICATOR
222-375-027-107	AIRSPEED INDICATOR
222-375-027-109	AIRSPEED INDICATOR
222-375-027-111	AIRSPEED INDICATOR
222-375-027-113	AIRSPEED INDICATOR

222-375-027-115	AIRSPEED INDICATOR
222-375-027-117	AIRSPEED INDICATOR
222-375-027-119	AIRSPEED INDICATOR
222-375-028-101	TURN AND BANK INDICATOR
222-375-030-001	VERTICAL SPEED INDICATOR
222-375-030-1	VERTICAL SPEED INDICATOR
222-375-033-101	GYRO HORIZON
222-375-033-103	ATTITUDE GYRO
222-375-033-107	GYRO HORIZON
222-375-034-101	DIRECTIONAL GYRO
222-375-038-101	FUEL FLOW INDICATOR
222-375-041-001	HORIZONTAL SITUATION INDICATOR
222-375-041-1	HORIZONTAL SITUATION INDICATOR
222-375-048-105	PANEL
222-375-060-103	DC GENERATOR CONTOL UNIT
222-375-060-105	DC GENERATOR CONTOL UNIT
222-375-060-109	VOLTAGE REGULATOR
222-375-060-111	VOLTAGE REGULATOR
222-375-060-113	VOLTAGE REGULATOR
222-375-060-115	VOLTAGE REGULATOR
222-375-060-119	VOLTAGE REGULATOR
222-375-064-101	DUAL FUEL QUANTITY INDICATOR
222-375-064-103	FUEL QUANTITY INDICATOR
222-375-064-105	FUEL QUANTITY INDICATOR
222-375-064-107	FUEL QUANTITY INDICATOR
222-375-067-101	RPM LIMIT DETECTOR
222-375-071-101	TRIPLE TORQUE INDICATOR
222-375-071-103	TRIPLE TORQUE INDICATOR
222-375-071-105	TRIPLE TORQUE INDICATOR
222-375-071-107	TRIPLE TORQUE INDICATOR
222-375-071-109	TRIPLE TORQUE INDICATOR
222-375-072-101	TURN AND SLIP INDICATOR
222-375-072-105	TURN AND SLIP INDICATOR
222-375-074-101	PANEL
222-375-077-011	OIL PRESSURE TRANSMITTER
222-375-077-103	PRESSURE TRANSMITTER
222-375-077-105	PRESSURE TRANSMITTER
222-375-077-107	ENGINE OIL TRANSMITTER
222-375-077-109	PRESSURE TRANSMITTER
222-375-077-11	OIL PRESSURE TRANSMITTER
222-375-077-111	PRESSURE TRANSDUCER
222-375-077-113	PRESSURE TRANSMITTER
222-375-077-115	PRESSURE TRANSMITTER
222-375-077-117	OIL PRESSURE TRANSMITTER
222-375-077-119	PRESSURE SWITCH
222-375-077-125	TRANSMITTER
222-375-115-101	PANEL

222-375-562-001	ATTITUDE DIRECTOR INDICATOR
222-375-562-101	ATTITUDE DIRECTOR INDICATOR
22-279-02A	N1 GAS PRODUCER INDICATOR
22-279-02B	N1 GAS PRODUCER INDICATOR
22-279-02C	N1 GAS PRODUCER INDICATOR
22-279-06	TACHOMETER INDICATOR
22-280	TACHOMETER INDICATOR
22-281	TACHOMETER INDICATOR
22-284	DUAL TACHOMETER INDICATOR
22-285	DUAL TACHOMETER INDICATOR
22-285-01	DUAL TACHOMETER INDICATOR
22-285-01-1A	DUAL TACHOMETER INDICATOR
22-285-03	DUAL TACHOMETER INDICATOR
22-285-03-1	DUAL TACHOMETER INDICATOR
22-285-03-2	DUAL TACHOMETER INDICATOR
22-285-04	DUAL TACHOMETER INDICATOR
22-304-04	TURBINE OUTLET TEMPERATURE INDICATOR
22-304-4	TURBINE OUTLET TEMPERATURE INDICATOR
22322SET12	CLOCK
22-373-01-1A	ALTIMETER
22-374B01	ALTIMETER
22-374B-01	ALTIMETER
22-374-B01-2	ALTIMETER
22-375-012-103	POWER SUPPLY
2260-1001-1	RPM LIMIT DETECTOR
22-697-05-1	AIRSPEED INDICATOR
22-697-06-1	AIRSPEED INDICATOR
22702-501	ENCODING ALTIMETER
22702-502	ENCODING ALTIMETER
22702-503	ENCODING ALTIMETER
22702-511	ENCODING ALTIMETER
22702-513	ENCODING ALTIMETER
22702-531	ENCODING ALTIMETER
22702-532	ENCODING ALTIMETER
22702-533	ENCODING ALTIMETER
22702-541	ENCODING ALTIMETER
22702-542	ENCODING ALTIMETER
22702-543	ENCODING ALTIMETER
22921-1	GRIP ASSEMBLY
22982 M2	WIPER MOTOR
22A524	TACH GENERATOR
22A554	TACH GENERATOR
22A571	TACH GENERATOR
22A580	TACH GENERATOR
22A6000	TACH GENERATOR
22A623A	TACH GENERATOR
22A649	TACH GENERATOR

22A656	TACH GENERATOR
22A703	TACH GENERATOR
22A731	TACH GENERATOR
22A738	TACH GENERATOR
22A769	TACH GENERATOR
230-360-701-101	ACTUATOR
230-360-701-103	ACTUATOR
230-375-010-103	PANEL
230-375-011-103	PANEL
2306-556-00-10	FUEL GAGE
2306-557-00-10	FUEL GAGE
2306-559-20-10	FUEL GAGE
2306-559-20-11	FUEL GAGE
2306-560-20-10	FUEL GAGE
2306-560-20-11	FUEL GAGE
2306-561-20-11	FUEL GAGE
2306-562-20-10	FUEL GAGE
2306-562-20-11	FUEL GAGE
2309-155-00-10	VOLTMETER
2309-158-20-10	FUEL GAGE
2309-255-00-10	VOLTMETER
2309-256-20-10	VOLTMETER
2309-355-00-11	AMMETER
2309-355-00-20	AMMETER
2309-357-00-11	DC AMMETER
2309-359-20-10	AMMETER
2309-361-20-10	AMMETER
2309-362-00-10	AMMETER
2310-130-00-12	VOLTMETER
2310-230-00-12	AMMETER
23-1205-2A	INVERTER
2313M-20-2	WIPER MOTOR
23-374B-01	ALTIMETER
23-400-61-2	DIRECTIONAL GYRO
234ES016-1	HANDGRIP
235-005	VOLTMETER
2390-2	RPM LIMIT DETECTOR
242005-104	COMPASS CONTROL ANNUNCIATOR
24929-002	ENCODING ALTIMETER
25005-001	ENCODING ALTIMETER
25005-002	ENCODING ALTIMETER
25005-011	ENCODING ALTIMETER
25005-012	ENCODING ALTIMETER
25005-021	ENCODING ALTIMETER
25005-022	ENCODING ALTIMETER
25005-031	ENCODING ALTIMETER
25005-032	ENCODING ALTIMETER

25005-041	ENCODING ALTIMETER
25005-042	ENCODING ALTIMETER
25005-051	ENCODING ALTIMETER
25005-052	ENCODING ALTIMETER
25005-101	ENCODING ALTIMETER
25005-102	ENCODING ALTIMETER
25005-111	ENCODING ALTIMETER
25005-112	ENCODING ALTIMETER
25005-121	ENCODING ALTIMETER
25005-122	ENCODING ALTIMETER
25005-201	ENCODING ALTIMETER
25005-202	ENCODING ALTIMETER
25005-211	ENCODING ALTIMETER
25005-212	ENCODING ALTIMETER
25005-221	ENCODING ALTIMETER
25005-222	ENCODING ALTIMETER
25005-301	ENCODING ALTIMETER
25005-302	ENCODING ALTIMETER
25005-311	ENCODING ALTIMETER
25005-312	ENCODING ALTIMETER
25005-321	ENCODING ALTIMETER
25005-322	ENCODING ALTIMETER
25005-501	ENCODING ALTIMETER
25005-502	ENCODING ALTIMETER
2502-1004	FUEL PROBE
2502-1005	FUEL PROBE
2502-2003	FUEL PROBE
2502-2102	AIRSPEED INDICATOR
2502-3002	FUEL PROBE
2502-7001	FUEL QUANTITY TRANSMITTER
2503148-2	ANNUNCIATOR
250F17-2	FUEL FLOW SWITCH
25122-A15A-1-A2	SYNCHRO INDICATOR
25122-A17F-2-A3	SYNCHRO INDICATOR
25122-A23F-2-A2	SYNCHRO INDICATOR
25122-A27C-1-A1	SYNCHRO INDICATOR
25122-A27E-2-A3	SYNCHRO INDICATOR
25122-A29B-2-A2	SYNCHRO INDICATOR
25122-A2C-1-A1	SYNCHRO INDICATOR
25122-A30E-1-A1	SYNCHRO INDICATOR
25122-A37A-1-A1	SYNCHRO INDICATOR
25122-A37B-1-A1	SYNCHRO INDICATOR
25122-A37M-2-A2	SYNCHRO INDICATOR
25122-A37R-2-A2	SYNCHRO INDICATOR
25122-B16A-1-A1	SYNCHRO INDICATOR
25122-B25A-2-A2	SYNCHRO INDICATOR
25122-B25B-2-A2	SYNCHRO INDICATOR

25122-B3C-4-A2	SYNCHRO INDICATOR
25122-B4A-1-A1	SYNCHRO INDICATOR
25122-B57A-1-A2	SYNCHRO INDICATOR
25122-B5D-2-A2	SYNCHRO INDICATOR
25122-C72A-17-A3	SYNCHRO INDICATOR
25140/164A168-1	PUMP FUEL BOOST
25140/22A703	TACH GENERATOR
25140/65A173	LINEAR ACTUATOR
25140/65A192	ACTUATOR
25140/65A237	LINEAR ACTUATOR
25140-22A649	TACH GENERATOR
25140-22A658	TACH GENERATOR
25140-22A690	TACH GENERATOR
2579-116-1	DC VOLTMETER
25850-213	AIRSPEED INDICATOR
2587193-1	DIRECTIONAL GYRO
2587193-143	DIRECTIONAL GYRO
2587193-2	DIRECTIONAL GYRO
2587193-23	DIRECTIONAL GYRO
2587193-3	DIRECTIONAL GYRO
2587193-33	DIRECTIONAL GYRO
2587193-4	DIRECTIONAL GYRO
2587193-41	DIRECTIONAL GYRO
2587193-42	DIRECTIONAL GYRO
2587193-43	DIRECTIONAL GYRO
2587193-44	DIRECTIONAL GYRO
2587193-45	DIRECTIONAL GYRO
2587193-46	DIRECTIONAL GYRO
2587193-47	DIRECTIONAL GYRO
2587193-5	DIRECTIONAL GYRO
2587193-6	DIRECTIONAL GYRO
2587451-2	DIRECTIONAL GYRO
2587451-3	DISPLACEMENT GYRO
2587493-7	DIRECTIONAL GYRO
2591411-144	ATTITUDE DIRECTOR INDICATOR
2591411-244	ATTITUDE DIRECTOR INDICATOR
2591411-245	ATTITUDE DIRECTOR INDICATOR
2591411-264	ATTITUDE DIRECTOR INDICATOR
2591411-265	ATTITUDE DIRECTOR INDICATOR
2591411-444	ATTITUDE DIRECTOR INDICATOR
2591411-902	ATTITUDE DIRECTOR INDICATOR
2591411-903	ATTITUDE DIRECTOR INDICATOR
2591411-904	ATTITUDE DIRECTOR INDICATOR
2591411-906	ATTITUDE DIRECTOR INDICATOR
2591411-907	ATTITUDE DIRECTOR INDICATOR
2591411-908	ATTITUDE DIRECTOR INDICATOR
2591411-909	ATTITUDE DIRECTOR INDICATOR

2591411-910	ATTITUDE DIRECTOR INDICATOR
2593379-001	DUAL REMOTE COMPENSATOR
2593379-1	DUAL REMOTE COMPENSATOR
2593379-2	DUAL REMOTE COMPENSATOR
2593691-901	VERTICAL GYRO
2593996-333	TARSYN THREE-AXIS REFERENCE SENSOR
2593996-444	TARSYN THREE-AXIS REFERENCE SENSOR
2593996-555	TARSYN THREE-AXIS REFERENCE SENSOR
260-2350	TRIPLE TACHOMETER INDICATOR
260-2350-1	TRIPLE TACHOMETER INDICATOR
260-2357-5	DUAL TORQUE INDICATOR
26055-204-060-006	TURBINE INLET TEMPERATURE INDICATOR
261-10015	FUEL QUANTITY INDICATOR
261-10021	FUEL QUANTITY INDICATOR
2612-2001	OIL TEMPERATURE INDICATOR
261-926-001	OIL TEMPERATURE & PRESSURE INDICATOR
2660-1655-52	BLOWER ASSEMBLY
26-66306-1	TACHOMETER INDICATOR
267-960-001	RPM INDICATOR
267-961-001	TORQUE INDICATOR
267-962-001	RPM INDICATOR
2680003-2	MACH AIRSPEED INDICATOR
27-19160-1	OIL TEMPERATURE & PRESSURE INDICAT0R
27-19161-1	FUEL PRESSURE INDICATOR
27-19177-1	FUEL PRESSURE INDICATOR
27-19178-1	OIL TEMPERATURE & PRESSURE INDICAT0R
27-66004-11	INTER TURBINE TEMPERATURE INDICATOR
27-66004-13	INTER TURBINE TEMPERATURE INDICATOR
27-66004-17	INTER TURBINE TEMPERATURE INDICATOR
27-66004-19	INTER TURBINE TEMPERATURE INDICATOR
27-66004-7	INTER TURBINE TEMPERATURE INDICATOR
27-66004-9	INTER TURBINE TEMPERATURE INDICATOR
27-66008-5	OIL TEMPERATURE INDICATOR
27-66101-5	TORQUE INDICATOR
27-66101-9	TORQUE INDICATOR
27-86022-15	AIRSPEED INDICATOR
2800-6845N1L	TURN AND SLIP INDICATOR
28007-017	ALTIMETER
28007-201	ALTIMETER
28007-202	ALTIMETER
28007-203	ALTIMETER
28007-204	ALTIMETER
28007-205	ALTIMETER
28007-206	ALTIMETER
28007-207	ALTIMETER
28007-208	ALTIMETER
28007-209	ALTIMETER

28007-210	ALTIMETER
28007-211	ALTIMETER
28007-212	ALTIMETER
28007-214	ALTIMETER
28007-216	ALTIMETER
28007-218	ALTIMETER
28007-221	ALTIMETER
28007-224	ALTIMETER
28007-227	ALTIMETER
28007-228	ALTIMETER
28007-232	ALTIMETER
28007-427	ALTIMETER
28007-429	ALTIMETER
28007-431	ALTIMETER
28007-433	ALTIMETER
28007-923	ALTIMETER
2800-7970	TURN AND SLIP INDICATOR
2800N12	TURN AND SLIP INDICATOR
284042-0001	VALVE ASSEMBLY
284356-0001	VALVE ASSEMBLY
2850-0017	RPM LIMIT DETECTOR
2850-0019	RPM LIMIT DETECTOR
28P61D2A	TURN AND SLIP INDICATOR
28W2D25P	TURN AND SLIP INDICATOR
2915-01-070-5394	FUEL PUMP
2915-01-124-5222	FUEL BOOST PUMP
29287-002	PRESSURE TRANSMITTER
29C4843	VOLTAGE REGULATOR
2A1000-1AL	STATIC INVERTER
2A1000-1G	STATIC INVERTER
2A1000-1G-100	STATIC INVERTER
2A1000-1G-RR-1657	STATIC INVERTER
2A1000-AL	STATIC INVERTER
2A125-1A	STATIC INVERTER
2A125-1B-1	STATIC INVERTER
2A125-1C	STATIC INVERTER
2A250-1A	STATIC INVERTER
2A250-1B-1	STATIC INVERTER
2A250-1C-1	STATIC INVERTER
2A350-1A	STATIC INVERTER
2A350-1AS-1830	STATIC INVERTER
2A350-1B-1	STATIC INVERTER
2A350-1B-1-RR-1658	STATIC INVERTER
2A50-1A	STATIC INVERTER
2A800-1G	STATIC INVERTER
2A800-1G-RR-1657	STATIC INVERTER
2C12-1	FUEL PUMP

2C27-3	FUEL CARTRIDGE
2C27-4	FUEL CARTRIDGE
2C37-3	FUEL BOOST PUMP
2C37-4	FUEL BOOST PUMP
2C37-6	FUEL BOOST PUMP
2CM15AAB1	TACH GENERATOR
2CM272B1	STARTER
2CM73J2	DC STARTER
2CM9AAA6	TACH GENERATOR
2CM9AAC6	TACH GENERATOR
2CM9AAH4	TACH GENERATOR
2CM9AAV6	TACH GENERATOR
2CM9AAZ6	TACH GENERATOR
2CM9ABE6	TACH GENERATOR
2CM9ABH7	TACH GENERATOR
2CM9ABK7	TACH GENERATOR
2CM9ABY7	TACH GENERATOR
2CM9ABZ7	TACH GENERATOR
2CM9ACE7	TACH GENERATOR
2CM9ACF8	TACH GENERATOR
2CM9ACH7	TACH GENERATOR
2CM9ADB9	TACH GENERATOR
2CM9ADE8	TACH GENERATOR
2CM9ADT6	TACH GENERATOR
2D1200-2A-1033	STATIC INVERTER
2D54050B700	ALTIMETER
2N3904	NPN TRANSMITTER
2ZZ122M	MASTER ALARM AND INDICATION PANEL
30005-0000-34	TORQUE SIGNAL CONDITIONER
30005-0000-46	SIGNAL CONDITIONER
30-0504-1	STROBE LIGHT
30-0504-11	STROBE LIGHT
30-0504-13	STROBE LIGHT
30-0504-15	STROBE LIGHT
30-0504-17	STROBE LIGHT
30-0504-19	STROBE LIGHT
30-0504-21	STROBE LIGHT
30-0504-23	STROBE LIGHT
30-0504-25	STROBE LIGHT
30-0504-27	STROBE LIGHT
30-0504-29	STROBE LIGHT
30-0504-3	STROBE LIGHT
30-0504-31	STROBE LIGHT
30-0504-33	STROBE LIGHT
30-0504-35	STROBE LIGHT
30-0504-39	ANTI-COLLISION LIGHT
30-0504-41	STROBE LIGHT

30-0504-7	STROBE LIGHT
30-0504-9	STROBE LIGHT
30076-007	DC GENERATOR
301-001-019-001	HANDGRIP
30-1098-1	ANTI-COLLISION LIGHT
30-1098-3	ANTI-COLLISION LIGHT
30-1099-1	ANTI-COLLISION LIGHT
30-1099-1M	ANTI-COLLISION LIGHT
30-1099-3	ANTI-COLLISION LIGHT
30-1099-5	ANTI-COLLISION LIGHT
30-1099-7	ANTI-COLLISION LIGHT
30-1314-3	ANTI-COLLISION LIGHT
30-1314-5	ANTI-COLLISION LIGHT
30-1638-1	ANTI-COLLISION LIGHT
30230-0160	VERTICAL SPEED INDICATOR
30230-1165	VERTICAL SPEED INDICATOR
30-231	SMOKE DETECTOR
30-231-31	SMOKE DETECTOR
30-231-9	SMOKE DETECTOR
30-231R-17	SMOKE DETECTOR
30260-3126	VERTICAL SPEED INDICATOR
303-006-003	DUAL TORQUE INDICATOR
303-006-303	DUAL TORQUE INDICATOR
30-326 ET-1	CONTROL AMPLIFIER
303560-113MSN	TURN COORDINATOR
303770-113MSN	TURN COORDINATOR
303950-113MSN	TURN COORDINATOR
305-1A	GYRO HORIZON
305-1AL	GYRO HORIZON
305-1B	GYRO HORIZON
305-1BL	GYRO HORIZON
305-1C	GYRO HORIZON
305-1CL	GYRO HORIZON
305-2A	GYRO HORIZON
305-2AL	GYRO HORIZON
305-2B	GYRO HORIZON
305-2BC	GYRO HORIZON
305-2BL	GYRO HORIZON
305-2BLS	GYRO HORIZON
305-2C	GYRO HORIZON
305-2CL	GYRO HORIZON
3057-147	TORQUE INDICATOR
3057-148	TORQUE INDICATOR
3057-148-1	TORQUE INDICATOR
3057-148-2	TORQUE INDICATOR
3057-149	TORQUE INDICATOR
3057-149-2	TORQUE INDICATOR

30-57-149-2	TORQUE INDICATOR
3057-149-3	TORQUE INDICATOR
30-57-149-3	TORQUE INDICATOR
3057-149-4	TORQUE INDICATOR
30-57-149-4	TORQUE INDICATOR
3057-149-5	TORQUE INDICATOR
30-57-149-5	TORQUE INDICATOR
3057-149-6	TORQUE INDICATOR
30-57-149-6	TORQUE INDICATOR
3057-149-7	TORQUE INDICATOR
30-57-149-7	TORQUE INDICATOR
3057-169	TORQUE INDICATOR
3057-169-1	TORQUE INDICATOR
3057-169-2	DUAL TORQUE INDICATOR
3057-182-1	DUAL TORQUE INDICATOR
3057-204-1	T4 TEMPERATURE INDICATOR
30-57-204-1	T4 TEMPERATURE INDICATOR
3057-3-134	TORQUE INDICATOR
3057-3-135	TORQUE INDICATOR
3057-3-136	TORQUE INDICATOR
3057-3-136-1	TORQUE INDICATOR
30-57-3-136-1	TORQUE INDICATOR
30-57-3-136-2	TORQUE INDICATOR
3057-3-136-3	TORQUE INDICATOR
3057-3-136-4	TORQUE INDICATOR
3057-3-136-5	TORQUE INDICATOR
3057-3-136-6	TORQUE INDICATOR
3057-3-137	TORQUE INDICATOR
3080-201-2	DUAL TORQUE INDICATOR
30-80-201-4	DUAL TORQUE INDICATOR
30DV-0575	FAN
3100-0001	TORQUE INDICATOR
31000-036	TURBINE OUTLET TEMPERATURE INDICATOR
310-007-003	DUAL TORQUE INDICATOR
3100-2003	ENGINE OIL PRESSURE INDICATOR
3101-0001	TORQUE INDICATOR
3101-0003	TORQUE INDICATOR
3101-3001	TORQUE INDICATOR
31-061	POSITION LIGHT
31-063	POSITION LIGHT
31-071	POSITION LIGHT
31-073	POSITION LIGHT
31130-1380	CHIP DETECTOR
31230-1120	VERTICAL SPEED INDICATOR
31230-1127	VERTICAL SPEED INDICATOR
31400-001	ALTIMETER
31400-002	ALTIMETER

31400-003	ALTIMETER
31400-004	ALTIMETER
31400-007	ALTIMETER
31400-011	ALTIMETER
31400-012	ALTIMETER
31400-013	ALTIMETER
31400-014	ALTIMETER
31400-017	ALTIMETER
31400-117	ALTIMETER
31-515-1	REAR POSITION LIGHT
31-515-2	REAR POSITION LIGHT
31-515-3	SEARCHLIGHT
31-75	REAR POSITION LIGHT
318-00040	OIL PRESSURE TRANSMITTER
318-100	OIL PRESSURE TRANSMITTER
32005-000	TACH GENERATOR
32005-0008	TACH GENERATOR
32005-002	TACH GENERATOR
32005-005	TACH GENERATOR
32005-007	TACH GENERATOR
32005-008	TACH GENERATOR
32005-023	TACH GENERATOR
32005-025	TACH GENERATOR
32005-026	TACH GENERATOR
32005-030	TACH GENERATOR
32005-034	TACH GENERATOR
32005-037	TACH GENERATOR
3201-1001	TORQUE INDICATOR
3208-2002	FUEL QUANTITY INDICATOR
32164-000	TACH GENERATOR
32164-005	TACH GENERATOR
32164-007	TACH GENERATOR
32164-010	TACH GENERATOR
32164-011	TACH GENERATOR
32164-012	TACH GENERATOR
323A-2G	FLUX VALVE
323A-3G	FLUX VALVE
3244884-3	FUEL CONTROL UNIT
3252010-0101	ALTIMETER
3252010-1101	ALTIMETER
3252011-0101	ENCODING ALTIMETER
3252013-1101	ALTIMETER
3252013-1201	ALTIMETER
3252013-1401	ALTIMETER
3252013-1501	ALTIMETER
3265013-0601	FUEL FLOW INDICATOR
32-742	ANTI-COLLISION LIGHT

32D37-1	DIFFERENTIAL PRESSURE SWITCH
331A-3F	COURSE INDICATOR
331A-3G	COURSE INDICATOR
331A-6P	COURSE INDICATOR
331A-6R	COURSE INDICATOR
332D-11T	VERTICAL GYRO
332E-3G	DIRECTIONAL GYRO
336-00006	AIRSPEED INDICATOR
336-D-113	HANDGRIP
34090-402	AIRSPEED INDICATOR
34101CIT7-1B1	TACHOMETER INDICATOR
34102-C1C-4-1C1	TACHOMETER INDICATOR
34401-30-A22-1	OIL PRESSURE TRANSMITTER
34528-H-011	STROBE LIGHT
34528-H-021	POWER SUPPLY
34528-H-022	POWER SUPPLY
34670-101	VERTICAL SPEED INDICATOR
34670-102	VERTICAL SPEED INDICATOR
34670-112	VERTICAL SPEED INDICATOR
34670-201	VERTICAL SPEED INDICATOR
34670-202	VERTICAL SPEED INDICATOR
34670-402	VERTICAL SPEED INDICATOR
34670-601	VERTICAL SPEED INDICATOR
34670-602	VERTICAL SPEED INDICATOR
34670-A1300	VERTICAL SPEED INDICATOR
34670-B1300	VERTICAL SPEED INDICATOR
34670-C1300	VERTICAL SPEED INDICATOR
350568-503	TURBINE OUTLET TEMPERATURE INDICATOR
35060-11106	CABIN RATE OF CLIMB INDICATOR
35060-1117	VERTICAL SPEED INDICATOR
35060-1122	VERTICAL SPEED INDICATOR
35060-1145	RATE OF CLIMB INDICATOR
35060-1152	RATE OF CLIMB INDICATOR
350A76-1036-00	VERTICAL SPEED INDICATOR
351-37609-117	MASTER CAUTION PANEL
351-37609-123	ANNUNCIATOR PANEL
351-37609-125	MASTER CAUTION PANEL
351-37609-127	ANNUNCIATOR PANEL
351-38128-203	CAUTION PANEL
35-1595	PRESSURE GAUGE
352010-1101	ALTIMETER
35260-0149	VERTICAL SPEED INDICATOR
355A72-3023-01	SENSOR ASSEMBLY
355A72-3023-02	SENSOR ASSEMBLY
355A75-3023-01	SENSOR ASSEMBLY
3567401-3001	OIL PRESSURE TRANSMITTER
3567411-1501	PRESSURE TRANSMITTER

3567411-1502	PRESSURE TRANSMITTER
3567411-6001	PRESSURE TRANSMITTER
3567411-6002	PRESSURE TRANSMITTER
3567411-6003	PRESSURE TRANSMITTER
3567411-6004	PRESSURE TRANSMITTER
3567749-1501	PRESSURE TRANSMITTER
3567749-4001	PRESSURE TRANSMITTER
3567749-4003	PRESSURE TRANSMITTER
3567749-6001	PRESSURE TRANSMITTER
3567749-6505	PRESSURE TRANSMITTER
3567749-9401	PRESSURE TRANSMITTER
3567749-9402	PRESSURE TRANSMITTER
3567749-9502	PRESSURE TRANSMITTER
3567749-9601	PRESSURE TRANSMITTER
3567758-6501	DUAL TORQUE TRANSMITTER
3567758-6503	DUAL TORQUE TRANSMITTER
356H2801	STROBE LIGHT
356H2802	POWER SUPPLY
35700-AD-M	ALTIMETER
3571211-0006	SYNCHRO INDICATOR
3571211-0052	SYNCHRO INDICATOR
3571211-0055	SYNCHRO INDICATOR
3571211-9001	SYNCHRO INDICATOR
3571211-9009	SYNCHRO INDICATOR
3571211-9010	SYNCHRO INDICATOR
3571211-9011	SYNCHRO INDICATOR
3571211-9012	SYNCHRO INDICATOR
3571211-9014	SYNCHRO INDICATOR
3571211-9015	SYNCHRO INDICATOR
3571211-9016	SYNCHRO INDICATOR
3571211-9020	SYNCHRO INDICATOR
3571211-9021	SYNCHRO INDICATOR
3571211-9028	SYNCHRO INDICATOR
3571211-9032	SYNCHRO INDICATOR
3571211-9035	SYNCHRO INDICATOR
3571211-9039	SYNCHRO INDICATOR
3571211-9040	SYNCHRO INDICATOR
3571211-9041	SYNCHRO INDICATOR
3571211-9043	SYNCHRO INDICATOR
3571211-9054	SYNCHRO INDICATOR
3571212-0006	SYNCHRO INDICATOR
3571212-0052	SYNCHRO INDICATOR
3571212-0055	SYNCHRO INDICATOR
3571251-9110	GAS PRODUCER TACHOMETER INDICATOR
3571251-9111	GAS PRODUCER TACHOMETER INDICATOR
3571251-9115	GAS PRODUCER TACHOMETER INDICATOR
3571251-9116	GAS PRODUCER TACHOMETER INDICATOR

3571251-9119	GAS PRODUCER TACHOMETER INDICATOR
3571251-9120	GAS PRODUCER TACHOMETER INDICATOR
3571251-9121	GAS PRODUCER TACHOMETER INDICATOR
3571251-9122	GAS PRODUCER TACHOMETER INDICATOR
3571251-9123	MGT INDICATOR
3571251-9127	TURBINE OUTLET TEMPERATURE INDICATOR
3571251-9129	TURBINE OUTLET TEMPERATURE INDICATOR
3571251-9131	INTER TURBINE TEMPERATURE INDICATOR
3571251-9202	TORQUE INDICATOR
3571251-9207	TORQUE INDICATOR
3571251-9209	TORQUE INDICATOR
3571251-9210	FUEL PRESSURE INDICATOR
3571251-9212	TORQUE INDICATOR
3571251-9212M	TORQUE INDICATOR
3571251-9215	TORQUE INDICATOR
3571251-9216	TORQUE INDICATOR
3571260-5009	TACHOMETER INDICATOR
3571261-2003	TACHOMETER INDICATOR
3571261-2004	TACHOMETER INDICATOR
3571261-8101	TACHOMETER INDICATOR
3571261-8102	TACHOMETER INDICATOR
3571261-8103	TACHOMETER INDICATOR
3571261-8104	TACHOMETER INDICATOR
3571261-81-04	TACHOMETER INDICATOR
3571262-2301	TACHOMETER INDICATOR
3571262-2302	TACHOMETER INDICATOR
3571262-2303	TACHOMETER INDICATOR
3571262-2306	TACHOMETER INDICATOR
3571262-2307	TACHOMETER INDICATOR
3571262-2308	TACHOMETER INDICATOR
3571262-5101	TACHOMETER INDICATOR
3571262-5108	TACHOMETER INDICATOR
3571262-5109	TACHOMETER INDICATOR
3571280-4002	TACHOMETER INDICATOR
3571281-8102	TACHOMETER INDICATOR
3571370-0001	DUAL TACHOMETER INDICATOR
3571370-3002	DUAL TACHOMETER INDICATOR
3571370-3003	DUAL TACHOMETER INDICATOR
3571371-6001	TRIPLE TACHOMETER INDICATOR
3571371-6002	TRIPLE TACHOMETER INDICATOR
3571371-8001	TACHOMETER INDICATOR
3571371-9001	TRIPLE TACHOMETER INDICATOR
35890-01	AIRSPEED INDICATOR
35890-14	AIRSPEED INDICATOR
35890-15	AIRSPEED INDICATOR
35890-16	AIRSPEED INDICATOR
35890-18	AIRSPEED INDICATOR

35890-48	AIRSPEED INDICATOR
35890-AA-M	AIRSPEED INDICATOR
35890-AB-M	AIRSPEED INDICATOR
35890-AD-M	AIRSPEED INDICATOR
35890-AE-M	AIRSPEED INDICATOR
35890-AF-M	AIRSPEED INDICATOR
36101P	GYRO HORIZON
36104-1H-8-A1	RADIO MAGNETIC INDICATOR
36104-1L-11-A1	RADIO MAGNETIC INDICATOR
36104-1L-11-A2	RADIO MAGNETIC INDICATOR
36109-1L11A3	RMI
361-11425-001	VOLTAGE REGULATOR
36300-1154	CLOCK
369A4514-3	ENGINE POWER OUT CONTROL UNIT
369A4515	DUAL TACHOMETER INDICATOR
369A4516	TACHOMETER INDICATOR
369A4516-7	TACHOMETER INDICATOR
369A4517	TACH GENERATOR
369A4521-5	TURBINE OUTLET TEMPERATURE INDICATOR
369A4521-7	TURBINE OUTLET TEMPERATURE INDICATOR
369D24135-5	TEMPERATURE INDICATOR
369D24136	AMP METER
369D24137	FUEL QUANTITY INDICATOR
369D24518	TACHOMETER INDICATOR
369D-24518-3	DUAL TACHOMETER INDICATOR
369D245-18-5	DUAL TACHOMETER INDICATOR
369D296305-21	INSTRUMENT CLUSTER
369D296305-31	INSTRUMENT CLUSTER
369D4518	DUAL TACHOMETER INDICATOR
369D4518-3	DUAL TACHOMETER INDICATOR
369H4508-3	COMPASS
369H4512	TORQUE INDICATOR
369H45126	TORQUE INDICATOR
369H45126-7	TORQUE INDICATOR
369H4512B	TORQUE INDICATOR
369H4518	DUAL TACHOMETER INDICATOR
369H4518-7	DUAL TACHOMETER INDICATOR
369H4522	TORQUE INDICATOR
369H4526	TORQUE INDICATOR
369H4526-21	TORQUE INDICATOR
369H4526-3	TORQUE INDICATOR
369H4526-5	TORQUE INDICATOR
369H4526-7	TORQUE INDICATOR
369H4551	TACH GENERATOR
369H6418	TORQUE INDICATOR
369H6425-5	DIMMER CONTROL
369H90153	HANDGRIP

369H92518	ATTITUDE GYRO
369H92831	GYRO HORIZON
369H92832	DIRECTIONAL GYRO
36D831518G1	STARTER
36D831711G2	DC STARTER
36D831711G4	DC STARTER
3706-2001	DC AMMETER
37-113-7	HANDLIGHT
37-113-8	HANDLIGHT
37-115	HANDLIGHT
37-117-7	HANDLIGHT
37-120-7	HANDLIGHT
371GC01Y02	MASTER ELECTRICAL BOX
371GC01Y021	MASTER ELECTRICAL BOX
371GCO1Y02	MASTER ELECTRICAL BOX
371K-010	ALTIMETER
371K-05	ALTIMETER
371P1-01	ALTIMETER
371P-1-01	ALTIMETER
372G01Y	MASTER ELECTRICAL BOX
372GC01Y	MASTER ELECTRICAL BOX
372GC01Y001	MASTER ELECTRICAL BOX
373GC01Y	MASTER ELECTRICAL BOX
373GC01Y001	MASTER ELECTRICAL BOX
37480-20	RATE OF CLIMB INDICATOR
37480-24	RATE OF CLIMB INDICATOR
37480-28	RATE OF CLIMB INDICATOR
37480-40	RATE OF CLIMB INDICATOR
37480-50	RATE OF CLIMB INDICATOR
37480-58	RATE OF CLIMB INDICATOR
37480-AA-M	RATE OF CLIMB INDICATOR
37480-AD-M	RATE OF CLIMB INDICATOR
374GC01Y	MASTER ELECTRICAL BOX
37500-000	ALTIMETER
37500-080	ALTIMETER
37500-084	ALTIMETER
37500-0840	ALTIMETER
37500-0841	ALTIMETER
37500-0847	ALTIMETER
37500-0848	ALTIMETER
37500-220	ALTIMETER
37500-224	ALTIMETER
37500-2241	ALTIMETER
37500-280	ALTIMETER
37500-284	ALTIMETER
37500-5847	ALTIMETER
37500-AB-M	ALTIMETER

3751251-9123	MGT INDICATOR
375GC01Y00	MASTER ELECTRICAL BOX
380807-001	FUEL QUANTITY INDICATOR
380807-002	FUEL QUANTITY INDICATOR
380807-003	FUEL QUANTITY INDICATOR
380807-004	FUEL QUANTITY INDICATOR
380807-005	FUEL QUANTITY INDICATOR
3809310-3	GAS TEMPERATURE INDICATOR
3809311-3	TACHOMETER INDICATOR
3809311-4	TACHOMETER INDICATOR
3809312-6	TORQUE INDICATOR
3809313-5	TORQUE INDICATOR
3809314-4	DUAL TACHOMETER INDICATOR
3809314-5	DUAL TACHOMETER INDICATOR
3809358-2	TACHOMETER INDICATOR
3809400-2	TACHOMETER INDICATOR
381058-08007	TRANSMITTER
381065-009	FUEL PROBE
38210-000	VERTICAL SPEED INDICATOR
38210-010	VERTICAL SPEED INDICATOR
38210-300	VERTICAL SPEED INDICATOR
38210-3641	RATE OF CLIMB INDICATOR
38210-380	VERTICAL SPEED INDICATOR
38210-3841	RATE OF CLIMB INDICATOR
38210-390	VERTICAL SPEED INDICATOR
38210-3940	RATE OF CLIMB INDICATOR
38210-3941	RATE OF CLIMB INDICATOR
38210-3948	RATE OF CLIMB INDICATOR
38210-397	VERTICAL SPEED INDICATOR
38210-480	VERTICAL SPEED INDICATOR
38210-490	VERTICAL SPEED INDICATOR
38210-AC-M	VERTICAL SPEED INDICATOR
38221-01-250	GYRO HORIZON
38221-07-254	GYRO HORIZON
38221-AA-M	GYRO HORIZON
38221-AB-M	GYRO HORIZON
38222-100	DIRECTIONAL GYRO
38222-101	DIRECTIONAL GYRO
38222-102	DIRECTIONAL GYRO
38222-103	DIRECTIONAL GYRO
38222-104	DIRECTIONAL GYRO
38222-105	DIRECTIONAL GYRO
38222-110	DIRECTIONAL GYRO
38222-111	DIRECTIONAL GYRO
38222-112	DIRECTIONAL GYRO
38222-113	DIRECTIONAL GYRO
38222-114	DIRECTIONAL GYRO

38222-115	DIRECTIONAL GYRO
38222-150	DIRECTIONAL GYRO
38222-151	DIRECTIONAL GYRO
38222-152	DIRECTIONAL GYRO
38222-153	DIRECTIONAL GYRO
38222-154	DIRECTIONAL GYRO
38222-155	DIRECTIONAL GYRO
38222-200	DIRECTIONAL GYRO
38222-201	DIRECTIONAL GYRO
38222-202	DIRECTIONAL GYRO
38222-203	DIRECTIONAL GYRO
38222-204	DIRECTIONAL GYRO
38222-205	DIRECTIONAL GYRO
38222-210	DIRECTIONAL GYRO
38222-211	DIRECTIONAL GYRO
38222-212	DIRECTIONAL GYRO
38222-213	DIRECTIONAL GYRO
38222-214	DIRECTIONAL GYRO
38222-215	DIRECTIONAL GYRO
38222-250	DIRECTIONAL GYRO
38222-251	DIRECTIONAL GYRO
38222-252	DIRECTIONAL GYRO
38222-253	DIRECTIONAL GYRO
38222-254	DIRECTIONAL GYRO
38222-255	DIRECTIONAL GYRO
38314A	GYRO HORIZON
38314B	GYRO HORIZON
38399-330	AIRSPEED INDICATOR
38399-330-02	AIRSPEED INDICATOR
38399-480	AIRSPEED INDICATOR
38399-480-02	AIRSPEED INDICATOR
38399-490	AIRSPEED INDICATOR
38399-490-02	AIRSPEED INDICATOR
38399-AB-M	AIRSPEED INDICATOR
38399-AC-M	AIRSPEED INDICATOR
38399-AD-M	AIRSPEED INDICATOR
384178-091	FUEL SELECTOR SWITCH
384178-103	FUEL QUANTITY SELECTOR
386500-5	FUEL PUMP
389-1	INDICATOR
391001-395	FUEL PROBE
391001-396	FUEL PROBE
391001-410	FUEL PROBE
391037-03160	TANK UNIT
391043-03001	TANK UNIT
391046-197	FUEL PROBE
391046-199	FUEL PROBE

391046-200	TRANSMITTER
3911212-5002	GAS TEMPERATURE INDICATOR
3911212-9001	GAS TEMPERATURE INDICATOR
3911212-9002	GAS TEMPERATURE INDICATOR
3911213-5002	GAS TEMPERATURE INDICATOR
3911213-9002	MGT INDICATOR
3911213-9005	GAS TEMPERATURE INDICATOR
3911213-9008	GAS TEMPERATURE INDICATOR
3911213-9009	GAS TEMPERATURE INDICATOR
3911213-9016	GAS TEMPERATURE INDICATOR
393004-01491	FUEL QUANTITY INDICATOR
393004-01970	GAS TEMPERATURE INDICATOR
393004-051	FUEL QUANTITY INDICATOR
393004-075	FUEL QUANTITY INDICATOR
393008-036	FUEL QUANTITY INDICATOR
393008-037	FUEL QUANTITY INDICATOR
393008-040	FUEL QUANTITY INDICATOR
393008-042	FUEL QUANTITY INDICATOR
393008-046	FUEL QUANTITY INDICATOR
393008-047	FUEL QUANTITY INDICATOR
393008-056	FUEL QUANTITY INDICATOR
393008-064	FUEL QUANTITY INDICATOR
393008-074	FUEL QUANTITY INDICATOR
393008-077	FUEL QUANTITY INDICATOR
393008-078	FUEL QUANTITY INDICATOR
393008-079	FUEL QUANTITY INDICATOR
393008-080	FUEL QUANTITY INDICATOR
393008-082	FUEL QUANTITY INDICATOR
3930291-9001	FUEL FLOW INDICATOR
393084-11358	LIQUID OXYGEN INDICATOR
393085-43708	FUEL QUANTITY INDICATOR
393090-101	FUEL QUANTITY INDICATOR
393090-103	FUEL QUANTITY INDICATOR
393090-109	FUEL QUANTITY INDICATOR
393090-111	FUEL QUANTITY INDICATOR
393090-113	FUEL QUANTITY INDICATOR
393090-115	FUEL QUANTITY INDICATOR
393090-117	FUEL QUANTITY INDICATOR
3932241-9001	FUEL QUANTITY INDICATOR
3932241-9002	FUEL QUANTITY INDICATOR
3932241-9003	FUEL QUANTITY INDICATOR
3932241-9008	FUEL QUANTITY INDICATOR
3935-1	TURN AND SLIP INDICATOR
3935-2	TURN AND SLIP INDICATOR
3940233-9003	GAS PRODUCER TACHOMETER INDICATOR
3941212-9001	GAS PRODUCER TACHOMETER INDICATOR
3941213-9003	GAS PRODUCER TACHOMETER INDICATOR

3941213-9009	GAS PRODUCER TACHOMETER INDICATOR
3941213-9014	GAS PRODUCER TACHOMETER INDICATOR
3942333-9002	DUAL TACHOMETER INDICATOR
3943331-9002	TRIPLE TACHOMETER INDICATOR
3943333-9001	TRIPLE TACHOMETER INDICATOR
3943333-9002	TRIPLE TACHOMETER INDICATOR
39563-001	BATTERY
39600-000	ENCODING ALTIMETER
39600-001	ENCODING ALTIMETER
39600-002	ENCODING ALTIMETER
39600-080	ENCODING ALTIMETER
39600-083	ENCODING ALTIMETER
39600-100	ENCODING ALTIMETER
39600-101	ENCODING ALTIMETER
39600-102	ENCODING ALTIMETER
39600-120	ENCODING ALTIMETER
39600-164	ENCODING ALTIMETER
39600-180	ENCODING ALTIMETER
39600-183	ENCODING ALTIMETER
39600-200	ENCODING ALTIMETER
39600-5241	ENCODING ALTIMETER
39600-584	ENCODING ALTIMETER
39600-5840	ENCODING ALTIMETER
39600-5841	ENCODING ALTIMETER
39600-5847	ENCODING ALTIMETER
39600-5848	ENCODING ALTIMETER
39600-586	ENCODING ALTIMETER
39600-684	ENCODING ALTIMETER
39600-686	ENCODING ALTIMETER
39600-900	ENCODING ALTIMETER
39601-AB-M	ENCODING ALTIMETER
39601-AC-M	ENCODING ALTIMETER
39601-AD-M	ENCODING ALTIMETER
39648-3	TACHOMETER INDICATOR
3972A010000	CONDENSER FAN
399A65-3	FUEL DUMP VALVE
399A65-31	FUEL DUMP VALVE
3A1000-1G	STATIC INVERTER
3A125-1B-1	STATIC INVERTER
3A250-1B-1	STATIC INVERTER
3A50-1B-1	STATIC INVERTER
3D2485-12	PNEUMATIC DE-ICER TIMER
3D2485-13	PNEUMATIC DE-ICER TIMER
3E1150-10	PROP DE-ICER TIMER
3E1150-11	PROP DE-ICER TIMER
3E1150-12	PROP DE-ICER TIMER
3E2311-6	TIMER/MONITOR

3E2Y8/475-1	VOLTAGE REGULATOR
3G2592V00551	LOAD INDICATOR
3S2060DR149A1A	VOLTAGE REGULATOR
3S2060DR149C1	VOLTAGE REGULATOR
3ZZ210M	MASTER ALARM AND INDICATION PANEL
400-0098-000	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0098-001	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0098-002	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
4000-10	EMERGENCY LOCATOR TRANSMITTER
4000-1002	CLOCK
400-0102-000	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0102-0003	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0102-001	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0102-002	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0102-003	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0103-000	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0103-001	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0103-002	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-0106-000	C-1000 CONTROL UNIT
400-0106-010	C-1000 CONTROL HEAD
400-0106-011	C-1000 CONTROL UNIT
4000-10F	EMERGENCY LOCATOR TRANSMITTER
400-012785-00	TRANSCEIVER
400-012785-01	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-012785-02	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-012785-03	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-012785-50	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-012785-51	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-012785-52	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-012785-53	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-00	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-01	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-02	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-03	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-50	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-51	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-52	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-014525-53	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
400-075-826	AIRSPEED INDICATOR
4000937-6201	NAVIGATION RECEIVER
4000B-12	DIRECTIONAL GYRO
4000B-9	DIRECTIONAL GYRO
4000C	DIRECTIONAL GYRO
4000D	DIRECTIONAL GYRO
40-0100-1	ROTATING BEACON
400100-105	MAGNETIC COMPASS
40-0100-11	ROTATING BEACON

40-0100-13	ROTATING BEACON
40-0100-17	ROTATING BEACON
40-0100-19	ROTATING BEACON
40-0100-21	ROTATING BEACON
40-0100-23	ROTATING BEACON
40-0100-25	ROTATING BEACON
40-0100-27	ROTATING BEACON
40-0100-29	ROTATING BEACON
40-0100-3	ROTATING BEACON
40-0100-31	ROTATING BEACON
40-0100-5	ROTATING BEACON
40-0100-7	ROTATING BEACON
40-0100-9	ROTATING BEACON
40-0103-29	ANTI-COLLISION LIGHT
40-0103-31	BEACON ASSEMBLY
40-01117	SEARCHLIGHT
40-0117-1	LIGHT ASSEMBLY BEACON
40-0127-1	TANDEM OSCILLATING LIGHT
40-0127-3	TANDEM OSCILLATING LIGHT
40-0127-5	TANDEM OSCILLATING LIGHT
40-0127-7	TANDEM OSCILLATING LIGHT
40-0127-8	TANDEM OSCILLATING LIGHT
40-0127-9	TANDEM OSCILLATING LIGHT
400-150-1	AIRSPEED SWITCH
4001808-901	VERTICAL GYRO
400201TYPEA13A1	CLOCK
400260-3	TEMPERATURE CONTROL
400260-4	TEMPERATURE CONTROL
400-366-010-101	MOTOR DRIVEN VALVE
400-375-017	AIRSPEED INDICATOR
400-375-017-101	AIRSPEED INDICATOR
4007977-7	LIGHT
400GL	VOLTMETER
4012-1003	VOLTMETER
4013-2001	VOLTMETER
4013-3001	VOLTMETER
4014267-902	ALTIMETER
4014267-904	RADAR ALTIMETER
4016-1020	AMMETER
4019190-1	DIRECTIONAL GYRO
4019190-13	DIRECTIONAL GYRO
4019190-16	DIRECTIONAL GYRO
4019190-18	DIRECTIONAL GYRO
4019190-2	DIRECTIONAL GYRO
4019190-3	DIRECTIONAL GYRO
4019190-4	DIRECTIONAL GYRO
4019190-5	DIRECTIONAL GYRO

4019190-6	DIRECTIONAL GYRO
4019190-7	DIRECTIONAL GYRO
4019286-901	VERTICAL GYRO
4019286-902	VERTICAL GYRO
4019286-903	VERTICAL GYRO
4019759-1	DIRECTIONAL GYRO
4019759-901	DIRECTIONAL GYRO
4019759-902	DIRECTIONAL GYRO
401EED1-1	STANDBY ENGINE INDICATOR
4020531-100	GYRO HORIZON
4020531-102	GYRO HORIZON
4020531-130	GYRO HORIZON
4020531-150	GYRO HORIZON
4020531-170	GYRO HORIZON
4020531-330	GYRO HORIZON
4020531-332	GYRO HORIZON
4020531-360	GYRO HORIZON
4020531-394	GYRO HORIZON
4020531-504	GYRO HORIZON
4020531-505	GYRO HORIZON
4020531-509	GYRO HORIZON
4020531-531	GYRO HORIZON
4020531-534	GYRO HORIZON
4020531-561	GYRO HORIZON
4020531-574	GYRO HORIZON
4020531-594	GYRO HORIZON
4020577-3	DIRECTIONAL GYRO
4020577-6	DIRECTIONAL GYRO
4020577-8	DIRECTIONAL GYRO
4020936-901	TARSYN THREE-AXIS REFERENCE SENSOR
4020936-902	TARSYN THREE-AXIS REFERENCE SENSOR
4020936-903	TARSYN THREE-AXIS REFERENCE SENSOR
4020936-904	TARSYN THREE-AXIS REFERENCE SENSOR
4021541-131	GYRO HORIZON
4021541-171	GYRO HORIZON
4021541-191	GYRO HORIZON
4021541-193	GYRO HORIZON
4021541-300	GYRO HORIZON
4021541-330	GYRO HORIZON
4021541-331	GYRO HORIZON
4021541-360	GYRO HORIZON
4021541-371	GYRO HORIZON
4021541-390	GYRO HORIZON
4021541-391	GYRO HORIZON
4021541-560	GYRO HORIZON
4021541-580	GYRO HORIZON
4021541-590	GYRO HORIZON

4021541-594	GYRO HORIZON
4021541-595	GYRO HORIZON
4021541-671	GYRO HORIZON
4021541-691	GYRO HORIZON
4021541-771	GYRO HORIZON
4021541-772	GYRO HORIZON
4021541-791	GYRO HORIZON
4021979-901	DIRECTIONAL GYRO
4022211-100	GYRO HORIZON
40-250	AIRSPEED INDICATOR
4027170-904	HORIZONTAL SITUATION INDICATOR
402-90-1	AIRSPEED SWITCH
4030182-901	ALTIMETER SENSOR
4030567-191	ATTITUDE INDICATOR
4030567-291	GYRO HORIZON
406-001-303-101	HANDGRIP
406-074-013-103	PANEL
406-075-819-101	PANEL
406-075-826-101	AIRSPEED INDICATOR
406-075-826-103	AIRSPEED INDICATOR
406-075-831-101	PANEL
406-075-832-103	PANEL
406-075-833-105	PANEL
406-075-840-103	PANEL
406-077-814-101	PANEL
40-619-3	HYDRAULIC PRESSURE INDICATOR
406-375-200-103	PANEL
406-375-200-105	PANEL
406-375-205-101	TURBINE OUTLET TEMPERATURE INDICATOR
406-375-205-103	TURBINE OUTLET TEMPERATURE INDICATOR
406-375-206-101	GAS PRODUCER TACHOMETER INDICATOR
406-375-207-101	DUAL TORQUE INDICATOR
406-375-208-101	DUAL TACHOMETER INDICATOR
406-375-213-105	RPM SENSOR
406-375-217-103	PANEL
406-375-220-101	ATTITUDE INDICATOR
406-375-220-103	ATTITUDE GYRO
406-375-221-101	PANEL
406-375-221-105	PANEL
406-375-222-105	PANEL
406-375-223-109	PANEL
406-375-223-119	PANEL
406-375-223-121	PANEL
406-375-224-101	PANEL
406-375-225-105	PANEL
406-375-231-105	TORQUE AND TURBINE GAS TEMPERATURE INDICATOR
406EED1-1	STANDBY ENGINE INDICATOR

407-075-015	AIRSPEED INDICATOR
407-075-015-103	AIRSPEED INDICATOR
407-075-024-103	FUEL PRESSURE/AMMETER INDICATOR
407-075-024-105	FUEL PRESSURE/AMMETER INDICATOR
407-075-024-107	FUEL PRESSURE/AMMETER INDICATOR
407-375-001-101	MGT INDICATOR
407-375-001-103	MGT INDICATOR
407-375-001-105	MGT INDICATOR
407-375-001-107	MGT INDICATOR
407-375-002-101	NG INDICATOR
407-375-002-103	NG INDICATOR
407-375-002-105	NG INDICATOR
407-375-003-101	ENGINE TORQUE INDICATOR
407-375-003-105	ENGINE TORQUE INDICATOR
407-375-003-107	TORQUE INDICATOR
407-375-003-109	TORQUE INDICATOR
407-375-004-101	OIL TEMPERATURE & PRESSURE INDICAT0R
407-375-004-103	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
407-375-005-101	TRANSMISSION OIL TEMPERATURE & PRESSURE INDICATOR
407-375-005-103	TRANSMISSION OIL TEMPERATURE & PRESSURE INDICATOR
407-375-006-101	FUEL QUANTITY INDICATOR
407-375-006-103	FUEL QUANTITY INDICATOR
407-375-007-101	FUEL PRESSURE/AMMETER INDICATOR
407-375-007-103	FUEL PRESSURE/AMMETER INDICATOR
407-375-007-105	FUEL PRESSURE/AMMETER INDICATOR
407-375-007-107	FUEL PRESSURE/AMMETER INDICATOR
407-375-007-109	FUEL PRESSURE/AMMETER INDICATOR
407-375-008-101	DUAL TACHOMETER INDICATOR
407-375-008-103	DUAL TACHOMETER INDICATOR
407-375-008-105	DUAL TACHOMETER INDICATOR
407-375-008-107	DUAL TACHOMETER INDICATOR
407-375-008-109	DUAL TACHOMETER INDICATOR
407-375-008-111	DUAL TACHOMETER INDICATOR
407-375-008-113	DUAL TACHOMETER INDICATOR
407-375-009-101	FUEL PROBE
407-375-010-101	FUEL PROBE
407-375-011-101	FUEL PROBE
407-375-015-101	CAUTION PANEL
407-375-015-103	CAUTION PANEL
407-375-015-105	CAUTION PANEL
407-375-015-107	CAUTION PANEL
407-375-015-109	CAUTION PANEL
407-375-015-111	CAUTION PANEL
407-375-016-101	FUEL SIGNAL CONDITIONER
407-375-016-103	FUEL SIGNAL CONDITIONER
407-375-021-107	RPM SENSOR
4101-1003	LOADMETER

4101-1006	LOADMETER
4101-1009	LOADMETER
4101-3002	LOADMETER
4106-1015	DC AMMETER
4106-1016	DC AMMETER
41105-C5A-4-B3	DUAL TACHOMETER INDICATOR
41105C5A4E3	DUAL TACHOMETER INDICATOR
41105-C5A-4E3	DUAL TACHOMETER INDICATOR
41105-C5A-4-E3	DUAL TACHOMETER INDICATOR
412-001-370-101	ACTUATOR
412-074-030-101	ISOLATION AMPLIFIER
412-074-101-101	TRANSMITTER
412-074-101-103	TRANSDUCER - DUAL ELEMENT
412-075-008-101	DUAL TORQUE INDICATOR
412-075-008-109	DUAL TORQUE INDICATOR
412-075-008-111	DUAL TORQUE INDICATOR
412-075-008-113	DUAL TORQUE INDICATOR
412-075-008-115	DUAL TORQUE INDICATOR
412-075-009-105	AIRSPEED INDICATOR
412-075-009-107	AIRSPEED INDICATOR
412-075-009-109	AIRSPEED INDICATOR
412-075-010-105	TRIPLE TACHOMETER INDICATOR
412-075-010-107	TRIPLE TACHOMETER INDICATOR
412-075-010-109	TRIPLE TACHOMETER INDICATOR
412-075-010-111	TRIPLE TACHOMETER INDICATOR
412-075-010-113	TRIPLE TACHOMETER INDICATOR
412-075-010-115	TRIPLE TACHOMETER INDICATOR
412-075-101-101	STATIC INVERTER
412-075-101-103	STATIC INVERTER
412-075-205-101	TORQUE/PRESSURE TRANSMITTER
412-075-502-105	AFCS ACTUATOR POSITION PANEL
412-075-513-103	FUEL CONTROL PANEL
412-075-700-111	PANEL
412-075-701-113	PANEL
412-075-704-103	PANEL
412-075-706-103	PANEL
412-075-706-105	PANEL
412-075-710-101	PANEL
412-075-711-101	PANEL
412-375-001-101	FUEL QUANTITY INDICATOR
412-375-001-105	FUEL QUANTITY INDICATOR
412-375-003-107	SIGNAL CONDITIONER
412-375-006-101	PRESSURE TRANSDUCER
412-375-006-103	PRESSURE TRANSDUCER
412-375-007-101	TRIPLE TORQUE INDICATOR
412-375-007-103	TRIPLE TORQUE INDICATOR
412-375-007-105	TRIPLE TORQUE INDICATOR

412-375-007-107	TRIPLE TORQUE INDICATOR
412-375-007-109	TRIPLE TORQUE INDICATOR
412-375-007-111	TRIPLE TORQUE INDICATOR
412-375-007-113	TRIPLE TORQUE INDICATOR
412-375-007-115	TRIPLE TORQUE INDICATOR
412-375-007-117	TRIPLE TORQUE INDICATOR
412-375-008-101	DUAL TACHOMETER INDICATOR
412-375-010-101	ENCODING ALTIMETER
412-375-010-103	ENCODING ALTIMETER
412-375-023-101	PANEL
412-375-023-103	PANEL
412-375-023-105	PANEL
412-375-024-101	PANEL
412-375-027-101	PANEL
412-375-035-101	FUEL PRESSURE INDICATOR
412-375-036-101	OIL TEMPERATURE & PRESSURE INDICATOR
412-375-079-101	STATIC INVERTER
412-375-084-101	PANEL
412-375-085-101	PANEL
412-375-086-101	PANEL
412-375-087-101	PANEL
412-375-400-101	PANEL
412-375-401-101	PANEL
412-375-401-103	PANEL
412-375-402-103	PANEL
412-375-402-105	PANEL
412-375-403-105	PANEL
412-375-404-101	PANEL
412-375-405-101	PANEL
412-375-405-103	PANEL
412-375-405-105	PANEL
412-375-700-105	PANEL
412-375-701-101	PANEL
412-375-702-103	PANEL
412-375-702-105	PANEL
412-375-702-107	PANEL
412-375-703-101	PANEL
412-375-704-101	PANEL
412-375-704-105	PANEL
412-375-710-103	PANEL
412-375-711-105	PANEL
412-375-711-107	PANEL
412-375-711-113	PANEL
412-375-712-101	PANEL
412-375-712-107	PANEL
412-375-712-109	PANEL
412-375-712-115	PANEL

412-375-712-123	PANEL
412-375-712-129	PANEL
412-375-713-103	PANEL
412-375-714-101	PANEL
412-375-714-103	PANEL
412-375-714-105	PANEL
4128-00141	OIL PRESSURE TRANSMITTER
412-899-126-119	MASTER CAUTION PANEL
412-899-701-107	PANEL
414ES209-5	GAS PRODUCER TACHOMETER INDICATOR
414ES273-1	HANDGRIP
414ES2883	TRIPLE TACHOMETER INDICATOR
415039983-00	FUEL SIGNAL CONDITIONER
418-00011	OIL PRESSURE TRANSMITTER
418-00014	OIL PRESSURE TRANSMITTER
418-00041	OIL PRESSURE TRANSMITTER
418-00044	OIL PRESSURE TRANSMITTER
418-00064	OIL PRESSURE TRANSMITTER
418-00081	OIL PRESSURE TANSMITTER
418-00084	OIL PRESSURE TRANSMITTER
418-00181	OIL PRESSURE TRANSMITTER
418-01081	OIL PRESSURE TRANSMITTER
418-01084	OIL PRESSURE TRANSMITTER
41850A	LANDING AND SEARCH LIGHT
41850A14-4580	LANDING AND SEARCH LIGHT
41850A17-4580	LANDING AND SEARCH LIGHT
420-208	DIFFERENTIAL PRESSURE SWITCH
420MV	TURBINE OUTLET TEMPERATURE INDICATOR
421722-8	SEARCHLIGHT
42540-3128	ALTIMETER
427-00154-101	SYNCHRO AMPLIFIER
427-00160-000	SYNCHRO AMPLIFIER
427-301-002-103	LINEAR ACTUATOR
427-366-102-101	TANK UNIT
427-366-103-101	MOTOR DRIVEN VALVE
427-375-005-109	PANEL
427-375-012-101	GRCU
427-375-014-105	PANEL
427-375-015-107	PANEL
427-876-168-101	PANEL
427-876-169-101	PANEL
429-375-005-101	PANEL
429-375-005-105	PANEL
42D107A1	DIFFERENTIAL PRESSURE SWITCH
42D185	GAGE PRESSURE SWITCH
42D208	DIFFERENTIAL PRESSURE SWITCH
42D218	DIFFERENTIAL PRESSURE SWITCH

42D362	DIFFERENTIAL PRESSURE SWITCH
42D394	DIFFERENTIAL PRESSURE SWITCH
42D395	DIFFERENTIAL PRESSURE SWITCH
4300-311	GYRO HORIZON
4300-411	ATTITUDE INDICATOR
4300-412	ATTITUDE INDICATOR
4300-413	ATTITUDE INDICATOR
4300-6980C	ATTITUDE INDICATOR
4300-7975	ATTITUDE INDICATOR
4300-8170-1L	GYRO HORIZON
4300-8220L	GYRO HORIZON
4300-8765-1L	GYRO HORIZON
4300-8765-3L	GYRO HORIZON
4300-8765-IL	ATTITUDE GYRO
4301-3003	ENGINE OIL PRESSURE INDICATOR
4301-3004	TRANSMISSION OIL PRESSURE INDICATOR
430-375-074-113	PANEL
430-375-076-113	PANEL
4305-7150L	DIRECTIONAL GYRO
4305-8175-1L	DIRECTIONAL GYRO
4306-1002	TRANSMISSION OIL PRESSURE INDICATOR
4306-1003	FUEL PRESSURE INDICATOR
4306-1008	ENGINE OIL PRESSURE INDICATOR
4306-1009	TRANSMISSION OIL PRESSURE INDICATOR
4306-1010	FUEL PRESSURE INDICATOR
4306-1011	TRANSMISSION OIL PRESSURE INDICATOR
4306-1012	ENGINE OIL PRESSURE INDICATOR
4306-1013	FUEL PRESSURE INDICATOR
4306-1015	ENGINE OIL PRESSURE INDICATOR
4306-1017	FUEL PRESSURE INDICATOR
4308-1002	TORQUE INDICATOR
4308-1003	TORQUE INDICATOR
4308-1004	TORQUE INDICATOR
4308-1005	TORQUE INDICATOR
4308-1006	TORQUE INDICATOR
4308-1007	TORQUE INDICATOR
4308-1009	TORQUE INDICATOR
4308-1014	TORQUE INDICATOR
4308-1020	TORQUE INDICATOR
4308-1024	TORQUE INDICATOR
4308-1025	TORQUE INDICATOR
4308-1026	TORQUE INDICATOR
4308-1033	TORQUE INDICATOR
4308-1034	TORQUE INDICATOR
4308-1046	TORQUE INDICATOR
4308-1050	TORQUE INDICATOR
4308-1052	TORQUE INDICATOR

4308-1071	TORQUE INDICATOR
4308-3001	TORQUE INDICATOR
4308-3002	TORQUE INDICATOR
4308-3008	TORQUE INDICATOR
4308-3013	TORQUE INDICATOR
4308-3018	TORQUE INDICATOR
4308-3021	TORQUE INDICATOR
4308-3022	TORQUE INDICATOR
4308-3035	TORQUE INDICATOR
4308-3037	TORQUE INDICATOR
4308-3038	TORQUE INDICATOR
4308-3051	TORQUE INDICATOR
4308-3055	TORQUE INDICATOR
4308-3056	TORQUE INDICATOR
4308-3058	TORQUE INDICATOR
4308-3062	TORQUE INDICATOR
4308-3063	TORQUE INDICATOR
4308-3064	TORQUE INDICATOR
4308-3065	TORQUE INDICATOR
4308-3066	TORQUE INDICATOR
4308-3074	TORQUE INDICATOR
4308-3075	TORQUE INDICATOR
4308-3096	TORQUE INDICATOR
4309-2001	TORQUE INDICATOR
4309-3003	TORQUE INDICATOR
4310-3005	TORQUE INDICATOR
4332-3003	FUEL PRESSURE INDICATOR
4332-8005	FUEL PRESSURE INDICATOR
4337-3021	DUAL TORQUE INDICATOR
4344-3113	TORQUE INDICATOR
4351-1103	TORQUE INDICATOR
4351-1107	TORQUE INDICATOR
4351-1109	TORQUE INDICATOR
4351-1112	TORQUE INDICATOR
4351-1203	TORQUE INDICATOR
4351-1205	TORQUE INDICATOR
4351-1207	TORQUE INDICATOR
4351-1209	TORQUE INDICATOR
4351-1212	TORQUE INDICATOR
4351-1214	TORQUE INDICATOR
4351-1215	TORQUE INDICATOR
4351-1303	TORQUE INDICATOR
4351-1307	TORQUE INDICATOR
4351-1309	TORQUE INDICATOR
4351-1312	TORQUE INDICATOR
4351-1403	TORQUE INDICATOR
4351-1407	TORQUE INDICATOR

4351-1409	TORQUE INDICATOR
4351-1412	TORQUE INDICATOR
4351-1413	TORQUE INDICATOR
4355-3001	TORQUE INDICATOR
4355-3010	TORQUE INDICATOR
4355-30-3001	TORQUE INDICATOR
44090-0941-01	AIRSPEED INDICATOR
44090-0941-02	AIRSPEED INDICATOR
44090-1841-01	AIRSPEED INDICATOR
44090-1841-02	AIRSPEED INDICATOR
44090-1941-01	AIRSPEED INDICATOR
44090-1941-02	AIRSPEED INDICATOR
44090-1941-03	AIRSPEED INDICATOR
44090-2941	AIRSPEED INDICATOR
44090-2941-03	AIRSPEED INDICATOR
44090-2941-04	AIRSPEED INDICATOR
44090-2941-05	AIRSPEED INDICATOR
44090-2948	AIRSPEED INDICATOR
44090-2948-01	AIRSPEED INDICATOR
44090-3941-03	AIRSPEED INDICATOR
44090-3941-04	AIRSPEED INDICATOR
44090-AB-M	AIRSPEED INDICATOR
44090-AE-M	AIRSPEED INDICATOR
44090-AF-M	AIRSPEED INDICATOR
44090-AGM	AIRSPEED INDICATOR
44090-AG-M	AIRSPEED INDICATOR
44090-AH-M	AIRSPEED INDICATOR
443147-2	TORQUE INDICATOR
44410-2-24	STROBE LIGHT
446000458-00	VERTICAL SPEED INDICATOR
446001240-00	FUEL QUANTITY INDICATOR
446003533-00	FUEL QUANTITY INDICATOR
446003587-00	FUEL QUANTITY INDICATOR
4460-2	TURN AND SLIP INDICATOR
446-10013	TORQUE INDICATOR
446-10127	TORQUE INDICATOR
446-10135	TORQUE INDICATOR
449-2	POWER SUPPLY
449-2A	POWER SUPPLY
449-2B	POWER SUPPLY
449-2C	POWER SUPPLY
449-2D	POWER SUPPLY
449-3	POWER SUPPLY
449-375-012-103	PANEL
45-0122-1	SEARCHLIGHT
45-0128	SEARCHLIGHT
45-0128-1	SEARCHLIGHT

45-0128-3	SEARCHLIGHT
45-0128-9	SEARCHLIGHT
45-0148-10	LANDING LIGHT
45-0148-3	LANDING LIGHT
45-0148-4	LANDING LIGHT
45-0148-7	LANDING LIGHT
45-0148-8	LANDING LIGHT
45-0148-9	LANDING LIGHT
45-0182-1	SEARCHLIGHT
45-0182-3	SEARCHLIGHT
45-0182-5	SEARCHLIGHT
45-0182-7	SEARCHLIGHT
45-0182-7M	SEARCHLIGHT
45-0182-9	SEARCHLIGHT
45-0339-11	SEARCHLIGHT
45-0339-13	SEARCHLIGHT
45-0339-5	SEARCHLIGHT
45-0339-7	SEARCHLIGHT
45-0339-9	SEARCHLIGHT
450-375-001-101	PANEL
450-375-004-103	PANEL
450-375-011-105	PANEL
452-0115	TRANSMITTER MODULE
4520115S	TRANSMITTER MODULE
453-0422-366	EMERGENCY LOCATOR TRANSMITTER
453-5000	EMERGENCY LOCATOR TRANSMITTER
453-5000-(622)	EMERGENCY LOCATOR TRANSMITTER
453-5000-(999)	EMERGENCY LOCATOR TRANSMITTER
453-5001	EMERGENCY LOCATOR TRANSMITTER
453-5001-(366)	EMERGENCY LOCATOR TRANSMITTER
453-5001-(419)	EMERGENCY LOCATOR TRANSMITTER
453-5001-247	EMERGENCY LOCATOR TRANSMITTER
453-5001-999	EMERGENCY LOCATOR TRANSMITTER
453-5003-(999)	EMERGENCY LOCATOR TRANSMITTER
453TS01Y	LANDING GEAR POSITION INDICATOR
454-00158-000	VERTICAL GYRO
454-00162-000	VERTICAL GYRO
455TS01Y	LANDING GEAR POSITION INDICATOR
457-1	VOLTAGE REGULATOR
458-01400	HYDRAULIC PRESSURE INDICATOR
45D16-1	DIFFERENTIAL PRESSURE SWITCH
45D31-2	DIFFERENTIAL PRESSURE SWITCH
45D32	DIFFERENTIAL PRESSURE SWITCH
45D34	DIFFERENTIAL PRESSURE SWITCH
4619-775-00-13	SLING LOAD INDICATOR
4619-776-00-10	SLING LOAD INDICATOR
4619-777-00-10	SLING LOAD INDICATOR

46700-00	VERTICAL SPEED INDICATOR
46700-01	VERTICAL SPEED INDICATOR
46700-13	VERTICAL SPEED INDICATOR
46700-AB-M	VERTICAL SPEED INDICATOR
4730-01-419-4750	TRANSMITTER MODULE
473-2	VOLTAGE REGULATOR
473203-001	SIGNAL CONDITIONER FUEL SYSTEM
473203-003	FUEL SIGNAL CONDITIONER
473215-001	FUEL SIGNAL CONDITIONER
47-375-013-101	PANEL
475-1	VOLTAGE REGULATOR
475-2	VOLTAGE REGULATOR
47-711-020	AIRSPEED INDICATOR
47-711-021-1	DUAL TACHOMETER INDICATOR
47-711-027-1	TACHOMETER INDICATOR
47-711-027-3	TACHOMETER INDICATOR
47-711-028	AIRSPEED INDICATOR
47-711-030-1	ALTIMETER
480GC01Y02	ELECTRICAL BOX
48313-94066-103	RPM SENSOR
48313-94214A	VOLTAGE REGULATOR
483C01AY	ELECTRICAL MASTER BOX (RH)
483GC01Y	ELECTRICAL MASTER BOX (RH)
48750-00	VERTICAL SPEED INDICATOR
48750-01	VERTICAL SPEED INDICATOR
48750-07	VERTICAL SPEED INDICATOR
48750-11	VERTICAL SPEED INDICATOR
48750-1148	VERTICAL SPEED INDICATOR
48750-1149	VERTICAL SPEED INDICATOR
48845-2	AIRSPEED INDICATOR
490017-1	BLOWER ASSEMBLY
490GC01AY03	ELECTRICAL MASTER BOX LEFT
490GC01Y02	ELECTRICAL BOX
490GC01Y04	LH GENERATOR CONTROL UNIT
490GC01Y06	LH GENERATOR CONTROL UNIT
49200-01	DIFFERENTIAL PRESSURE SWITCH
495269986-00	FUEL PROBE
497-075-015	AIRSPEED INDICATOR
49B10	TEMPERATURE INDICATOR
49B11	TEMPERATURE INDICATOR
49B12	TEMPERATURE INDICATOR
49C4357	GRIP ASSEMBLY
50003-4	ATTITUDE GYRO
5000B-11	GYRO HORIZON
5000B-25	GYRO HORIZON
5000B-28	GYRO HORIZON
5000B-5	GYRO HORIZON

5000E	GYRO HORIZON
5000F	ATTITUDE GYRO
5000F-10	GYRO HORIZON
5000F-11	GYRO HORIZON
5000F-5	GYRO HORIZON
5000F-7	GYRO HORIZON
5000L	ATTITUDE GYRO
5000L-4	ATTITUDE GYRO
5000L-8	ATTITUDE GYRO
5001-3008	OAT GAUGE
5002-1009	TRANSMISSION OIL TEMPERATURE INDICATOR
5002-1010	ENGINE OIL TEMPERATURE INDICATOR
5002-1016	ENGINE OIL TEMPERATURE INDICATOR
5002-1017	TRANSMISSION OIL TEMPERATURE INDICATOR
5002-1020	ENGINE OIL TEMPERATURE INDICATOR
5002-1021	TRANSMISSION OIL TEMPERATURE INDICATOR
5002-3002	ENGINE OIL TEMPERATURE INDICATOR
5002-3003	TRANSMISSION OIL TEMPERATURE INDICATOR
5006-1004	TURBINE OUTLET TEMPERATURE INDICATOR
5006-1031	TURBINE OUTLET TEMPERATURE INDICATOR
5006-1036	TURBINE OUTLET TEMPERATURE INDICATOR
5006-1038	TURBINE OUTLET TEMPERATURE
5006-1039	TURBINE OUTLET TEMPERATURE INDICATOR
5006-1051	TURBINE OUTLET TEMPERATURE INDICATOR
5006-1064	TURBINE OUTLET TEMPERATURE INDICATOR
5006-3011	TURBINE OUTLET TEMPERATURE INDICATOR
5007-155-00-20	NR TRANSMITTER
50099-4-2	AIRSPEED INDICATOR
5010-600-00-10	FAILURE INDICATOR
501-1036-01	ATTITUDE INDICATOR
501-1036-02	ATTITUDE INDICATOR
501-1036-03	ATTITUDE INDICATOR
501-1036-04	ATTITUDE INDICATOR
501-1036-05	ATTITUDE INDICATOR
501-1036-06	ATTITUDE INDICATOR
501-1036-07	ATTITUDE INDICATOR
501-1063-01	ATTITUDE INDICATOR
501-1063-02	ATTITUDE INDICATOR
501-1063-03	ATTITUDE INDICATOR
501-1063-04	ATTITUDE INDICATOR
501-1063-05	ATTITUDE INDICATOR
501-1063-06	ATTITUDE INDICATOR
501-1063-07	ATTITUDE INDICATOR
501-1063-08	ATTITUDE INDICATOR
501-1078-01	ATTITUDE INDICATOR
501-1078-02	ATTITUDE INDICATOR
501-1078-03	ATTITUDE INDICATOR

501-1078-04	ATTITUDE INDICATOR
501-1078-05	ATTITUDE INDICATOR
501-1078-06	ATTITUDE INDICATOR
501-1078-07	ATTITUDE INDICATOR
501-1078-08	ATTITUDE INDICATOR
501-1078-09	ATTITUDE INDICATOR
501-1078-10	ATTITUDE INDICATOR
501-1078-11	ATTITUDE INDICATOR
501-1078-12	ATTITUDE INDICATOR
501-1078-13	ATTITUDE INDICATOR
501-1099-02	ATTITUDE INDICATOR
501-1105-01	ATTITUDE INDICATOR
501-1105-02	ATTITUDE INDICATOR
501-1105-03	ATTITUDE INDICATOR
501-1105-04	ATTITUDE INDICATOR
501-1105-05	ATTITUDE INDICATOR
501-1105-06	ATTITUDE INDICATOR
501-1105-07	ATTITUDE INDICATOR
501-1105-08	ATTITUDE INDICATOR
501-1105-09	ATTITUDE INDICATOR
501-1105-10	ATTITUDE INDICATOR
501-1105-11	ATTITUDE INDICATOR
501-1113-01	DISPLACEMENT GYRO
501-1114-01	DISPLACEMENT GYRO
501-1114-02	VERTICAL GYRO
501-1116-01	DISPLACEMENT GYRO
501-1131-01	ATTITUDE INDICATOR
501-1131-02	ATTITUDE INDICATOR
501-1149-01	DIRECTIONAL GYRO
501-1150-01	DISPLACEMENT GYRO
501-1170-01	ATTITUDE INDICATOR
501-1170-02	ATTITUDE INDICATOR
501-1170-03	ATTITUDE INDICATOR
501-1170-04	ATTITUDE INDICATOR
501-1170-05	ATTITUDE INDICATOR
501-1170-06	ATTITUDE INDICATOR
501-1170-07	ATTITUDE INDICATOR
501-1170-08	ATTITUDE INDICATOR
501-1170-09	ATTITUDE INDICATOR
501-1170-10	ATTITUDE INDICATOR
501-1170-11	ATTITUDE INDICATOR
501-1170-12	ATTITUDE INDICATOR
501-1170-13	ATTITUDE INDICATOR
501-1170-14	ATTITUDE INDICATOR
501-1170-15	ATTITUDE INDICATOR
501-1170-16	ATTITUDE INDICATOR
501-1170-17	ATTITUDE INDICATOR

501-1170-18	ATTITUDE INDICATOR
501-1170-19	ATTITUDE INDICATOR
501-1170-20	ATTITUDE INDICATOR
501-1170-21	ATTITUDE INDICATOR
501-1170-22	ATTITUDE INDICATOR
501-1170-23	ATTITUDE INDICATOR
501-1170-24	ATTITUDE INDICATOR
501-1170-25	ATTITUDE INDICATOR
501-1170-26	ATTITUDE INDICATOR
501-1170-27	ATTITUDE INDICATOR
501-1195-01	ATTITUDE INDICATOR
501-1195-02	ATTITUDE INDICATOR
501-1197-01	ATTITUDE INDICATOR
501-1197-02	ATTITUDE INDICATOR
501-1197-03	ATTITUDE INDICATOR
501-1197-04	ATTITUDE INDICATOR
501-1197-05	ATTITUDE INDICATOR
501-1197-06	ATTITUDE INDICATOR
501-1197-07	ATTITUDE INDICATOR
501-1197-08	ATTITUDE INDICATOR
501-1197-09	ATTITUDE INDICATOR
501-1197-10	ATTITUDE INDICATOR
501-1197-11	ATTITUDE INDICATOR
501-1197-12	ATTITUDE INDICATOR
501-1197-14	ATTITUDE INDICATOR
501-1197-15	ATTITUDE INDICATOR
501-1197-16	ATTITUDE INDICATOR
501-1197-17	ATTITUDE INDICATOR
501-1197-18	ATTITUDE INDICATOR
501-1197-19	ATTITUDE INDICATOR
501-1197-20	ATTITUDE INDICATOR
501-1197-21	ATTITUDE INDICATOR
501-1197-22	ATTITUDE INDICATOR
501-1197-23	ATTITUDE INDICATOR
501-1197-24	ATTITUDE INDICATOR
501-1197-25	ATTITUDE INDICATOR
501-1197-26	ATTITUDE INDICATOR
501-1197-27	ATTITUDE INDICATOR
501-1197-28	ATTITUDE INDICATOR
501-1197-29	ATTITUDE INDICATOR
501-1197-31	ATTITUDE INDICATOR
501-1197-32	ATTITUDE INDICATOR
501-1197-33	ATTITUDE INDICATOR
501-1210-01	VERTICAL GYRO
501-1224-01	GYRO HORIZON
501-1224-02	VERTICAL GYRO
501-1225-01	DISPLACEMENT GYRO

501-1228-01	POWER SUPPLY
501-1228-02	POWER SUPPLY
501-1228-03	POWER SUPPLY
501-1228-04	POWER SUPPLY
501-1228-05	POWER SUPPLY
501-1228-06	POWER SUPPLY
501-1228-07	POWER SUPPLY
501-1255-01	DISPLACEMENT GYRO
501-1277-01	ATTITUDE INDICATOR
501-1278-01	ATTITUDE INDICATOR
501-1278-02	ATTITUDE INDICATOR
501-1295-01	ATTITUDE INDICATOR
501-1296-01	ATTITUDE INDICATOR
501-1296-02	ATTITUDE INDICATOR
501-1296-03	ATTITUDE INDICATOR
501-1296-04	ATTITUDE INDICATOR
501-1296-05	ATTITUDE INDICATOR
501-1296-06	ATTITUDE INDICATOR
501-1296-07	ATTITUDE INDICATOR
501-1296-08	ATTITUDE INDICATOR
501-1296-09	ATTITUDE INDICATOR
501-1297-01	ATTITUDE INDICATOR
501-1412-01	ATTITUDE INDICATOR
501-1412-02	ATTITUDE INDICATOR
501-1412-03	ATTITUDE INDICATOR
501-1412-04	ATTITUDE INDICATOR
501-1412-05	ATTITUDE INDICATOR
501-1412-06	ATTITUDE INDICATOR
501-1412-07	ATTITUDE INDICATOR
501-1453-01	ATTITUDE INDICATOR
501-1455-01	ATTITUDE INDICATOR
501-1492-01	ATTITUDE INDICATOR
501-1492-02	ATTITUDE INDICATOR
501-1617-01	ATTITUDE INDICATOR
501-1648-01	ATTITUDE INDICATOR
501-1648-02	ATTITUDE INDICATOR
501-1664-01	ATTITUDE INDICATOR
501-1665-01	ATTITUDE INDICATOR
501-1709-01	ATTITUDE INDICATOR
501-1748-01	ATTITUDE INDICATOR
501-1753-04	ATTITUDE INDICATOR
501-1798-01	ATTITUDE INDICATOR
501-1811-01	ATTITUDE INDICATOR
501-1812-01	ATTITUDE INDICATOR
501-1813-01	ATTITUDE INDICATOR
501-1818-01	ATTITUDE INDICATOR
501-1828-01	ATTITUDE INDICATOR

501-1838-01	ATTITUDE INDICATOR
501-1844-01	ATTITUDE INDICATOR
501-1845-01	ATTITUDE INDICATOR
501-1848-01	ATTITUDE INDICATOR
501-1849-01	ATTITUDE INDICATOR
501-1850-01	ATTITUDE INDICATOR
501-1874-06	ATTITUDE INDICATOR
501-1874-08	ATTITUDE INDICATOR
501-1874-09	ATTITUDE INDICATOR
501-1874-10	ATTITUDE INDICATOR
5018-105-00-10	OIL PRESSURE PROCESSOR
5018-110-00-10	ENGINE SHUTDOWN DETECTION
5018-111-00-10	ENGINE SHUTDOWN DETECTION
5021-1028	TURBINE OUTLET TEMPERATURE INDICATOR
5021-3001	TURBINE OUTLET TEMPERATURE INDICATOR
5021-3002	TURBINE OUTLET TEMPERATURE INDICATOR
5021-3009	TURBINE OUTLET TEMPERATURE INDICATOR
5021-3030	TURBINE OUTLET TEMPERATURE INDICATOR
5021-3033	TURBINE OUTLET TEMPERATURE INDICATOR
5021-3039	TURBINE OUTLET TEMPERATURE INDICATOR
50234-1	HYDRAULIC PRESSURE TRANSMITTER
5029-3003	TURBINE OUTLET TEMPERATURE INDICATOR
5029-3004	TURBINE OUTLET TEMPERATURE INDICATOR
5029-3014	TURBINE OUTLET TEMPERATURE INDICATOR
502BL3	TEMPERATURE INDICATOR
502BL3B	TEMPERATURE INDICATOR
502BL3E	TEMPERATURE INDICATOR
502BL3G	TEMPERATURE INDICATOR
5032-1017	TURBINE OUTLET TEMPERATURE INDICATOR
5032-1019	TURBINE OUTLET TEMPERATURE INDICATOR
5032-1025	TURBINE OUTLET TEMPERATURE INDICATOR
5032-1051	TURBINE OUTLET TEMPERATURE INDICATOR
5032-1119	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3001	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3016	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3018	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3019	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3020	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3047	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3069	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3073	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3075	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3085	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3091	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3092	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3093	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3096	TURBINE OUTLET TEMPERATURE INDICATOR

5032-3097	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3101	INTER TURBINE TEMPERATURE INDICATOR
5032-3106	TURBINE OUTLET TEMPERATURE INDICATOR
5032-3134	TGT INDICATOR
5032-3144	INTER TURBINE TEMPERATURE INDICATOR
5032-3153	TURBINE OUTLET TEMPERATURE INDICATOR
50-324284	TACHOMETER INDICATOR
50-325285-1	TACHOMETER INDICATOR
5032-8101	INTER TURBINE TEMPERATURE INDICATOR
5035P	ENCODING ALTIMETER
5035P2	ALTIMETER
5035P2-P13	ALTIMETER
5035P2-P26	ALTIMETER
5035P2-P42	ALTIMETER
5035P2-P44	ENCODING ALTIMETER
5035P2-P44 P.44	ENCODING ALTIMETER
5035-P42	ALTIMETER
5035PB-P57	ALTIMETER
5035P-P23	ENCODING ALTIMETER
5035P-P45	ENCODING ALTIMETER
5035P-P46	ALTIMETER
50-380034	TACHOMETER INDICATOR
50-380034-1	TACHOMETER INDICATOR
50-380034-3	TACHOMETER INDICATOR
50-380035	PROPELLER SPEED INDICATOR
50-380035-1	PROPELLER SPEED INDICATOR
50-380035-3	PROPELLER SPEED INDICATOR
50-380035-5	PROPELLER SPEED INDICATOR
50-3800-43-3	TACHOMETER INDICATOR
50-380094-9	ALTIMETER
50-383034-5	TACHOMETER INDICATOR
504-0004-901	TURN AND SLIP INDICATOR
504-0004-902	TURN AND SLIP INDICATOR
504-0004-903	TURN AND SLIP INDICATOR
504-0004-910	TURN AND SLIP INDICATOR
504-0004-911	TURN AND SLIP INDICATOR
504-0006-914	GYRO HORIZON
504-0017-901	GYRO HORIZON
504-0017-903	GYRO HORIZON
504-0017-905	GYRO HORIZON
504-0017-907	GYRO HORIZON
504-0017-908	GYRO HORIZON
504-0017-909	GYRO HORIZON
504-0017-910	GYRO HORIZON
504-0017-911	GYRO HORIZON
504-0017-912	GYRO HORIZON
504-0017-913	GYRO HORIZON

504-0017-914	GYRO HORIZON
504-0017-916	GYRO HORIZON
504-0017-917	GYRO HORIZON
504-0017-918	GYRO HORIZON
504-0017-921	GYRO HORIZON
504-0017-922	GYRO HORIZON
504-0017-923	GYRO HORIZON
504-0017-924	GYRO HORIZON
504-0017-925	GYRO HORIZON
504-0017-926	GYRO HORIZON
504-0017-928	GYRO HORIZON
504-0017-930	GYRO HORIZON
504-0017-931	GYRO HORIZON
504-0017-932	GYRO HORIZON
504-0017-933	GYRO HORIZON
504-0017-934	GYRO HORIZON
504-0024-901	GYRO HORIZON
504-0024-902	GYRO HORIZON
504-0024-903	GYRO HORIZON
504-0024-904	GYRO HORIZON
504-0024-905	GYRO HORIZON
504-0024-906	GYRO HORIZON
504-0027-911	GYRO HORIZON
504-0028-901	GYRO HORIZON
504-0028-902	GYRO HORIZON
504-0028-903	GYRO HORIZON
504-0028-904	GYRO HORIZON
504-0028-905	GYRO HORIZON
504-0028-906	GYRO HORIZON
504-0028-907	GYRO HORIZON
504-0028-908	GYRO HORIZON
504-0028-909	GYRO HORIZON
504-0028-910	GYRO HORIZON
504-0028-911	GYRO HORIZON
504-0028-912	GYRO HORIZON
504-0028-913	GYRO HORIZON
504-0030-909	GYRO HORIZON
504-0030-910	GYRO HORIZON
504-0030-911	GYRO HORIZON
504-0030-912	GYRO HORIZON
504-0030-913	GYRO HORIZON
504-0030-914	GYRO HORIZON
504-0030-915	GYRO HORIZON
504-0030-916	GYRO HORIZON
504-0030-918	GYRO HORIZON
504-0030-919	GYRO HORIZON
504-0030-920	GYRO HORIZON

504-0031-901	GYRO HORIZON
504-0031-902	GYRO HORIZON
504-0031-903	GYRO HORIZON
504-0031-904	GYRO HORIZON
504-0031-906	GYRO HORIZON
504-0031-907	GYRO HORIZON
504-0031-908	GYRO HORIZON
504-0031-909	GYRO HORIZON
504-0031-910	GYRO HORIZON
504-0031-912	GYRO HORIZON
504-0031-913	GYRO HORIZON
504-0031-914	GYRO HORIZON
504-0031-915	GYRO HORIZON
504-0031-916	GYRO HORIZON
504-0031-917	GYRO HORIZON
504-0032-902	GYRO HORIZON
504-0032-904	GYRO HORIZON
504-0032-906	GYRO HORIZON
504-0032-911	GYRO HORIZON
504-0032-912	GYRO HORIZON
504-0032-916	GYRO HORIZON
504-0032-917	GYRO HORIZON
504-0032-932	GYRO HORIZON
504-0033-921	GYRO HORIZON
504-0033-922	GYRO HORIZON
504-0033-923	GYRO HORIZON
504-0033-924	GYRO HORIZON
504-0033-925	GYRO HORIZON
504-0033-926	GYRO HORIZON
504-0033-927	GYRO HORIZON
504-0033-928	GYRO HORIZON
504-0033-929	GYRO HORIZON
504-0033-930	GYRO HORIZON
504-0033-931	GYRO HORIZON
504-0033-932	GYRO HORIZON
504-0033-933	GYRO HORIZON
504-0033-934	GYRO HORIZON
504-0035-901	ATTITUDE INDICATOR
504-0035-902	ATTITUDE INDICATOR
504-0035-903	ATTITUDE INDICATOR
504-0035-904	ATTITUDE INDICATOR
504-0035-905	ATTITUDE INDICATOR
504-0035-906	ATTITUDE INDICATOR
504-0035-907	ATTITUDE INDICATOR
504-0035-908	ATTITUDE INDICATOR
504-0035-909	ATTITUDE INDICATOR
504-0035-910	ATTITUDE INDICATOR

504-0035-911	ATTITUDE INDICATOR
504-0035-912	ATTITUDE INDICATOR
504-0035-913	ATTITUDE INDICATOR
504-0035-914	ATTITUDE INDICATOR
504-0035-915	ATTITUDE INDICATOR
504-0035-916	ATTITUDE INDICATOR
504-0035-917	ATTITUDE INDICATOR
504-0035-918	ATTITUDE INDICATOR
504-0035-921	ATTITUDE INDICATOR
504-0035-922	ATTITUDE INDICATOR
504-0035-923	ATTITUDE INDICATOR
504-0035-924	ATTITUDE INDICATOR
504-0035-925	ATTITUDE INDICATOR
504-0035-926	ATTITUDE INDICATOR
504-0037-901	GYRO HORIZON
504-0037-902	GYRO HORIZON
504-0037-903	GYRO HORIZON
504-0037-904	GYRO HORIZON
504-0038-902	GYRO HORIZON
504-0038-903	GYRO HORIZON
504-0038-904	GYRO HORIZON
504-0038-905	GYRO HORIZON
504-0038-906	GYRO HORIZON
504-0038-907	GYRO HORIZON
504-0038-908	GYRO HORIZON
504-0038-909	GYRO HORIZON
504-0038-910	GYRO HORIZON
504-0038-911	GYRO HORIZON
504-0038-913	GYRO HORIZON
504-0038-914	GYRO HORIZON
504-0040-901	GYRO HORIZON
504-0040-902	GYRO HORIZON
504-0040-903	GYRO HORIZON
504-0040-904	GYRO HORIZON
504-0040-905	GYRO HORIZON
504-0040-906	GYRO HORIZON
504-0040-907	GYRO HORIZON
504-0040-908	GYRO HORIZON
504-0040-909	GYRO HORIZON
504-0040-910	GYRO HORIZON
504-0041-901	GYRO HORIZON
504-0041-902	GYRO HORIZON
504-0042-901	GYRO HORIZON
504-0042-902	GYRO HORIZON
504-0042-903	GYRO HORIZON
504-0042-904	GYRO HORIZON
504-0042-905	GYRO HORIZON

504-0043-901	GYRO HORIZON
504-0044-901	GYRO HORIZON
504-0045-901	GYRO HORIZON
504-0045-902	GYRO HORIZON
504-0045-903	GYRO HORIZON
504-0045-904	GYRO HORIZON
504-0045-914	ATTITUDE GYRO
504-0046-901	GYRO HORIZON
504-0048-901	GYRO HORIZON
504-0048-902	GYRO HORIZON
504-0048-903	GYRO HORIZON
504-0051-901	GYRO HORIZON
504-0052-901	GYRO HORIZON
504-0057-901	GYRO HORIZON
504-0110-901	ATTITUDE INDICATOR
504-0110-902	ATTITUDE INDICATOR
504-0110-903	ATTITUDE INDICATOR
504-0110-904	ATTITUDE INDICATOR
504-0110-906	ATTITUDE INDICATOR
504-0110-907	ATTITUDE INDICATOR
504-0110-908	ATTITUDE INDICATOR
504-0110-909	ATTITUDE INDICATOR
504-0110-910	ATTITUDE INDICATOR
504-0110-911	ATTITUDE INDICATOR
504-0110-912	ATTITUDE INDICATOR
504-0110-913	ATTITUDE INDICATOR
504-0110-914	ATTITUDE INDICATOR
504-0110-915	ATTITUDE INDICATOR
504-0110-916	ATTITUDE INDICATOR
504-0110-917	ATTITUDE INDICATOR
504-0110-918	ATTITUDE INDICATOR
504-0110-919	ATTITUDE INDICATOR
504-0110-920	ATTITUDE INDICATOR
504-0110-921	ATTITUDE INDICATOR
504-0110-922	ATTITUDE INDICATOR
504-0110-923	ATTITUDE INDICATOR
504-0110-924	ATTITUDE INDICATOR
504-0110-925	ATTITUDE INDICATOR
504-0110-926	ATTITUDE INDICATOR
504-0110-927	ATTITUDE INDICATOR
504-0111-901	ATTITUDE INDICATOR
504-0111-902	ATTITUDE INDICATOR
504-0111-903	ATTITUDE INDICATOR
504-0111-904	ATTITUDE INDICATOR
504-0111-905	ATTITUDE INDICATOR
504-0111-906	ATTITUDE INDICATOR
504-0111-907	ATTITUDE INDICATOR

504-0111-908	ATTITUDE INDICATOR
504-0111-909	ATTITUDE INDICATOR
504-0111-910	ATTITUDE INDICATOR
504-0111-911	ATTITUDE INDICATOR
504-0111-912	ATTITUDE INDICATOR
504-0111-913	ATTITUDE INDICATOR
504-0111-914	ATTITUDE INDICATOR
504-0111-915	ATTITUDE INDICATOR
504-0111-916	ATTITUDE INDICATOR
504-0111-917	ATTITUDE INDICATOR
504-0111-918	ATTITUDE INDICATOR
504-0111-919	ATTITUDE INDICATOR
504-0111-920	ATTITUDE INDICATOR
504-0111-921	ATTITUDE INDICATOR
504-0111-922	ATTITUDE INDICATOR
504-0111-923	ATTITUDE INDICATOR
504-0111-924	ATTITUDE INDICATOR
504-0111-925	ATTITUDE INDICATOR
504-0111-926	ATTITUDE INDICATOR
504-0111-927	ATTITUDE INDICATOR
504-0111-928	ATTITUDE INDICATOR
504-0111-929	ATTITUDE INDICATOR
504-0111-930	ATTITUDE GYRO
504-0111-931	ATTITUDE INDICATOR
504-0111-932	ATTITUDE INDICATOR
504-0111-933	ATTITUDE INDICATOR
504-0111-934	GYRO HORIZON
504-0111-935	ATTITUDE INDICATOR
504-0111-936	ATTITUDE INDICATOR
504-0111-937	ATTITUDE INDICATOR
504-0111-938	ATTITUDE INDICATOR
504-0111-939	ATTITUDE INDICATOR
504-0111-940	ATTITUDE INDICATOR
504-0111-941	ATTITUDE INDICATOR
504-0111-942	ATTITUDE INDICATOR
504-0111-943	ATTITUDE INDICATOR
504-0111-944	ATTITUDE INDICATOR
504-0121-901	GYRO HORIZON
504-0121-902	GYRO HORIZON
504-0121-903	GYRO HORIZON
504-0121-904	GYRO HORIZON
504-0121-905	GYRO HORIZON
504-0121-906	GYRO HORIZON
504-0121-907	GYRO HORIZON
504-0121-908	GYRO HORIZON
504-0121-909	GYRO HORIZON
504-0121-910	GYRO HORIZON

504-0121-911	GYRO HORIZON
504-0121-912	GYRO HORIZON
504-0121-913	GYRO HORIZON
504-0121-914	GYRO HORIZON
504-0121-915	GYRO HORIZON
504-0121-916	GYRO HORIZON
504-0121-917	GYRO HORIZON
504-0121-918	GYRO HORIZON
504-0121-919	GYRO HORIZON
504-0121-920	GYRO HORIZON
504-0121-921	GYRO HORIZON
504-0121-923	GYRO HORIZON
504-0121-924	GYRO HORIZON
504-0121-925	GYRO HORIZON
504-0121-927	GYRO HORIZON
504-0121-929	GYRO HORIZON
504-0121-931	GYRO HORIZON
504-0122-901	GYRO HORIZON
504-0122-902	GYRO HORIZON
504-0122-903	GYRO HORIZON
504-0122-904	GYRO HORIZON
504-0122-905	GYRO HORIZON
504-0122-906	GYRO HORIZON
504-0122-907	GYRO HORIZON
504-0122-908	GYRO HORIZON
504-0122-910	GYRO HORIZON
504-0122-911	GYRO HORIZON
504-0122-912	GYRO HORIZON
504-0122-914	GYRO HORIZON
504-0122-915	GYRO HORIZON
504-0122-916	GYRO HORIZON
504-0122-917	GYRO HORIZON
504-0122-918	GYRO HORIZON
504-0122-919	GYRO HORIZON
504-0122-920	GYRO HORIZON
504-0125-901	GYRO HORIZON
504-0126-901	GYRO HORIZON
504-0126-902	GYRO HORIZON
504-0127-901	GYRO HORIZON
504-0127-902	GYRO HORIZON
504-0128-901	GYRO HORIZON
504-0129-901	GYRO HORIZON
504-033-921	ATTITUDE GYRO
504-070-907-102	MOTOR CONVERTER ASSEMBLY
505-0002-904	DIRECTIONAL GYRO
505-0010-901	DIRECTIONAL GYRO
505-0010-902	DIRECTIONAL GYRO

505-0017-904	DIRECTIONAL GYRO
505-0023-907	DIRECTIONAL GYRO
505-0031-901	DIRECTIONAL GYRO
505-0031-902	DIRECTIONAL GYRO
505-0031-903	DIRECTIONAL GYRO
505-0031-904	DIRECTIONAL GYRO
505-0031-905	DIRECTIONAL GYRO
505-0031-906	DIRECTIONAL GYRO
505-0031-907	DIRECTIONAL GYRO
505-0031-909	DIRECTIONAL GYRO
505-0031-910	DIRECTIONAL GYRO
505-0031-911	DIRECTIONAL GYRO
505-0031-912	DIRECTIONAL GYRO
505-0031-916	DIRECTIONAL GYRO
505-0031-926	DIRECTIONAL GYRO
505-0031-927	DIRECTIONAL GYRO
505-0031-928	DIRECTIONAL GYRO
505-0031-929	DIRECTIONAL GYRO
505-0031-930	DIRECTIONAL GYRO
505-0031-SERIES	DIRECTIONAL GYRO
505-0033-925	ATTITUDE GYRO
505-0033-926	ATTITUDE GYRO
505-0033-927	ATTITUDE GYRO
505-0033-928	ATTITUDE GYRO
505-0033-929	ATTITUDE GYRO
505-0033-930	ATTITUDE GYRO
505-0033-931	ATTITUDE GYRO
505-0033-932	ATTITUDE GYRO
505-0033-933	ATTITUDE GYRO
505-0033-934	ATTITUDE GYRO
505-2A	GYRO HORIZON
505-2B	GYRO HORIZON
505-2BG	GYRO HORIZON
505-2BK	GYRO HORIZON
505-2BKS	GYRO HORIZON
505-2BS	GYRO HORIZON
505-2C	GYRO HORIZON
50579-3	HYDRAULIC PRESSURE TRANSMITTER
50629-1	HYDRAULIC PRESSURE TRANSMITTER
507-0020-910	TURN COORDINATOR
509-0001-915	TURN AND SLIP INDICATOR
509-0004-901	TURN AND SLIP INDICATOR
509-0004-902	TURN AND SLIP INDICATOR
509-0004-903	TURN AND SLIP INDICATOR
509-0004-910	TURN AND SLIP INDICATOR
509-0004-911	TURN AND SLIP INDICATOR
50971-2	SIGNAL CONDITIONER

510 SERIES	ATTITUDE GYRO
510-10A	GYRO HORIZON
510-10B	GYRO HORIZON
510-10C	GYRO HORIZON
510-17A	GYRO HORIZON
510-17B	GYRO HORIZON
510-1A	GYRO HORIZON
510-1B	GYRO HORIZON
510-1F	GYRO HORIZON
510-1G	GYRO HORIZON
510-1J	GYRO HORIZON
510-1K	GYRO HORIZON
510-1M	GYRO HORIZON
510-1N	GYRO HORIZON
510-1P	GYRO HORIZON
510-1R	GYRO HORIZON
510-21A/AH	GYRO HORIZON
510-21B/BH	GYRO HORIZON
510-21C/CH	GYRO HORIZON
510-21D/DH	GYRO HORIZON
510-21E/EH	GYRO HORIZON
510-21F	GYRO HORIZON
510-22A/AH	GYRO HORIZON
510-22B/BH	GYRO HORIZON
510-22C/CH	GYRO HORIZON
510-22D/DH	GYRO HORIZON
510-22E/EH	GYRO HORIZON
510-22F/FH	GYRO HORIZON
510-22G/GH	GYRO HORIZON
510-22H/HH	GYRO HORIZON
510-22J	GYRO HORIZON
510-22K	GYRO HORIZON
510-22LH	GYRO HORIZON
510-22M	GYRO HORIZON
510-22N	GYRO HORIZON
510-24J/JH	GYRO HORIZON
510-24K/KH	GYRO HORIZON
510-24L	GYRO HORIZON
510-24L/LH	GYRO HORIZON
510-24L2	GYRO HORIZON
510-24M/MH	GYRO HORIZON
510-24N	GYRO HORIZON
510-24P	GYRO HORIZON
510-24R	GYRO HORIZON
510-24S	GYRO HORIZON
510-24V	GYRO HORIZON
510-24W	GYRO HORIZON

510-25A	GYRO HORIZON
510-27A	GYRO HORIZON
510-27B	GYRO HORIZON
510-27C	GYRO HORIZON
510-27E	GYRO HORIZON
510-27F	GYRO HORIZON
510-27G	GYRO HORIZON
510-27H	GYRO HORIZON
510-27J	GYRO HORIZON
510-27K	GYRO HORIZON
510-27L	GYRO HORIZON
510-27M	GYRO HORIZON
510-27N	ATTITUDE GYRO
510-29A/AH	GYRO HORIZON
510-29B/BH	GYRO HORIZON
510-29C/CH	GYRO HORIZON
510-29D/DH	GYRO HORIZON
510-30B	GYRO HORIZON
510-30BK	GYRO HORIZON
510-30BKW	GYRO HORIZON
510-30BW	GYRO HORIZON
510-30C	GYRO HORIZON
510-30D	GYRO HORIZON
510-30DK	GYRO HORIZON
510-30DKW	GYRO HORIZON
510-30DW	GYRO HORIZON
510-31A	GYRO HORIZON
510-31B	GYRO HORIZON
510-32A	GYRO HORIZON
510-32AK	GYRO HORIZON
510-32B	GYRO HORIZON
510-32BK	GYRO HORIZON
510-33A	GYRO HORIZON
510-34A	GYRO HORIZON
510-35A	GYRO HORIZON
510-35B	GYRO HORIZON
510-35C	GYRO HORIZON
510-35D	GYRO HORIZON
510-36A	GYRO HORIZON
510-37A	GYRO HORIZON
510-37B	GYRO HORIZON
510-37C	GYRO HORIZON
510-39A	GYRO HORIZON
510-3A	GYRO HORIZON
510-40A	GYRO HORIZON
510-41A	ATTITUDE INDICATOR
510-44A	GYRO HORIZON

510-5A	GYRO HORIZON
510-5C	GYRO HORIZON
510-7A	GYRO HORIZON
510-7B	GYRO HORIZON
510-7C	GYRO HORIZON
510-8A	GYRO HORIZON
510-8B	GYRO HORIZON
510-8C	GYRO HORIZON
510-8D	GYRO HORIZON
510-8E	GYRO HORIZON
510-8F	GYRO HORIZON
510-8G	GYRO HORIZON
510-8H	GYRO HORIZON
51-2003	INDICATOR
51-2004	INDICATOR
51-2005	INDICATOR
51-5005	INDICATOR
51509-001	D.C. GENERATOR CONTROL UNIT
51509-001R	D.C. GENERATOR CONTROL UNIT
51509-002	VOLTAGE REGULATOR
51509-002A	VOLTAGE REGULATOR
51509-002B	VOLTAGE REGULATOR
51509-002R	VOLTAGE REGULATOR
51509-200	VOLTAGE REGULATOR
51522-000	D.C. GENERATOR CONTROL UNIT
51522-003	D.C. GENERATOR CONTROL UNIT
51522-005	D.C. GENERATOR CONTROL UNIT
51522-006	D.C. GENERATOR CONTROL UNIT
51522-006A	D.C. GENERATOR CONTROL UNIT
51522-007	D.C. GENERATOR CONTROL UNIT
51530-001	D.C. GENERATOR CONTROL UNIT
51530-001A	D.C. GENERATOR CONTROL UNIT
51530-001D	D.C. GENERATOR CONTROL UNIT
51530-001E	D.C. GENERATOR CONTROL UNIT
51530-001E1	GENERATOR CONTROL UNIT
51530-001EI	D.C. GENERATOR CONTROL UNIT
51530-006	D.C. GENERATOR CONTROL UNIT
51530-006A	GENERATOR CONTROL UNIT
51530-006B	DC GENERATOR CONTROL UNIT
51530-007	GENERATOR CONTROL UNIT
51530-007A	DC GENERATOR CONTROL UNIT
51530-007B	GENERATOR CONTROL UNIT
51530-007D	DC GENERATOR CONTROL UNIT
51530-008	DC GENERATOR CONTROL UNIT
51538-005A	VOLTAGE REGULATOR
51539-002A	GENERATOR CONTROL UNIT
51539-002B	GENERATOR CONTROL UNIT

51539-002M	GENERATOR CONTROL UNIT
51539-002N	D.C. GENERATOR CONTROL UNIT
51565-000	VOLTAGE REGULATOR
51565-000R	VOLTAGE REGULATOR
51565-001	VOLTAGE REGULATOR
51565-001R	VOLTAGE REGULATOR
51576-003	VOLTAGE REGULATOR
51576-003	VOLTAGE REGULATOR
5160-458	LIGHT
518-28007-201	ENCODING ALTIMETER
518-28007-202	ENCODING ALTIMETER
518-28007-203	ENCODING ALTIMETER
518-28007-204	ENCODING ALTIMETER
518-28007-205	ENCODING ALTIMETER
518-28007-206	ENCODING ALTIMETER
518-28007-207	ENCODING ALTIMETER
518-28007-208	ENCODING ALTIMETER
518-28007-209	ENCODING ALTIMETER
518-28007-210	ENCODING ALTIMETER
518-28007-211	ENCODING ALTIMETER
518-28007-212	ENCODING ALTIMETER
518-28007-213	ENCODING ALTIMETER
518-28007-214	ENCODING ALTIMETER
518-28007-215	ENCODING ALTIMETER
518-28007-216	ENCODING ALTIMETER
518-28007-217	ENCODING ALTIMETER
518-28007-218	ENCODING ALTIMETER
518-28007-221	ENCODING ALTIMETER
518-28007-224	ENCODING ALTIMETER
518-28007-227	ENCODING ALTIMETER
518-28007-228	ENCODING ALTIMETER
518-28007-232	ENCODING ALTIMETER
518-28007-427	ENCODING ALTIMETER
518-28007-429	ENCODING ALTIMETER
518-28007-431	ENCODING ALTIMETER
518-28007-433	ENCODING ALTIMETER
518-28007-923	ENCODING ALITMETER
519-22702-501	ENCODING ALTIMETER
519-22702-502	ENCODING ALTIMETER
519-22702-503	ENCODING ALTIMETER
519-22702-511	ENCODING ALTIMETER
519-22702-512	ENCODING ALTIMETER
519-22702-513	ENCODING ALTIMETER
519-22702-531	ENCODING ALTIMETER
519-22702-532	ENCODING ALTIMETER
519-22702-533	ENCODING ALTIMETER
519-22702-541	ENCODING ALTIMETER

519-22702-542	ENCODING ALTIMETER
519-22702-543	ENCODING ALTIMETER
51B2214	CABIN TEMPERATURE INDICATOR
51B2214/1	CABIN TEMPERATURE INDICATOR
51B2232/1	DUCT AIR TEMPERATURE INDICATOR
51B5518	DUAL AMMETER
51B5518/1	DUAL AMMETER
51B5520	DUAL AMMETER
520 7137 011	RMI
520 7137 012	RMI
520 7137 013	RMI
520 7137 014	RMI
520 7137 015	RMI
520 7137 016	RMI
520 7137 017	RMI
520 7137 018	RMI
520 7137 021	RMI
520 7137 022	RMI
520 7137 023	RMI
520 7137 024	RMI
520 7137 025	RMI
520 7137 026	RMI
520 7137 027	RMI
520 7137 028	RMI
5-2000-07	DIRECTIONAL GYRO
520-10B	ATTITUDE INDICATOR
520-11B	ATTITUDE INDICATOR
520-12B	ATTITUDE INDICATOR
520-15B	ATTITUDE INDICATOR
520-16B	ATTITUDE INDICATOR
520-1A	ATTITUDE INDICATOR
520-1AG	ATTITUDE INDICATOR
520-1B	ATTITUDE INDICATOR
520-1BG	ATTITUDE INDICATOR
520-2A	ATTITUDE INDICATOR
520-2AG	ATTITUDE INDICATOR
520-2B	ATTITUDE INDICATOR
520-2BG	ATTITUDE INDICATOR
520-3137-317	RADIO MAGNETIC INDICATOR
520-3A	ATTITUDE INDICATOR
520-3AG	ATTITUDE INDICATOR
520-3B	ATTITUDE INDICATOR
520-3BG	ATTITUDE INDICATOR
520-4210-002	HORIZONTAL SITUATION INDICATOR
520-4A	ATTITUDE INDICATOR
520-4AG	ATTITUDE INDICATOR
520-4B	ATTITUDE INDICATOR

520-4BG	ATTITUDE INDICATOR
5205160 006	COURSE INDICATOR
520-5B	ATTITUDE INDICATOR
520-6B	ATTITUDE INDICATOR
520-7100-001	CONVERTER
520-7100-002	CONVERTER
520-7143-004	RMI
520-9130003	HORIZONTAL SITUATION INDICATOR
520-9130-003	HORIZONTAL SITUATION INDICATOR
5209130-004	HORIZONTAL SITUATION INDICATOR
520-9130-004	HORIZONTAL SITUATION INDICATOR
520-9130007	HORIZONTAL SITUATION INDICATOR
520-9130008	HORIZONTAL SITUATION INDICATOR
520-9130103	HORIZONTAL SITUATION INDICATOR
520-9130104	HORIZONTAL SITUATION INDICATOR
520-9130107	HORIZONTAL SITUATION INDICATOR
520-9130108	HORIZONTAL SITUATION INDICATOR
520-9132003	HORIZONTAL SITUATION INDICATOR
520-9132004	HORIZONTAL SITUATION INDICATOR
520-9132007	HORIZONTAL SITUATION INDICATOR
520-9132008	HORIZONTAL SITUATION INDICATOR
520-9132103	HORIZONTAL SITUATION INDICATOR
520-9132104	HORIZONTAL SITUATION INDICATOR
520-9132107	HORIZONTAL SITUATION INDICATOR
520-9132108	HORIZONTAL SITUATION INDICATOR
520-9135003	HORIZONTAL SITUATION INDICATOR
520-9135004	HORIZONTAL SITUATION INDICATOR
520-9135007	HORIZONTAL SITUATION INDICATOR
520-9135008	HORIZONTAL SITUATION INDICATOR
520-9135103	HORIZONTAL SITUATION INDICATOR
520-9135104	HORIZONTAL SITUATION INDICATOR
520-9135107	HORIZONTAL SITUATION INDICATOR
520-9135108	HORIZONTAL SITUATION INDICATOR
520-9137003	HORIZONTAL SITUATION INDICATOR
5209137-004	HORIZONTAL SITUATION INDICATOR
520-9137004	HORIZONTAL SITUATION INDICATOR
520-9137007	HORIZONTAL SITUATION INDICATOR
520-9137008	HORIZONTAL SITUATION INDICATOR
520-9137103	HORIZONTAL SITUATION INDICATOR
520-9137104	HORIZONTAL SITUATION INDICATOR
520-9137107	HORIZONTAL SITUATION INDICATOR
520-9137108	HORIZONTAL SITUATION INDICATOR
520-9B	ATTITUDE INDICATOR
52441B	HANDGRIP
52D137-1332	HORIZONTAL SITUATION INDICATOR
52D137-1333	HORIZONTAL SITUATION INDICATOR
52D67	ATTITUDE GYRO

5301-6	TORQUE TRANSMITTER
530-34090-402	AIRSPEED INDICATOR
5306-155-00-10	OIL PRESSURE INDICATOR
5306-160-00-11	OIL PRESSURE INDICATOR
5306-161-20-10	OIL PRESSURE INDICATOR
5306-166-00-10	OIL PRESSURE INDICATOR
5306-167-20-10	OIL TEMPERATURE & PRESSURE INDICATOR
5306-167-20-11	OIL PRESSURE INDICATOR
5306-168-00-10	ENGINE OIL PRESSURE INDICATOR
5306-169-20-10	ENGINE OIL PRESSURE INDICATOR
5306-255-00-11	OIL TEMPERATURE INDICATOR
5306-256-00-10	OIL PRESSURE INDICATOR
5306-261-00-11	OIL TEMPERATURE INDICATOR
5306-265-00-10	OIL TEMPERATURE INDICATOR
5306-266-20-10	OIL TEMPERATURE INDICATOR
5306-266-20-11	OIL TEMPERATURE INDICATOR
5306-267-00-10	OIL TEMPERATURE INDICATOR
5306-267-20-10	OIL TEMPERATURE INDICATOR
5306-268-20-10	OIL TEMPERATURE INDICATOR
5309-155-00-11	FUEL PRESSURE INDICATOR
5309-158-00-10	FUEL PRESSURE INDICATOR
5309-159-20-10	FUEL PRESSURE INDICATOR
5309-159-20-11	FUEL PRESSURE INDICATOR
53-19-3	PRESSURE SWITCH
53-39-3	OIL PRESSURE TRANSMITTER
53-40-8	PRESSURE SWITCH
53-51-6	TORQUE TRANSMITTER
53-51-6-1	TORQUE TRANSMITTER
535201-1	LANDING GEAR SELECTOR
53-52-6	TORQUE TRANSMITTER
5400-7295-1	TURN COORDINATOR
5400-7295-2	TURN COORDINATOR
5400-7425-1	TURN COORDINATOR
5400-7425-2	TURN COORDINATOR
540264-2-1	ACTUATOR
54174-10028-1	TRANSDUCER
54174-10028-102	PRESSURE TRANSDUCER
54174-10028-102T	PRESSURE TRANSDUCER
54174-10028-105	PRESSURE TRANSDUCER
5418227-29	AIRSPEED INDICATOR
5448-709-91-11	N1 INDICATOR
548-039	ENCODING ALTIMETER
5501B-S9	ENCODING ALTIMETER
550-34670-101	VERTICAL SPEED INDICATOR
550-34670-102	VERTICAL SPEED INDICATOR
550-34670-201	VERTICAL SPEED INDICATOR
550-34670-202	VERTICAL SPEED INDICATOR

550-34670-601	VERTICAL SPEED INDICATOR
550-34670-602	VERTICAL SPEED INDICATOR
550-34670-A1300	VERTICAL SPEED INDICATOR
550-34670-B1300	VERTICAL SPEED INDICATOR
550-34670-C2300	VERTICAL SPEED INDICATOR
550-519	AIRSPEED INDICATOR
5506-S	ENCODING ALTIMETER
5506-SA	ENCODING ALTIMETER
550-8340N3L	TURN AND SLIP INDICATOR
55103G	SHUT-OFF VALVE
55103GA	SHUT OFF VALVE
5550-8340N1L	TURN AND SLIP INDICATOR
5550-8340N3L	TURN AND SLIP INDICATOR
5550-8340N5L	TURN AND SLIP INDICATOR
5550-8465 N1L	TURN AND SLIP INDICATOR
5550-9235N1L	TURN AND SLIP INDICATOR
5550-9235NIL	TURN AND SLIP INDICATOR
5560-8165N1L	TURN AND BANK INDICATOR
55972-3809357-2	TURBINE OUTLET TEMPERATURE INDICATOR
55D111-001	DIRECTIONAL GYRO
55D111-005	DIRECTIONAL GYRO
55D111-006	DIRECTIONAL GYRO
5617-352-91-11	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
5617-352-91-12	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
5617-353-99-10	OIL TEMPERATURE & PRESSURE INDICATOR
5617-355-91-11	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
5617-357-91-10	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
5617-358-91-10	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
5617-359-80-10	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
56215-2	INTER TURBINE TEMPERATURE INDICATOR
5626-518-00	TEMPERATURE INDICATOR
5626-519-0	TEMPERATURE INDICATOR
5626-522-0	TEMPERATURE INDICATOR
5626-522-00	TEMPERATURE INDICATOR
5626-523-91	TEMPERATURE INDICATOR
5626-524-00-00	TEMPERATURE INDICATOR
5626-524-00-11	TEMPERATURE INDICATOR
5626-525-0	TEMPERATURE INDICATOR
5626-555-00-11	TEMPERATURE INDICATOR
562-974	DC VOLTMETER & LOADMETER
563-031	OIL TEMPERATURE & PRESSURE INDICAT0R
563-032	FUEL PRESSURE INDICATOR
563-060	FUEL PRESSURE INDICATOR
563-061	OIL TEMPERATURE & PRESSURE INDICAT0R
5633.711.80.10	NG TACHOMETER INDICATOR
5633-619-00-10	NG TACHOMETER INDICATOR
5633-619-00-11	NG TACHOMETER INDICATOR

5633-619-00-12	NG TACHOMETER INDICATOR
5633-622-20-10	NG TACHOMETER INDICATOR
5633-622-20-11	NG TACHOMETER INDICATOR
5633-707-80-12	NG SPEED AND LIMIT INDICATOR
5633-710-80-11	NG INDICATOR
5633-711-80-10	NG INDICATOR
5633-712-20-11	NG INDICATOR
5633-713-20-10	NG SPEED AND LIMIT INDICATOR
5633-716-80-10	NG SPEED AND LIMIT INDICATOR
5633-717-20-10	NG SPEED AND LIMIT INDICATOR
5637-551-00-11	T4 TEMPERATURE INDICATOR
5637-551-00-12	T4 TEMPERATURE INDICATOR
5637-553-00-10	T4 TEMPERATURE INDICATOR
5637-553-00-11	T4 TEMPERATURE INDICATOR
5637-554-20-10	T4 TEMPERATURE INDICATOR
5637-554-20-11	T4 TEMPERATURE INDICATOR
5637-560-00-10	T4 TEMPERATURE INDICATOR
5637-562-20-10	T4 TEMPERATURE INDICATOR
5638-710-20-10	NR-NTL INDICATOR
5638-710-20-11	NR-NTL INDICATOR
5638-710-20-12	NR-NTL INDICATOR
56515-2	INTER TURBINE TEMPERATURE INDICATOR
566330-2R	RATE GYRO
5677-752-00-10	TORQUE INDICATOR
5677-752-00-11	TORQUE INDICATOR
5677-752-00-12	TORQUE INDICATOR
5677-753-20-10	TORQUE INDICATOR
5677-753-20-11	TORQUE INDICATOR
5677-753-20-12	TORQUE INDICATOR
5677-763-20-10	TORQUE INDICATOR
5677-771-00-10	TORQUE INDICATOR
5678-710-80-12	NP INDICATOR
5678-711-80-10	NP INDICATOR
5678-713-80-10	NP INDICATOR
5678-715-80-10	PROPELLER SPEED INDICATOR
570-074-080-003	TRANSDUCER-SINGLE ELEMENT
570-074-315-1	THREE AXIS RATE SENSOR
5702-1003	FUEL QUANTITY INDICATOR
5702-1005	FUEL QUANTITY INDICATOR
5702-1007	FUEL QUANTITY INDICATOR
5702-3002	FUEL QUANTITY INDICATOR
570-31400-001	ALTIMETER
570-31400-002	ALTIMETER
570-31400-003	ALTIMETER
570-31400-004	ALTIMETER
570-31400-007	ALTIMETER
570-31400-011	ALTIMETER

570-31400-012	ALTIMETER
570-31400-013	ALTIMETER
570-31400-014	ALTIMETER
570-31400-017	ALTIMETER
5707-3002	FUEL QUANTITY INDICATOR
5707-3007	FUEL QUANTITY INDICATOR
5707-3012	FUEL QUANTITY INDICATOR
5707-3013	FUEL QUANTITY INDICATOR
5707-3025	FUEL QUANTITY INDICATOR
5707-3027	FUEL QUANTITY INDICATOR
5707-3037	FUEL QUANTITY INDICATOR
5707-3061	FUEL QUANTITY INDICATOR
5707-3063	FUEL QUANTITY INDICATOR
571-25005-001	ENCODING ALTIMETER
571-25005-002	ENCODING ALTIMETER
571-25005-011	ENCODING ALTIMETER
571-25005-012	ENCODING ALTIMETER
571-25005-021	ENCODING ALTIMETER
571-25005-022	ENCODING ALTIMETER
571-25005-031	ENCODING ALTIMETER
571-25005-032	ENCODING ALTIMETER
571-25005-041	ENCODING ALTIMETER
571-25005-042	ENCODING ALTIMETER
571-25005-051	ENCODING ALTIMETER
571-25005-052	ENCODING ALTIMETER
571-25005-101	ENCODING ALTIMETER
571-25005-102	ENCODING ALTIMETER
571-25005-111	ENCODING ALTIMETER
571-25005-112	ENCODING ALTIMETER
571-25005-121	ENCODING ALTIMETER
571-25005-122	ENCODING ALTIMETER
571-25005-201	ENCODING ALTIMETER
571-25005-202	ENCODING ALTIMETER
571-25005-211	ENCODING ALTIMETER
571-25005-212	ENCODING ALTIMETER
571-25005-221	ENCODING ALTIMETER
571-25005-222	ENCODING ALTIMETER
571-25005-301	ENCODING ALTIMETER
571-25005-302	ENCODING ALTIMETER
571-25005-311	ENCODING ALTIMETER
571-25005-312	ENCODING ALTIMETER
571-25005-321	ENCODING ALTIMETER
571-25005-322	ENCODING ALTIMETER
571-25005-501	ENCODING ALTIMETER
571-25005-502	ENCODING ALTIMETER
5728H	TURN AND SLIP INDICATOR
5728H1	TURN AND SLIP INDICATOR

5728H100-1	TURN AND SLIP INDICATOR
5728H100-1L	TURN AND SLIP INDICATOR
5728H100-1R	TURN AND SLIP INDICATOR
5728H100-2	TURN AND SLIP INDICATOR
5728H100-2A	TURN AND SLIP INDICATOR
5728H100-2AR	TURN AND SLIP INDICATOR
5728H100-2R	TURN AND SLIP INDICATOR
5728H101-1	TURN AND SLIP INDICATOR
5728H101-1R	TURN AND SLIP INDICATOR
5728H101-2	TURN AND SLIP INDICATOR
5728H101-2R	TURN AND SLIP INDICATOR
5728H102-1	TURN AND SLIP INDICATOR
5728H102-2	TURN AND SLIP INDICATOR
5728H102-2R	TURN AND SLIP INDICATOR
5728H102-R	TURN AND SLIP INDICATOR
5728H110-1	TURN AND SLIP INDICATOR
5728H110-1001	TURN AND SLIP INDICATOR
5728H110-1R	TURN AND SLIP INDICATOR
5728H110-2N	TURN AND SLIP INDICATOR
5728H110-2R	TURN AND SLIP INDICATOR
5728H111-1	TURN AND SLIP INDICATOR
5728H111-1R	TURN AND SLIP INDICATOR
5728H111-2	TURN AND SLIP INDICATOR
5728H111-2R	TURN AND SLIP INDICATOR
5728H112-1	TURN AND SLIP INDICATOR
5728H112-11	TURN AND SLIP INDICATOR
5728H112-1R	TURN AND SLIP INDICATOR
5728H112-2	TURN AND SLIP INDICATOR
5728H112-21	TURN AND SLIP INDICATOR
5728H112-2R	TURN AND SLIP INDICATOR
5728H1DL	TURN AND SLIP INDICATOR
5728H1R	TURN AND SLIP INDICATOR
5728H2	TURN AND SLIP INDICATOR
5728H2-1A	TURN AND SLIP INDICATOR
5728H2-1AR	TURN AND SLIP INDICATOR
5728H2R	TURN AND SLIP INDICATOR
5728N	TURN AND SLIP INDICATOR
5728N1	TURN AND SLIP INDICATOR
5728N100-1	TURN AND SLIP INDICATOR
5728N100-1R	TURN AND SLIP INDICATOR
5728N100-2	TURN AND SLIP INDICATOR
5728N100-2R	TURN AND SLIP INDICATOR
5728N101-1	TURN AND SLIP INDICATOR
5728N101-1R	TURN AND SLIP INDICATOR
5728N101-2	TURN AND SLIP INDICATOR
5728N101-2R	TURN AND SLIP INDICATOR
5728N102-1	TURN AND SLIP INDICATOR

5728N102-1R	TURN AND SLIP INDICATOR
5728N102-2	TURN AND SLIP INDICATOR
5728N102-2R	TURN AND SLIP INDICATOR
5728N110-1	TURN AND SLIP INDICATOR
5728N110-1R	TURN AND SLIP INDICATOR
5728N110-2	TURN AND SLIP INDICATOR
5728N110-2R	TURN AND SLIP INDICATOR
5728N111-1	TURN AND SLIP INDICATOR
5728N111-1R	TURN AND SLIP INDICATOR
5728N111-2	TURN AND SLIP INDICATOR
5728N111-2R	TURN AND SLIP INDICATOR
5728N112-1	TURN AND SLIP INDICATOR
5728N112-1R	TURN AND SLIP INDICATOR
5728N112-2	TURN AND SLIP INDICATOR
5728N112-2R	TURN AND SLIP INDICATOR
5728N1R	TURN AND SLIP INDICATOR
5728N1X	TURN AND SLIP INDICATOR
5728N2	TURN AND SLIP INDICATOR
5728N2R	TURN AND SLIP INDICATOR
574-074-162-001	PANEL
574-074-162-1	PANEL
575-25850	MACH AIRSPEED INDICATOR
5802-1034	AIRSPEED
5802-3060	AIRSPEED
5802-3060D	AIRSPEED
5802-306D	AIRSPEED
5813-700-00-10	NR-NTL INDICATOR
5813-700-00-11	NR-NTL INDICATOR
5813-700-00-12	NR-NTL INDICATOR
5813-701-00-00	NR-NTL INDICATOR
5826-01-020-2258	NAVIGATION RECEIVER
5826-01-039-4148	COURSE INDICATOR
58-30069-3	ALTIMETER
58-380048-1	LOADMETER
58-380048-2	LOADMETER
58-380069-3	ALTIMETER
5876-703-00-10	COPILOT NR INDICATOR
5876-704-20-10	COPILOT NR INDICATOR
5876-704-20-11	COPILOT NR INDICATOR
5876-705-00-10	COPILOT NR INDICATOR
5879-716-80-10	NP INDICATOR
58880-458-01400	HYDRAULIC PRESSURE INDICATOR
5930-14-3670158	FUEL LEVEL SWITCH
5930-14-3670159	FUEL LEVEL SWITCH
5930-14-3670160	FUEL LEVEL SWITCH
5930-14-3819305	FUEL LEVEL SWITCH
5930-14-3819306	FUEL LEVEL SWITCH

5930-14-3819307	FUEL LEVEL SWITCH
5930-14-5754605	FUEL LEVEL SWITCH
5932 A.10	ALTIMETER
5932 A.11	ALTIMETER
5932 A.60	ALTIMETER
5932 A.9	ALTIMETER
5932-BH01	ALTIMETER
5932-BH-1	ALTIMETER
5932-BH-3	ALTIMETER
5932-BH-5	ALTIMETER
5932-BH-7	ALTIMETER
5934 A.68	ALTIMETER
5934-1	ALTIMETER
5934-1 A.89	ALTIMETER
5934-1 A.90	ALTIMETER
5934-1A.91	ALTIMETER
5934-3	ALTIMETER
5934-3A.68	ALTIMETER
5934A.91	ALTIMETER
5934A-1	ALTIMETER
5934A-3	ALTIMETER
5934A-3 A.91	ALTIMETER
5934-A66	ALTIMETER
5934A91	ALTIMETER
5934AD-1	ALTIMETER
5934AD-3	ALTIMETER
5934AM-1	ALTIMETER
5934AM-3	ALTIMETER
5934D-1	ALTIMETER
5934D-1A.159	ALTIMETER
5934D-3	ALTIMETER
5934D-3A.159	ALTIMETER
5934M-1	ALTIMETER
5934M-1 A.116	ALTIMETER
5934M-1 A.92	ALTIMETER
5934M-3	ALTIMETER
5934P-1	ALTIMETER
5934P-3	ALTIMETER
5934P-3 A.194	ALTIMETER
5934P-3A.441	ALTIMETER
5934PA-1	ALTIMETER
5934PA-1-001	ALTIMETER
5934PA-1A.86	ALTIMETER
5934PA-1D	ALTIMETER
5934PA-3	ALTIMETER
5934PA-3A.86	ALTIMETER
5934P-A56	ALTIMETER

5934PAD	ALTIMETER
5934PAD-1	ALTIMETER
5934PAD-1 A 132	ALTIMETER
5934PAD-1A.135	ALTIMETER
5934PAD-3	ALTIMETER
5934PAD-3B	ALTIMETER
5934PAM-1	ALTIMETER
5934PAM-3	ALTIMETER
5934PAM-3A.87	ALTIMETER
5934PD-1	ALTIMETER
5934PD-3	ALTIMETER
5934PM-1	ALTIMETER
5934PM-3	ALTIMETER
59885/2313M-20-3	WIPER MOTOR
59885/2313M-20-4	WIPER MOTOR ASSY
5I-2005	DUCT AIR TEMPERATURE INDICATOR
600-563	CONTROL MOTION TRANSDUCER
600-568	CONTROL MOTION TRANDUCER
600-580	TRANSDUCER
600-581	TRANSDUCER - SINGLE ELEMENT
60-0605	ALTIMETER
60-0608	ALTIMETER
601285-01	QUAD INDICATOR
601285-02	QUAD INDICATOR
601285-03	INSTRUMENT CLUSTER
60-1750	STROBE POWER SUPPLY
6020--01/102/8805	LANDING LIGHT
60-2885-1	POWER SUPPLY
60-3269-1	POWER SUPPLY
60-3269-3	POWER SUPPLY
60-3474-1	STROBE POWER SUPPLY
60-3474-3	STROBE POWER SUPPLY
60-3474-5	POWER SUPPLY
60-3557	POWER SUPPLY, FLASH TUBE
60-3557-1	POWER SUPPLY, FLASH TUBE
60-3844-1	EXIT LIGHT POWER SUPPLY
60-3844-1LB	EXIT LIGHT POWER SUPPLY
60-3844-3	EXIT LIGHT POWER SUPPLY
60-3844-3LB	EXIT LIGHT POWER SUPPLY
605-1	RPM LIMIT DETECTOR
608-10023	DUAL TACHOMETER INDICATOR
608-10024	DUAL TACHOMETER INDICATOR
61000-011	TEMPERATURE INDICATOR
61000-013	TEMPERATURE INDICATOR
61000-014	TEMPERATURE INDICATOR
61000-015	TEMPERATURE INDICATOR
61000-016	TEMPERATURE INDICATOR

61000-018	TEMPERATURE INDICATOR
61000-019	TEMPERATURE INDICATOR
61000-020	TEMPERATURE INDICATOR
61000-021	TEMPERATURE INDICATOR
61000-022	TEMPERATURE INDICATOR
61000-023	TEMPERATURE INDICATOR
61000-025	TEMPERATURE INDICATOR
61000-026	TEMPERATURE INDICATOR
61000-028	TEMPERATURE INDICATOR
61000-029	TEMPERATURE INDICATOR
61000-030	TEMPERATURE INDICATOR
61000-031	TEMPERATURE INDICATOR
61000-032	TEMPERATURE INDICATOR
61000-033	TEMPERATURE INDICATOR
61000-034	TEMPERATURE INDICATOR
61000-035	TEMPERATURE INDICATOR
61000-036	TEMPERATURE INDICATOR
61000-037	TEMPERATURE INDICATOR
61000-038	TEMPERATURE INDICATOR
61000-039	TEMPERATURE INDICATOR
61000-040	TEMPERATURE INDICATOR
61000-041	TEMPERATURE INDICATOR
61000-042	TEMPERATURE INDICATOR
61000-047	TEMPERATURE INDICATOR
61000-051	TEMPERATURE INDICATOR
61000-068	TEMPERATURE INDICATOR
61015-001-4	TORQUE INDICATOR
61015-007-1	DUAL TORQUE INDICATOR
61015-008-1	DUAL TORQUE INDICATOR
6103-1004	ALTIMETER
611-40053	TACHOMETER INDICATOR
61-2008	STROBE POWER SUPPLY
6130-00-014-6184	INVERTER
61349-SR-2AK	TORQUE INDICATOR
61476-402-1	TACHOMETER INDICATOR
61476-403-1	TACHOMETER INDICATOR
617-10029	DUAL TACHOMETER INDICATOR
617-10030	DUAL TACHOMETER INDICATOR
618-12	CLOCK
618-12-24	CLOCK
618-17250	AMMETER
618-24	CLOCK
618-24-100	CLOCK
618T-3	HF TRANSCEIVER
6220-01-253-9658	STROBE LIGHT
6246-00402	FUEL QUANTITY INDICATOR
6246-00610	TEMPERATURE INDICATOR

6340-01-087-2792	SMOKE DETECTOR
640-12	CLOCK
640-24	CLOCK
64050-228-1	AIRSPEED INDICATOR
64130-100-1	ALTIMETER
64130-101-1	ALTIMETER
64130-102-1	ALTIMETER
64130-103-1	ALTIMETER
64140-953-1	ALTIMETER
64140-955-1	ALTIMETER
64140-956-1	ALTIMETER
64140-971-1	ALTIMETER
64152-02215-104	HANDGRIP
64156-02415-104	HANDGRIP
64156-02415-105	HANDGRIP
64251-409-1	PRESSURE TRANSMITTER
64251-409-2	PRESSURE TRANSMITTER
64251-903-1	PRESSURE TRANSMITTER
64251-903-1X	TRANSMITTER
64251-903-2	PRESSURE TRANSMITTER
64279-001-1	PRESSURE TRANSMITTER
64279-001-2	PRESSURE TRANSMITTER
64279-004-1	PRESSURE TRANSMITTER
64279-200-2	PRESSURE TRANSDUCER
64301-030-1	DIFFERENTIAL PRESSURE SWITCH
6445-01	FIRE OVERHEAT CONTROL CARD
64514-201-1	TACHOMETER INDICATOR
64514-202-1	TACHOMETER INDICATOR
64514-203-1	TACHOMETER INDICATOR
64514-205-2	TACHOMETER INDICATOR
64514-208-1	TACHOMETER INDICATOR
64530-068-4	NG INDICATOR
64538-068-1	TACHOMETER INDICATOR
64550-005-1	TACH GENERATOR
64550-007-1	TACH GENERATOR
64550-023-1	TACH GENERATOR
64550-029-1	TACH GENERATOR
64660-025-1	TEMPERATURE PROBE
646768-1	FUEL PUMP
64751-003-2	TRANSMITTER, FUEL QUANTITY
64751-003-3	TRANSMITTER, FUEL QUANTITY
64751-100-1	TRANSMITTER
64751-101-1	TRANSMITTER
64757-100-2	FUEL PROBE
64757-101-2	FUEL PROBE
64760-019-1	FUEL LEVEL SWITCH
64760-021-1	FUEL LEVEL SWITCH

64760-022-1	FUEL LEVEL SWITCH
64760-025-1	FUEL LEVEL SWITCH
64760-026-1	FUEL LEVEL SWITCH
64760-027-1	FUEL LEVEL SWITCH
64760-027-2	FUEL LEVEL SWITCH
64818-000-1	OIL TEMPERATURE INDICATOR
64818-001-1	OIL PRESSURE INDICATOR
64818-009-1	OIL PRESSURE INDICATOR
64818-010-1	OIL PRESSURE INDICATOR
64818-012-1	OIL TEMPERATURE INDICATOR
64818-013-1	OIL PRESSURE INDICATOR
64818-014-1	OIL PRESSURE INDICATOR
64818-015-1	OIL TEMPERATURE INDICATOR
64818-018-1	OIL PRESSURE INDICATOR
64818-019-1	OIL PRESSURE INDICATOR
64818-020-1	OIL TEMPERATURE INDICATOR
64818-300-1	FUEL PRESSURE INDICATOR
64818-303-1	FUEL PRESSURE INDICATOR
64818-307-1	FUEL PRESSURE INDICATOR
64A120	LINEAR ACTUATOR
650-1021-042	HORIZONTAL SITUATION INDICATOR
650-1021-232	HORIZONTAL SITUATION INDICATOR
650-1021-242	HORIZONTAL SITUATION INDICATOR
650-1041-042	HORIZONTAL SITUATION INDICATOR
650-1041-932	HORIZONTAL SITUATION INDICATOR
650-1051-681	HORIZONTAL SITUATION INDICATOR
650-1061-932	HORIZONTAL SITUATION INDICATOR
6501-1001	TACHOMETER INDICATOR
6501-1005	TACHOMETER INDICATOR
6501-1006	TACHOMETER INDICATOR
6501-1010	TACHOMETER INDICATOR
6501-1011	TACHOMETER INDICATOR
650-1101-232	HORIZONTAL SITUATION INDICATOR
6501-1014	TACHOMETER INDICATOR
6501-1018	TACHOMETER INDICATOR
650-1101-932	HORIZONTAL SITUATION INDICATOR
650-1101-942	HORIZONTAL SITUATION INDICATOR
6501-1040	TACHOMETER INDICATOR
6501-1044	TACHOMETER INDICATOR
6501-1047	TACHOMETER INDICATOR
6501-1051	TACHOMETER INDICATOR
6501-1055	TACHOMETER INDICATOR
6501-1056	TACHOMETER INDICATOR
6501-1058	TACHOMETER INDICATOR
6501-1068	TACHOMETER INDICATOR
650-1141-902	HORIZONTAL SITUATION INDICATOR
650-1141-932	HORIZONTAL SITUATION INDICATOR

650-1141-942	HORIZONTAL SITUATION INDICATOR
650-1161-632	HORIZONTAL SITUATION INDICATOR
6501-2004	TACHOMETER INDICATOR
6501-3003	TACHOMETER INDICATOR
6501-3007	TACHOMETER INDICATOR
6501-3008	TACHOMETER INDICATOR
6501-3009	TACHOMETER INDICATOR
6501-3010	TACHOMETER INDICATOR
6501-3018	TACHOMETER INDICATOR
6501-3034	TACHOMETER INDICATOR
6501-3037	TACHOMETER INDICATOR
6501-3054	GAS PRODUCER TACHOMETER INDICATOR
6501-3061	TACHOMETER INDICATOR
6501-3062	TACHOMETER INDICATOR
6501-3089	PERCENT TACHOMETER INDICATOR
6501-3091	TACHOMETER INDICATOR
6501-3135	GAS PRODUCER TACHOMETER INDICATOR
6501-3139	GAS PRODUCER TACHOMETER INDICATOR
6501-3142	TACHOMETER INDICATOR
6501-3146	GAS PRODUCER TACHOMETER INDICATOR
6501-3149	GAS PRODUCER TACHOMETER INDICATOR
6501-8140	TACHOMETER INDICATOR
650-2031-931	HORIZONTAL SITUATION INDICATOR
6502-1001	DUAL TACHOMETER INDICATOR
6502-1002	DUAL TACHOMETER INDICATOR
6502-1006	DUAL TACHOMETER INDICATOR
6502-1007	DUAL TACHOMETER INDICATOR
6502-1008	DUAL TACHOMETER INDICATOR
6502-1009	DUAL TACHOMETER INDICATOR
6502-1011	DUAL TACHOMETER INDICATOR
6502-1013	DUAL TACHOMETER INDICATOR
6502-1014	DUAL TACHOMETER INDICATOR
6502-1019	DUAL TACHOMETER INDICATOR
6502-1024	DUAL TACHOMETER INDICATOR
6502-1032	DUAL TACHOMETER INDICATOR
6502-1033	DUAL TACHOMETER INDICATOR
6502-1034	DUAL TACHOMETER INDICATOR
6502-1038	DUAL TACHOMETER INDICATOR
6502-1041	DUAL TACHOMETER INDICATOR
6502-1048	DUAL TACHOMETER INDICATOR
6502-1053	DUAL TACHOMETER INDICATOR
6502-1055	DUAL TACHOMETER INDICATOR
650-2121-231	HORIZONTAL SITUATION INDICATOR
6502-2004	DUAL TACHOMETER INDICATOR
6502-3003	DUAL TACHOMETER INDICATOR
6502-3010	DUAL TACHOMETER INDICATOR
6502-3031	DUAL TACHOMETER INDICATOR

6502-3044	DUAL TACHOMETER INDICATOR
6502-3045	DUAL TACHOMETER INDICATOR
6502-3046	DUAL TACHOMETER INDICATOR
6502-3061	DUAL TACHOMETER INDICATOR
6503A-1009	GAS PRODUCER TACHOMETER INDICATOR
6503A-1015	GAS PRODUCER TACHOMETER INDICATOR
6503A-1022	GAS PRODUCER TACHOMETER INDICATOR
6503A-1024	GAS PRODUCER TACHOMETER INDICATOR
6503A-1032	GAS PRODUCER TACHOMETER INDICATOR
6503A-1058	GAS PRODUCER TACHOMETER INDICATOR
6503A-1073	GAS PRODUCER TACHOMETER INDICATOR
6503A-1097	GAS PRODUCER TACHOMETER INDICATOR
6503A-3043	GAS PRODUCER TACHOMETER INDICATOR
6503A-3045	GAS PRODUCER TACHOMETER INDICATOR
6503A-3085	GAS PRODUCER TACHOMETER INDICATOR
6503A-3088	GAS PRODUCER TACHOMETER INDICATOR
6503A-3101	GAS PRODUCER TACHOMETER INDICATOR
6503A-3121	GAS PRODUCER TACHOMETER INDICATOR
6503A-3122	GAS PRODUCER TACHOMETER INDICATOR
6503A-3165	GAS PRODUCER TACHOMETER INDICATOR
6503A-3166	GAS PRODUCER TACHOMETER INDICATOR
65041-02415-102P	HANDGRIP
65042-02115-102P	HANDGRIP
6505-3062	TACHOMETER INDICATOR
6505A1008	TRIPLE TACHOMETER INDICATOR
6505A-1008	TRIPLE TACHOMETER INDICATOR
6505A-1028	TRIPLE TACHOMETER INDICATOR
6505A-2023	TRIPLE TACHOMETER INDICATOR
6505A-2031	TRIPLE TACHOMETER INDICATOR
6505A-3027	TRIPLE TACHOMETER INDICATOR
6505A-3042	TRIPLE TACHOMETER INDICATOR
6505A3053	TRIPLE TACHOMETER INDICATOR
6505A-3053	TRIPLE TACHOMETER INDICATOR
6505A-3062	TRIPLE TACHOMETER INDICATOR
6505A-3068	TRIPLE TACHOMETER INDICATOR
65-0647-1	MASTER CAUTION PANEL
65-0647-11	MASTER CAUTION PANEL
65-0647-3	MASTER CAUTION PANEL
65-0647-5	MASTER CAUTION PANEL
65-0647-7	MASTER CAUTION PANEL
65-0647-9	MASTER CAUTION PANEL
65-0648-1	MASTER CAUTION PANEL
65-0700-1	ANNUNCIATOR PANEL
65-0700-3	ANNUNCIATOR PANEL
65-0878-1	ANNUNCIATOR PANEL
65-0878-3	ANNUNCIATOR PANEL
65-0878-7	ANNUNCIATOR PANEL

65-0879-1	ANNUNCIATOR PANEL
65-0879-11	ANNUNCIATOR PANEL
65-0879-3	ANNUNCIATOR PANEL
65-0879-5	ANNUNCIATOR PANEL
65100-019	TORQUE INDICATOR
651-1041-932	HORIZONTAL SITUATION INDICATOR
651-1101-932	HORIZONTAL SITUATION INDICATOR
651-1141-932	HORIZONTAL SITUATION INDICATOR
6520-3011	TRIPLE TACHOMETER INDICATOR
6520-8013	TRIPLE TACHOMETER INDICATOR
6530A SERIES	GAS PRODUCER TACHOMETER INDICATOR
6530A-1009	GAS PRODUCER TACHOMETER INDICATOR
6530A-1015	GAS PRODUCER TACHOMETER INDICATOR
6530A-1022	GAS PRODUCER TACHOMETER INDICATOR
6530A-1024	GAS PRODUCER TACHOMETER INDICATOR
6530A-1058	GAS PRODUCER TACHOMETER INDICATOR
6530A-1073	GAS PRODUCER TACHOMETER INDICATOR
6530A-1097	GAS PRODUCER TACHOMETER INDICATOR
6530A-3043	GAS PRODUCER TACHOMETER INDICATOR
6530A-3045	GAS PRODUCER TACHOMETER INDICATOR
6530A-3085	GAS PRODUCER TACHOMETER INDICATOR
6530A-3101	GAS PRODUCER TACHOMETER INDICATOR
6530A-3121	GAS PRODUCER TACHOMETER INDICATOR
6530A-3122	GAS PRODUCER TACHOMETER INDICATOR
6530A-3165	GAS PRODUCER TACHOMETER INDICATOR
6530A-3166	GAS PRODUCER TACHOMETER INDICATOR
653-2061-931	HORIZONTAL SITUATION INDICATOR
65401-02471-101	HANDGRIP
65412-02215-102	HANDGRIP
65412-02215-103	HANDGRIP
65416-02415-103	GRIP ASSEMBLY
6547-A	TACHOMETER INDICATOR
6547-A-1	TACHOMETER INDICATOR
65-52808-26-01	OVERHEAT ACCESSORY UNIT
65-52808-26-01 R1	OVERHEAT ACCESSORY UNIT
65-52808-3	OVERHEAT ACCESSORY UNIT
65-52808-6	OVERHEAT ACCESSORY UNIT
65-52808-7	OVERHEAT ACCESSORY UNIT
65-52808-7A	OVERHEAT ACCESSORY UNIT
65560-04801-101	HANDGRIP
65560-04900-101	HANDGRIP
65653-05025-103	HANDGRIP
65A120	ACTUATOR
65A149	LINEAR ACTUATOR
65A168	LINEAR ACTUATOR
65A173	ACTUATOR
65A181	LINEAR ACTUATOR

65A192	ACTUATOR
65A237	ACTUATOR
65A238	ACTUATOR
6600355-1	MOTOR DRIVEN VALVE
6601-1004	VERTICAL SPEED INDICATOR
6601-3009	RATE OF CLIMB INDICATOR
66-021-01	TACHOMETER INDICATOR
66-021-03	TACHOMETER INDICATOR
66-021-04	TACHOMETER INDICATOR
66-021-05	TACHOMETER INDICATOR
66-021-07	TACHOMETER INDICATOR
66-022-01	DUAL TACHOMETER INDICATOR
66-022-03	DUAL TACHOMETER INDICATOR
66-022-04	DUAL TACHOMETER INDICATOR
66-022-1	DUAL TACHOMETER INDICATOR
6607-1-90A	PRESSURE SWITCH
6608208-5	ANGLE OF ATTACK INDICATOR
6608217-11	AILERON TRIM INDICATOR
660-8332-1	TACHOMETER INDICATOR
6608401-11	AMMETER
6610-00-089-6950	TURN AND SLIP INDICATOR
6610-00-134-5625	ALTIMETER
6610-00-159-1627	TURN AND SLIP INDICATOR
6610-00-169-1489	TURN AND SLIP INDICATOR
6610-00-526-4397	AIRSPEED INDICATOR
6610-00-557-3030	ATTITUDE INDICATOR
6610-00-903-0714	VERTICAL SPEED INDICATOR
6610-00-912-3613	ATTITUDE INDICATOR
6610-00-952-8832	VERTICAL SPEED INDICATOR
6610-01-029-6702	RATE GYRO TRANSMITTER
6610-01-029-673	VERTICAL SPEED INDICATOR
6610-01-029-7544	ATTITUDE INDICATOR
6610-01-135-2149	ATTITUDE INDICATOR
6610-01-159-0438	TURN AND SLIP INDICATOR
6610-01-163-7061	RATE GYRO TRANSMITTER
6610-01-226-7612	AIRSPEED INDICATOR
6610-012-4624	VERTICAL SPEED INDICATOR
6610-01-568-4933	AIRSPEED INDICATOR
6610-089-6950	TURN AND SLIP INDICATOR
6610-12-140-6782	VERTICAL SPEED INDICATOR
6610-12-141-1331	VERTICAL SPEED INDICATOR
6610-12-144-9338	VERTICAL SPEED INDICATOR
6610-14-268-1620	GYRO HORIZON
66-1037-08	DME INDICATOR
6610-388-0049	ATTITUDE INDICATOR
6610-390-8441	ATTITUDE INDICATOR
6610-526-4717	ATTITUDE INDICATOR

6610-526-6765	ATTITUDE INDICATOR
6610-663-8798	ATTITUDE INDICATOR
6610-663-8800	ATTITUDE INDICATOR
661072-0101	ALTIMETER
6610-810-3245	ALTIMETER
661102B	PHASE ADAPTER
6615-01-031-7270	DISPLACEMENT GYRO
6615-01-134-8914	VERTICAL GYRO
6615-01-187-0548	DISPLACEMENT GYRO
6620-00-179-2254	OIL PRESSURE INDICATOR
6620-00-514-5334	PRESSURE INDICATOR, MULTI PURPOSE
6620-01-025-8229	GAS TEMPERATURE INDICATOR
6620-01-0296705	TACHOMETER INDICATOR
6620-01-029-6705	TACHOMETER INDICATOR
6620-01-0653740	TACHOMETER INDICATOR
6620-01-065-3740	TACHOMETER INDICATOR
6620-01-179-2657	PRESSURE TRANSMITTER
6620-01-301-8222	TORQUE INDICATOR
6620-01-322-7678	TACHOMETER INDICATOR
6620-01-422-3446	TRANSMITTER
6620-020-6096	TURBINE INLET TEMPERATURE INDICATOR
6620-557-3023	TACHOMETER INDICATOR
6620-738-5996	TURBINE INLET TEMPERATURE INDICATOR
6625-00-235-4782	DC VOLTMETER
6625-00-538-9683	AC VOLTMETER
6625-00-544-5899	LOADMETER
6680-00-981-7828	LIQUID OXYGEN INDICATOR
6680-01-056-1779	FUEL QUANTITY INDICATOR
6680-01-081-9181	TACHOMETER INDICATOR
6680-01-291-4271	TOTALIZER FUEL QUANTITY INDICATOR
6685-919-2188	TURBINE INLET TEMPERATURE INDICATOR
67-005-298-00	DUAL INDICATOR
671BK-010	ALTIMETER
671BK-011	ALTIMETER
671BK-03	ALTIMETER
671BK-07	ALTIMETER
671BU-010	ALTIMETER
671CK-010	ALTIMETER
671CK-018	ALTIMETER
671CKL-010	ALTIMETER
671CP-19-017	ALTIMETER
671CPU-015	ALTIMETER
671CU-015	ALTIMETER
671K-03	ALTIMETER
671P-19-017	ALTIMETER
672087-101	HYDRAULIC PRESSURE INDICATOR
672379-103	PRESSURE INDICATOR

67458-1	PANEL
67-542-002-00J	HANDGRIP
67-542-003-00J	HANDGRIP
67A258	ACTUATOR
67A317	STEP ACTUATOR
680-0251-600	MAGNETIC BRAKE
680-2351-1	TURBINE OUTLET TEMPERATURE INDICATOR
684-4022-100	STATIC INVERTER
684-4143-100	STATIC INVERTER
688-100	FIRE WARNING INDICATOR
697749-9	INDICATOR
698611-1	TORQUE INDICATOR
7000466-901	ATTITUDE DIRECTOR INDICATOR
7000466-902	ATTITUDE DIRECTOR INDICATOR
7000466-903	ATTITUDE DIRECTOR INDICATOR
7000466-904	ATTITUDE DIRECTOR INDICATOR
7000466-905	ATTITUDE DIRECTOR INDICATOR
7000466-906	ATTITUDE DIRECTOR INDICATOR
7000466-907	ATTITUDE DIRECTOR INDICATOR
7000466-908	ATTITUDE DIRECTOR INDICATOR
7000466-909	ATTITUDE DIRECTOR INDICATOR
7000466-910	ATTITUDE DIRECTOR INDICATOR
7000466-911	ATTITUDE DIRECTOR INDICATOR
7000466-912	ATTITUDE DIRECTOR INDICATOR
7000466-913	ATTITUDE DIRECTOR INDICATOR
7000466-914	ATTITUDE DIRECTOR INDICATOR
7000466-915	ATTITUDE DIRECTOR INDICATOR
7000466-916	ATTITUDE DIRECTOR INDICATOR
7000466-917	ATTITUDE DIRECTOR INDICATOR
7000466-918	ATTITUDE DIRECTOR INDICATOR
7000466-920	ATTITUDE DIRECTOR INDICATOR
7000466-925	ATTITUDE DIRECTOR INDICATOR
7000466-926	ATTITUDE DIRECTOR INDICATOR
7000466-935	ATTITUDE DIRECTOR INDICATOR
7000466-936	ATTITUDE DIRECTOR INDICATOR
7000466-945	ATTITUDE DIRECTOR INDICATOR
7000466-946	ATTITUDE DIRECTOR INDICATOR
7000466-951	ATTITUDE DIRECTOR INDICATOR
7000466-953	ATTITUDE DIRECTOR INDICATOR
7000466-955	ATTITUDE DIRECTOR INDICATOR
7000466-957	ATTITUDE DIRECTOR INDICATOR
7000466-959	ATTITUDE DIRECTOR INDICATOR
7000466-961	ATTITUDE DIRECTOR INDICATOR
7000466-966	ATTITUDE DIRECTOR INDICATOR
7000466-986	ATTITUDE DIRECTOR INDICATOR
7000469-901	HORIZONTAL SITUATION INDICATOR
7000469-909	HORIZONTAL SITUATION INDICATOR

7000788-105	GYRO HORIZON
7000788-135	GYRO HORIZON
7000788-175	GYRO HORIZON
7000788-191	GYRO HORIZON
7000788-195	GYRO HORIZON
7000839-901	RADIO ALTIMETER INDICATOR
7000839-904	RADIO ALTIMETER INDICATOR
7000839-905	RADIO ALTIMETER INDICATOR
7000850-571	ATTITUDE DIRECTOR INDICATOR
7000850-771	ATTITUDE DIRECTOR INDICATOR
7001182-913	ATTITUDE DIRECTOR INDICATOR
70-0158-1	DIMMER CONTROL
70-0158-5	DIMMER CONTROL
7002353-902	AIR DATA SENSOR
7002353-913	AIR DATA SENSOR
700248-1	LANDING LIGHT
7002493-901	HORIZONTAL SITUATION INDICATOR
7002493-902	HORIZONTAL SITUATION INDICATOR
7002493-903	HORIZONTAL SITUATION INDICATOR
7002493-904	HORIZONTAL SITUATION INDICATOR
7002493-905	HORIZONTAL SITUATION INDICATOR
7002493-906	HORIZONTAL SITUATION INDICATOR
7002493-907	HORIZONTAL SITUATION INDICATOR
7002493-908	HORIZONTAL SITUATION INDICATOR
7002493-909	HORIZONTAL SITUATION INDICATOR
7002493-910	HORIZONTAL SITUATION INDICATOR
7002493-911	HORIZONTAL SITUATION INDICATOR
7002493-912	HORIZONTAL SITUATION INDICATOR
700-2CF	GYRO HORIZON
700348-11	RPM LIMIIT DETECTOR
700348-15	RPM LIMIT DETECTOR
700348-17	RPM LIMIIT DETECTOR
700348-7	RPM LIMIIT DETECTOR
700-3CF	GYRO HORIZON
700-5CF	GYRO HORIZON
7020B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
70250-21014-103	HANDGRIP
70285-01	ANTI-COLLISION LIGHT
70285-06	SEARCHLIGHT
70285-1	STROBE LIGHT
70285-21	STROBE LIGHT
7030 C.27	VERTICAL SPEED INDICATOR
7030 C.27A	VERTICAL SPEED INDICATOR
7030B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
7030C.189	VERTICAL SPEED INDICATOR
704 A45 360 043	AUDIO CONTROL PANEL
704.A.43.230.006	TRIM MOTOR ACTUATOR

70400-01260-102	HANDGRIP
70400-01405-103	HANDGRIP
70400-01405-104	HANDGRIP
70400-21222-044	HANDGRIP
70400-21260-103	HANDGRIP
70400-21405-106	HANDGRIP
70400-21405-107	HANDGRIP
70400-61801-101	HANDGRIP
70400-61801-102	HANDGRIP
70400-61802-101	HANDGRIP
7040B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
70450-21905-101	HANDGRIP
7046-100	TRANSMITTER
704A 47 612 120	N ROTOR INDICATOR
704A.37.721.026	PRESSURE SWITCH
704A.37.721.056	PRESSURE SWITCH
704A.37.721.073	PRESSURE SWITCH
704A_47_612 052	ROTOR INDICATOR
704A37633008	OIL TEMPERATURE INDICATOR
704A37-642-060	PRESSURE TRANSMITTER
704A37-670-009	FLOW TRANSMITTER
704A41110016	HANDGRIP
704A41110030	HANDGRIP
704A41110037	HANDGRIP
704A41110038	HANDGRIP
704A41110040	HANDGRIP
704A41110041	HANDGRIP
704A41110045	HANDGRIP
704A41110053	HANDGRIP
704A41-110-053	GRIP ASSEMBLY
704A41-110-106	GRIP ASSEMBLY
704A46.817.027	BEACON ASSEMBLY
704A46.817.056	BEACON ASSEMBLY
704A46580048	ENGINE WARNING BOX
704A46814049	LIGHT DIMMER
704A46-814-049	LIGHT DIMMER
704A46817027	BEACON ASSEMBLY
704A46817056	BEACON ASSEMBLY
704A46818000	DIMMER LIGHT CARD
704A46-820-034	SEARCHLIGHT
704A46851007	STROBE LIGHT
704A47.270-133	CLUSTER GAUGE
704A47.720.059	ALARM ROTOR
704A47111037	VERTICAL SPEED INDICATOR
704A-47-150-132	GYRO HORIZON
704A47-2701-00	QUAD INDICATOR
704A47-270-101	INSTRUMENT CLUSTER

704A47-270-102	INSTRUMENT CLUSTER
704A47610069	TACHOMETER INDICATOR
704A47610072	NR/NF INDICATOR
704A-47611-014	TACH GENERATOR
704A47612025	GAS PRODUCER TACHOMETER INDICATOR
704A-47-612-025	GAS PRODUCER TACHOMETER INDICATOR
704A47-612-039	TACHOMETER INDICATOR
704A47612042	GAS PRODUCER TACHOMETER INDICATOR
704A-47-612-042	GAS PRODUCER TACHOMETER INDICATOR
704A47-612-044	NG INDICATOR
704A47612052	N ROTOR INDICATOR
704A47-612-052	ROTOR RPM INDICATOR
704A47-612-063	NG INDICATOR
704A47-612-113	NG SPEED AND LIMIT INDICATOR
704A47612120	N/ROTOR INDICATOR
704A-47-612-120	TACHOMETER INDICATOR
704A47616040	TRIPLE TACHOMETER INDICATOR
704A47616045	TRIPLE TACHOMETER INDICATOR
704A47620-019	PRESSURE TRANSMITTER
704A-47-620-019	PRESSURE TRANSMITTER
704A47621082	DUAL TORQUE INDICATOR
704A-47-621-089	DUAL TORQUE INDICATOR
704A47621096	DUAL TORQUE INDICATOR
704A47-621-097	TORQUE INDICATOR
704A47632038	TEMPERATURE INDICATOR
704A47632051	TURBINE OUTLET TEMPERATURE INDICATOR
704A47-632-065	T4 TEMPERATURE INDICATOR
704A47632066	TEMPERATURE T4 INDICATOR
704A47-632-066	TEMPERATURE INDICATOR
704A47-633-045	OIL TEMPERATURE INDICATOR
704A47633047	OIL TEMPERATURE INDICATOR
704A47-640-009	TORQUE TRANSMITTER
704A47-651-012	FUEL QUANTITY TRANSMITTER
704A47720100	ALARM ROTOR
704A47723014	ANNUNCIATOR
704A47723017	ANNUNCIATOR
704R47-612-053	INDICATOR
70550-03101-101	HANDGRIP
7060B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
7060C.46	VERTICAL SPEED INDICATOR
7060L	VERTICAL SPEED INDICATOR
7060L C.179	VERTICAL SPEED INDICATOR
708554-11	PANEL, FAULT-FUNCTION INDICATOR-CAUTION ADVISORY
708554-13	MASTER CAUTION PANEL
708554-5	FAULT FUNCTION PANEL
709K-01	ALTIMETER
71117-1	OIL PRESSURE INDICATOR

7120B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
7125-1	RATE GYRO TRANSMITTER
7125-2	RATE GYRO TRANSMITTER
7130B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
7140B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
7160B	INSTANTANEUOUS VERTICAL SPEED INDICATOR
7160C130	VERTICAL SPEED INDICATOR
716523-2	FUEL QUANTITY INDICATOR
716-523-2	FUEL INDICATOR
716585-1	FUEL QUANTITY INDICATOR
716-585-1	FUEL INDICATOR
716586-1	FUEL QUANTITY INDICATOR
716-586-1	FUEL INDICATOR
716587-1	FUEL QUANTITY INDICATOR
716-587-1	FUEL INDICATOR
716-879	FUEL INDICATOR
716BK-5-046	RATE OF CLIMB INDICATOR
716BK-8-036	RATE OF CLIMB INDICATOR
716BU-4-052	RATE OF CLIMB INDICATOR
716BU-8-036	RATE OF CLIMB INDICATOR
716CU-4-052	RATE OF CLIMB INDICATOR
716U-03	ALTIMETER
7185-15	ACTUATOR
7185-7	ACTUATOR
7200-2	RATE OF CLIMB INDICATOR
7200-3	RATE OF CLIMB INDICATOR
7200-4	RATE OF CLIMB INDICATOR
7201-2	RATE OF CLIMB INDICATOR
7201-3	RATE OF CLIMB INDICATOR
7201-4	RATE OF CLIMB INDICATOR
7210-2	RATE OF CLIMB INDICATOR
7210-3	RATE OF CLIMB INDICATOR
7210-4	RATE OF CLIMB INDICATOR
7211-2	RATE OF CLIMB INDICATOR
7211-3	RATE OF CLIMB INDICATOR
7211-4	RATE OF CLIMB INDICATOR
72914/45-0128	SEARCHLIGHT
72914/45-0128-3	SEARCHLIGHT
73-101-1	FUEL QUANTITY TANK UNIT
73-102-1	FUEL PROBE
73-102-2	FUEL PROBE
73-118-1	FUEL QUANTITY TRANSMITTER
73168/17343-771-310F	DETECTOR
739K-03	AIRSPEED INDICATOR
739U-03	AIRSPEED INDICATOR
73B020-001	DIRECTIONAL GYRO
742287-1-0	FUEL QUANTITY INDICATOR

742288-1-0	FUEL QUANTITY INDICATOR
742289-1-0	FUEL QUANTITY INDICATOR
742290-1-0	FUEL QUANTITY INDICATOR
742366-1-0	FUEL QUANTITY INDICATOR
748-355-2	FUEL QUANTITY TRANSMITTER
748-538	FUEL INDICATOR
748-735	FUEL INDICATOR
748-934-2	INDICATOR
749-416	INDICATOR
75-0285-11	LIGHT ASSEMBLY INDICATOR
75-0285-13	LIGHT ASSEMBLY INDICATOR
75-0285-15	LIGHT ASSEMBLY INDICATOR
75-0285-17	LIGHT ASSEMBLY INDICATOR
75-0285-21	LIGHT ASSEMBLY INDICATOR
75-0286-1	LIGHT ASSEMBLY INDICATOR
75-0286-11	LIGHT ASSEMBLY INDICATOR
75-0286-13	LIGHT ASSEMBLY INDICATOR
75-0286-17	LIGHT ASSEMBLY INDICATOR
75-0286-3	LIGHT ASSEMBLY INDICATOR
75-0286-9	LIGHT ASSEMBLY INDICATOR
75-0363-3	ANNUNCIATOR PANEL
75-0434-5	CAUTION ANNUCIATOR PANEL
7532-175-00-12	DUAL TACHOMETER INDICATOR
756450-02011-104	GRIP ASSEMBLY
7582-175-00-12	DUAL TACHOMETER INDICATOR
7582-175-00-12X	DUAL TACHOMETER INDICATOR
7582-175-00-12XX	DUAL TACHOMETER INDICATOR
758355-2	FUEL LEVEL TRANSMITTER
758-355-2	FUEL PROBE
758IE000	FUEL QUANTITY PROBE
76-1	VERTICAL GYRO
76-2	VERTICAL GYRO
762283-1-0	FUEL QUANTITY TRANSMITTER
76450-00803-101	HANDGRIP
76450-00902-103	DUAL TORQUE INDICATOR
76450-00904-106	PTIT INDICATOR
76450-00908-101	HANDGRIP
76450-01076-101	N1 TACHOMETER INDICATOR
76450-01076-103	TRIPLE TACHOMETER INDICATOR
76450-01076-106	TURBINE TEMPERATURE INDICATOR
76450-01076-110	N1 INDICATOR
76450-01076-111	TEMPERATURE INDICATOR
76450-01078-104	HYDRAULIC PRESSURE INDICATOR
76450-01078-106	DUAL TACHOMETER INDICATOR
76450-01078-112	TRANSMISSION OIL TEMPERATURE INDICATOR
76450-01078-128	PRESSURE TRANSMITTER
76450-01096-108	N1 INDICATOR

76450-02010-103	HANDGRIP
76450-02011-103	HANDGRIP
76450-02011-104	HANDGRIP
76550-01010-101	WINDSHIELD HEATER CONTROL
76550-02005-102	SEARCHLIGHT
76550-09006-105	GENERATOR CONTROL UNIT
76550-09006-106	GENERATOR CONTROL UNIT
76600-02113-103	VERTICAL GYRO
76AT2B	THERMOCOUPLE THERMOMETER INDICATOR
76AT3BN	THERMOCOUPLE THERMOMETER INDICATOR
76AT3C	THERMOCOUPLE THERMOMETER INDICATOR
76B20	THERMOCOUPLE THERMOMETER INDICATOR
76B23	THERMOCOUPLE THERMOMETER INDICATOR
76B2A	THERMOCOUPLE THERMOMETER INDICATOR
76B3	THERMOCOUPLE THERMOMETER INDICATOR
7740-00001	TANK UNIT
7740-00002	TANK UNIT
7740-00005	TANK UNIT
7740-00006	TANK UNIT
7740-00011	TANK UNIT
7740-00012	TANK UNIT
7740-00013	TANK UNIT
7740-000168	TANK UNIT
7740-000169	TANK UNIT
7740-000177	TANK UNIT
7740-000182	TANK UNIT
7740-000183	TANK UNIT
7740-00025	TANK UNIT
7740-00026	TANK UNIT
7740-00027	TANK UNIT
7740-00028	TANK UNIT
7740-00030	TANK UNIT
7740-00037	TANK UNIT
7740-00040	TANK UNIT
7740-00041	TANK UNIT
7740-00046	TANK UNIT
7740-00047	TANK UNIT
7740-00050	TANK UNIT
7740-00051	TANK UNIT
7740-00052	TANK UNIT
7740-00055	TANK UNIT
7740-00056	TANK UNIT
7740-00067	TANK UNIT
7740-00068	TANK UNIT
7740-00069	TANK UNIT
7740-00071	TANK UNIT
7740-00078	TANK UNIT

7740-00079	TANK UNIT
7740-00082	TANK UNIT
7740-00084	TANK UNIT
7740-00087	TANK UNIT
7740-00088	TANK UNIT
7740-00089	TANK UNIT
7740-00091	TANK UNIT
7740-00095	TANK UNIT
7740-00096	TANK UNIT
7740-0010	TANK UNIT
7740-00100	TANK UNIT
7740-00106	TANK UNIT
7740-00107	TANK UNIT
7740-00108	TANK UNIT
7740-00109	TANK UNIT
7740-00114	TANK UNIT
7740-00117	TANK UNIT
7740-00118	TANK UNIT
7740-00121	TANK UNIT
7740-00126	TANK UNIT
7740-00128	TANK UNIT
7740-00134	TANK UNIT
7740-00138	TANK UNIT
7740-00139	TANK UNIT
7740-00147	TANK UNIT
7740-00154	TANK UNIT
7740-00155	TANK UNIT
7740-00157	TANK UNIT
7740-00159	TANK UNIT
7740-00164	TANK UNIT
7740-00167	TANK UNIT
7740-00176	TANK UNIT
7740-00190	TANK UNIT
7740-00194	TANK UNIT
7740-00195	TANK UNIT
7740-00204	TANK UNIT
7740-00205	TANK UNIT
7740-00206	TANK UNIT
7740-00207	TANK UNIT
7740-00210	TANK UNIT
7740-00212	TANK UNIT
7740-00213	TANK UNIT
7740-00214	TANK UNIT
7740-00231	TANK UNIT
7740-00233	TANK UNIT
7740-00234	TANK UNIT
7740-00242	TANK UNIT

7740-00243	TANK UNIT
7740-00247	TANK UNIT
7740-00257	TANK UNIT
7740-00258	TANK UNIT
7740-00259	TANK UNIT
7740-00264	TANK UNIT
7740-00291	TANK UNIT
7740-00292	TANK UNIT
7740-00293	TANK UNIT
7740-00298	TANK UNIT
7740-00302	TANK UNIT
7740-00303	TANK UNIT
7740-00305	TANK UNIT
7740-00309	TANK UNIT
7740-00312	TANK UNIT
7740-00325	TANK UNIT
7740-00326	TANK UNIT
7740-00336	TANK UNIT
7740-00337	TANK UNIT
7740-00344	TANK UNIT
7740-00345	TANK UNIT
7740-00346	TANK UNIT
7740-00362	TANK UNIT
7740-00363	TANK UNIT
7740-00375	TANK UNIT
7740-00381	TANK UNIT
7740-00393	TANK UNIT
7740-00394	TANK UNIT
7740-00403	TANK UNIT
7740-00404	TANK UNIT
7740-00405	TANK UNIT
7740-00408	TANK UNIT
7740-00409	TANK UNIT
7740-00410	TANK UNIT
7740-00411	TANK UNIT
7740-00412	TANK UNIT
7740-00413	TANK UNIT
7740-00414	TANK UNIT
7740-00419	TANK UNIT
7740-00420	TANK UNIT
7740-00435	TANK UNIT
7740-00438	TANK UNIT
7740-00439	TANK UNIT
7740-00443	TANK UNIT
7740-00448	TANK UNIT
7740-00459	TANK UNIT
7740-00466	TANK UNIT

7740-00468	TANK UNIT
7740-00469	TANK UNIT
7740-00480	TANK UNIT
7740-00504	TANK UNIT
7740-00506	TANK UNIT
7740-00514	TANK UNIT
7740-00515	TANK UNIT
7740-00517	TANK UNIT
7740-0108	TANK UNIT
7740-015	TANK UNIT
7740-037	TANK UNIT
7740-106	TANK UNIT
7740-107	TANK UNIT
7740-109	TANK UNIT
7740-114	TANK UNIT
7740-135	TANK UNIT
7740-204	TANK UNIT
7740-205	TANK UNIT
7740-206	TANK UNIT
7740-207	TANK UNIT
7740-40	TANK UNIT
7740-41	TANK UNIT
7740-468	TANK UNIT
7740-469	TANK UNIT
7740-503	TANK UNIT
7740-504	TANK UNIT
7740-59	TANK UNIT
78035-01100	TACHOMETER INDICATOR
78035-01112	TACHOMETER INDICATOR
78035-01113	TACHOMETER INDICATOR
78035-01118	TACHOMETER INDICATOR
78035-0161	TACHOMETER INDICATOR
78035-11119	TACHOMETER INDICATOR
7813-175-00-13	TRIPLE TACHOMETER INDICATOR
7813-175-00-13F	TRIPLE TACHOMETER INDICATOR
7813-175-00-13X	TRIPLE TACHOMETER INDICATOR
7813-175-00-13Y	TRIPLE TACHOMETER INDICATOR
7813-175-00-15	TRIPLE TACHOMETER INDICATOR
7813-177-00-11	TRIPLE TACHOMETER INDICATOR
7813-177-00-12	TRIPLE TACHOMETER INDICATOR
7813-178-20-11	TRIPLE TACHOMETER INDICATOR
7813-178-20-12	TRIPLE TACHOMETER INDICATOR
78200000-01	TRIPLE TACHOMETER INDICATOR
78200000-02	TRIPLE TACHOMETER INDICATOR
78200000-03	TRIPLE TACHOMETER INDICATOR
78200000-04	TRIPLE TACHOMETER INDICATOR
78200000-05	TRIPLE TACHOMETER INDICATOR

78200000-06	TRIPLE TACHOMETER INDICATOR
78200000-07	TRIPLE TACHOMETER INDICATOR
78200000-08	TRIPLE TACHOMETER INDICATOR
78286-76450-00904-106	TURBINE INLET TEMPERATURE INDICATOR
78300000-01	TRIPLE TORQUE INDICATOR
78300000-02	TRIPLE TORQUE INDICATOR
78300000-03	TRIPLE TORQUE INDICATOR
78300000-04	TRIPLE TORQUE INDICATOR
78300000-05	TRIPLE TORQUE INDICATOR
78300000-06	TRIPLE TORQUE INDICATOR
78300000-07	TRIPLE TORQUE INDICATOR
78300000-08	TRIPLE TORQUE INDICATOR
78300000-09	TRIPLE TORQUE INDICATOR
78300000-11	TRIPLE TORQUE INDICATOR
783200000-05	TRIPLE TORQUE INDICATOR
78320000-01	TRIPLE TORQUE INDICATOR
78320000-02	TRIPLE TORQUE INDICATOR
78320000-03	TRIPLE TORQUE INDICATOR
78320000-04	TRIPLE TORQUE INDICATOR
78320000-05	TRIPLE TORQUE INDICATOR
7852-175-00-12	NL DUAL INDICATOR
787-6385-001	COURSE INDICATOR
787-6385-002	COURSE INDICATOR
787-6385-003	COURSE INDICATOR
787-6385-004	COURSE INDICATOR
787-6385-005	COURSE INDICATOR
787-6385-006	COURSE INDICATOR
788664-1	NR/NF INDICATOR
788664-2	NR/NF INDICATOR
788664-3	NR/NF INDICATOR
788998-1-1	NR/NF INDICATOR
792-6356-002	COURSE INDICATOR
792-6356-003	COURSE INDICATOR
792-6356-004	COURSE INDICATOR
794167-1	FUEL PROBE
8.040.051.2	ALTIMETER
8.148.015	GYRO HORIZON
8.148.900-1	GYRO HORIZON
8.148.900-2	GYRO HORIZON
8.148.900-3	GYRO HORIZON
8.148.900-4	GYRO HORIZON
8.249.001	GYRO HORIZON
8.249.006	GYRO HORIZON
8.249.007	GYRO HORIZON
8.249.009	GYRO HORIZON
8.249.050	GYRO HORIZON
8.249.086	GYRO HORIZON

8.249.095	GYRO HORIZON
8000 B 336	AIRSPEED INDICATOR
8000 B.12	AIRSPEED INDICATOR
8000 B.336	AIRSPEED INDICATOR
8000 B.4	AIRSPEED INDICATOR
8000 B.629	AIRSPEED INDICATOR
8000B.336	AIRSPEED INDICATOR
8000B.402	AIRSPEED INDICATOR
8000B.751	AIRSPEED INDICATOR
8000-BH5	AIRSPEED INDICATOR
8000L	AIRSPEED INDICATOR
8000T	AIRSPEED INDICATOR
80-0203	ANNUNCIATOR PANEL
80-0203-15	ANNUNCIATOR PANEL
80-0203-17	ANNUNCIATOR PANEL
80-0203-19	ANNUNCIATOR PANEL
80-0203-23	ANNUNCIATOR PANEL
80-0203-9	ANNUNCIATOR PANEL
80-0295	ANNUNCIATOR CAUTION PANEL
80-0368-1	ANNUNCIATOR CAUTION PANEL
80-0368-11	ANNUNCIATOR CAUTION PANEL
80-0368-21	ANNUNCIATOR CAUTION PANEL
80-0368-23	ANNUNCIATOR CAUTION PANEL
80-0368-3	ANNUNCIATOR CAUTION PANEL
80-0368-5	ANNUNCIATOR CAUTION PANEL
80-0368-7	ANNUNCIATOR CAUTION PANEL
80-0381-3	ANNUNCIATOR CAUTION PANEL
80-0500-1	ANNUNCIATOR CAUTION PANEL
80-0500-15	ANNUNCIATOR CAUTION PANEL
80-0500-17	ANNUNCIATOR CAUTION PANEL
80-0500-3	ANNUNCIATOR CAUTION PANEL
80-0500-35	ANNUNCIATOR CAUTION PANEL
80-0500-37	ANNUNCIATOR CAUTION PANEL
80-0500-9	ANNUNCIATOR CAUTION PANEL
800-5-BATT	CLOCK
80181WB84	TACHOMETER INDICATOR
8025-1 B.701	AIRSPEED INDICATOR
8025-B845	AIRSPEED INDICATOR
80294-2001844204	TRANSMITTER
8030B.448	AIRSPEED INDICATOR
8040B	ENCODING ALTIMETER
8040B-20	ENCODING ALTIMETER
8040B-20LX	ENCODING ALTIMETER
8040B-20MB	ENCODING ALTIMETER
8040B-20MB-LX	ENCODING ALTIMETER
8040B-30	ENCODING ALTIMETER
8040B-30LX	ENCODING ALTIMETER

8040B-30MB	ENCODING ALTIMETER
8040B-30MB-LX	ENCODING ALTIMETER
8040B-35	ENCODING ALTIMETER
8040B-35LX	ENCODING ALTIMETER
8040B-35MB	ENCODING ALTIMETER
8040B-35MB-LX	ENCODING ALTIMETER
8040B-LX	ENCODING ALTIMETER
8040B-MB	ENCODING ALTIMETER
8040B-MB-LX	ENCODING ALTIMETER
8040B-S20LW	ENCODING ALTIMETER
805C0620-05	INDICATOR
8107-101-00-12	PRESSURE SENSOR
8107-105-00-10	PRESSURE SENSOR
8107-122-00-10	OIL PRESSURE TRANSMITTER
8107-126-00-01	FUEL PRESSURE TRANSMITTER
8107-126-00-10	OIL PRESSURE TRANSMITTER
8107-133-00-10	OIL PRESSURE TRANSMITTER
8107-140-00-10	ENGINE SHUTDOWN DETECTION
81-0970-3	LIGHTING PANEL
81-101-3	FUEL QUANTITY INDICATOR
81-101-5	FUEL QUANTITY INDICATOR
8114-101-00-10	PRESSURE SENSOR
811B	CLOCK
8140B-20MB	ENCODING ALTIMETER
8140B-20MB-LX	ENCODING ALTIMITER
8140B-30MB	ENCODING ALTIMITER
8140B-30MB-LX	ENCODING ALTIMITER
8140B-35MB	ENCODING ALTIMITER
8140B-35MB-LX	ENCODING ALTIMITER
8140B-S20LW	ENCODING ALTIMETER
8140B-S20-LW-MB	ENCODING ALTIMETER
8141B	ENCODING ALTIMETER
8141B-LX	ENCODING ALTIMETER
8141B-MB	ENCODING ALTIMETER
8141B-MB-LX	ENCODING ALTIMETER
8142B	ENCODING ALTIMETER
8142B-LX	ENCODING ALTIMETER
8142B-MB	ENCODING ALTIMETER
8142B-MB-LX	ENCODING ALTIMETER
8148.900-1	GYRO HORIZON
8148.900-15	GYRO HORIZON
8148.900-2	GYRO HORIZON
8148.900-3	GYRO HORIZON
8148.900-4	GYRO HORIZON
82000-05602	ANNUNCIATOR PANEL
82000-05603	ANNUNCIATOR PANEL
82000-05604	ANNUNCIATOR PANEL

82000-05605	ANNUNCIATOR PANEL
82000-05606	ANNUNCIATOR PANEL
82000-05607	ANNUNCIATOR PANEL
820-264	INDICATOR
820-602	ANGLE OF ATTACK INDICATOR
820-615	INDICATOR
820-616	INDICATOR
820-617	INDICATOR
820-619	INDICATOR
820-620	INDICATOR
820-621	INDICATOR
820-622	INDICATOR
820-623	INDICATOR
820-642	INDICATOR
820-643	INDICATOR
820-644	INDICATOR
820-645	INDICATOR
820-646	INDICATOR
820-647	INDICATOR
820-658	INDICATOR
820-659	INDICATOR
820-662	AMMETER
820-663	INDICATOR
820-665	INDICATOR
820-666	INDICATOR
820-672	INDICATOR
820-675	INDICATOR
820-676	INDICATOR
820-679	INDICATOR
820-685	INDICATOR
820-688	INDICATOR
820-689	INDICATOR
820-696	INDICATOR
820-717	INDICATOR
82100000-01	DUAL TORQUE INDICATOR
82100000-02	DUAL TORQUE INDICATOR
82300000-01	TRIPLE TACHOMETER INDICATOR
82300000-02	TRIPLE TACHOMETER INDICATOR
82300000-03	TRIPLE TACHOMETER INDICATOR
82300000-04	TRIPLE TACHOMETER INDICATOR
82300000-06	TRIPLE TACHOMETER INDICATOR
8-240-02	PROXIMITY SWITCH
8-240-02A	PROXIMITY SWITCH
8-240-04	PROXIMITY SWITCH
8-240-04A	PROXIMITY SWITCH
8-240-06	PROXIMITY SWITCH
8-240-08	PROXIMITY SWITCH

8-240-12	PROXIMITY SWITCH
8-240-34	PROXIMITY SWITCH
8-240-37	PROXIMITY SWITCH
8-240-38	PROXIMITY SWITCH
82410162-007	EMERGENCY LIGHTS CONTROL
826A16-4	SHUT-OFF VALVE
83000-00401	LIGHT CONTROL UNIT
83000-00402	LIGHT CONTROL UNIT
83000-00501	LIGHT CONTROL UNIT
83000-00502	LIGHT CONTROL UNIT
83000-01401	EMERGENCY LIGHTS PWS
83000-01402	EMERGENCY LIGHTS PWS
83000-03201	POWER SUPPLY
830-266	INDICATOR
83-104-1	FUEL QUANTITY INDICATOR
8312-109-00-10	OIL TEMPERATURE TRANSMITTER
833-00157	RELAY
834-1	AUDIO AMPLIFIER
8-405-02	PROXIMITY SWITCH
8-405-04	PROXIMITY SWITCH
8-405-06	PROXIMITY SWITCH
8-405-08	PROXIMITY SWITCH
8-405-12	PROXIMITY SWITCH
8-405-34	PROXIMITY SWITCH
8-405-36	PROXIMITY SWITCH
8-405-44	PROXIMITY SWITCH
8-405-46	PROXIMITY SWITCH
843-67-1	VERTICAL SPEED INDICATOR
843-67-1A	VERTICAL SPEED INDICATOR
843-67-2	VERTICAL SPEED INDICATOR
843-67-2A	VERTICAL SPEED INDICATOR
843-67-3	VERTICAL SPEED INDICATOR
843-67-3R	VERTICAL SPEED INDICATOR
843-67-6	VERTICAL SPEED INDICATOR
843-67-6-R	VERTICAL SPEED INDICATOR
850083-507	DUAL TACHOMETER INDICATOR
85-02-205-1	BLOWER ASSEMBLY
85-02-205-2	BLOWER ASSEMBLY
850275-507	TACHOMETER INDICATOR
850275-509	TACHOMETER INDICATOR
8503-S20LW	ALTIMETER
850610-1	DC VOLTMETER
850611-501	DC AMMETER
8518T71	TACHOMETER INDICATOR
85374/277700	ATTITUDE INDICATOR
8555M1	LANDING LIGHT
8555M2	LANDING LIGHT

8555M3	LANDING LIGHT
8555M4	LANDING LIGHT
8555M5	LANDING LIGHT
8555M6	LANDING LIGHT
8555M7	LANDING LIGHT
8555M9	LANDING LIGHT
8595-03	VERTICAL GYRO
86000-1107	CLOCK
86000-2104	CLOCK
8610-101-00	FUEL QUANTITY TRANSMITTER
8611-101-00	FUEL QUANTITY TRANSMITTER
861260-01	DOUBLE-CHECK VALVE
861C010101	SLAVED VALVE
861C010102	SLAVED VALVE
86200000-01	HORIZONTAL SITUATION INDICATOR
86400-1163	CLOCK
86400-1168	CLOCK
86400-3162	CLOCK
86425-4	FUEL PRESSURE INDICATOR
87000-1105	CLOCK
87000-1106	CLOCK
87000-1111	CLOCK
87000-1115	CLOCK
87000-1120	CLOCK
8700-1111	CLOCK
87232009-1	TEMPERATURE PROBE
87232009-2	TEMPERATURE PROBE
87500-1130	CLOCK
87500-1132	CLOCK
87500-1133	CLOCK
87500-1134	CLOCK
87500-1135	CLOCK
87500-1136	CLOCK
87500-1137	CLOCK
87500-1138	CLOCK
87500-1139	CLOCK
87500-1140	CLOCK
87500-1141	CLOCK
87500-1142	CLOCK
87500-1144	CLOCK
87500-1145	CLOCK
87500-1146	CLOCK
87500-2131	CLOCK
8800-T	ALTITUDE INDICATOR
8820-694	INDICATOR
8930-112B90H101	SMOKE DETECTOR
89513-91D74-1	SERVO CONTROL

895TS05NY	SWITCH CONTROL LANDING GEAR
897331-1	PRESSURE SWITCH
897331-2	PRESSURE SWITCH
897331-3	PRESSURE SWITCH
897331-4	PRESSURE SWITCH
897331-5	PRESSURE SWITCH
89944-B4515210002	ALTIMETER
8CDJ81WDG4	TACHOMETER INDICATOR
8D1274	GAGE PRESSURE SWITCH
8D1494	DIFFERENTIAL PRESSURE SWITCH
8D1495	DIFFERENTIAL PRESSURE SWITCH
8D1496	DIFFERENTIAL PRESSURE SWITCH
8DJ100WAA1	TEMPERATURE INDICATOR
8DJ100WAA2	TEMPERATURE INDICATOR
8DJ1201-VAA	DUAL TACHOMETER INDICATOR
8DJ1201-WAA	DUAL TACHOMETER INDICATOR
8DJ120AAH1	DUAL TACHOMETER INDICATOR
8DJ120AAP1	DUAL TACHOMETER INDICATOR
8DJ120AAP-1	TACHOMETER INDICATOR
8DJ120WAA	TACHOMETER INDICATOR
8DJ120WAA1	DUAL TACHOMETER INDICATOR
8DJ12AAP-1	DUAL TACHOMETER INDICATOR
8DJ131AAB	TRIPLE TACHOMETER INDICATOR
8DJ131AAB1	TRIPLE TACHOMETER INDICATOR
8DJ131AAG SUB 1	TRIPLE TACHOMETER INDICATOR
8DJ131AAG1	TRIPLE TACHOMETER INDICATOR
8DJ131AAG2	TRIPLE TACHOMETER INDICATOR
8DJ131AAJ	TRIPLE TACHOMETER INDICATOR
8DJ131AAJ1	TRIPLE TACHOMETER INDICATOR
8DJ131AAT2	TRIPLE TACHOMETER INDICATOR
8DJ131LAE1	TRIPLE TACHOMETER INDICATOR
8DJ131LAE-1	TRIPLE TACHOMETER INDICATOR
8DJ131LAF2	TRIPLE TACHOMETER INDICATOR
8DJ131LAN1	TRIPLE TACHOMETER INDICATOR
8DJ131LAN-1	TRIPLE TACHOMETER INDICATOR
8DJ131LAV	TRIPLE TACHOMETER INDICATOR
8DJ131LAV1	TRIPLE TACHOMETER INDICATOR
8DJ131LAW	TRIPLE TACHOMETER INDICATOR
8DJ131LAW1	TRIPLE TACHOMETER INDICATOR
8DJ131LAZ1	TRIPLE TACHOMETER INDICATOR
8DJ131LBA	TRIPLE TACHOMETER INDICATOR
8DJ131LBA1	TRIPLE TACHOMETER INDICATOR
8DJ131LBK2	TRIPLE TACHOMETER INDICATOR
8DJ131LBT2	TRIPLE TACHOMETER INDICATOR
8DJ13AAA	TACHOMETER INDICATOR
8DJ13AAT	TACHOMETER INDICATOR
8DJ13ABK	TACHOMETER INDICATOR

8DJ13ACX	TACHOMETER INDICATOR
8DJ13ADL	TACHOMETER INDICATOR
8DJ13ADX	TACHOMETER INDICATOR
8DJ13AEL	TACHOMETER INDICATOR
8DJ13AGT	TACHOMETER INDICATOR
8DJ142LAX3	FUEL FLOW INDICATOR
8DJ148AA1	TACHOMETER INDICATOR
8DJ148CAB1	TACHOMETER INDICATOR
8DJ148CAC1	TACHOMETER INDICATOR
8DJ148CAD1	DUAL TACHOMETER INDICATOR
8DJ148WAA1	TACHOMETER INDICATOR
8DJ148WAC2	TACHOMETER INDICATOR
8DJ148WAC3	TACHOMETER INDICATOR
8DJ148WAD2	TACHOMETER INDICATOR
8DJ148WAD3	TACHOMETER INDICATOR
8DJ148WAF1	DUAL TACHOMETER INDICATOR
8DJ148WAF-1	TACHOMETER INDICATOR
8DJ148WAFA-1	TACHOMETER INDICATOR
8DJ150FAD-1	DUAL TACHOMETER INDICATOR
8DJ150FAE1	DUAL TACHOMETER INDICATOR
8DJ150FAK1	DUAL TACHOMETER INDICATOR
8DJ150LAC1	TACHOMETER INDICATOR
8DJ150LAD1	DUAL TACHOMETER INDICATOR
8DJ150LAE1	TACHOMETER INDICATOR
8DJ150WAA1	DUAL TACHOMETER INDICATOR
8DJ150WAC1	DUAL TACHOMETER INDICATOR
8DJ150WAD1	DUAL TACHOMETER INDICATOR
8DJ150WAE1	DUAL TACHOMETER INDICATOR
8DJ150WAF1	DUAL TACHOMETER INDICATOR
8DJ150WAG1	DUAL TACHOMETER INDICATOR
8DJ150WAH1	DUAL TACHOMETER INDICATOR
8DJ15AAC	TACHOMETER INDICATOR
8DJ15AAF	TACHOMETER INDICATOR
8DJ162LYB2	PROPELLER SPEED INDICATOR
8DJ162LZC2	PROPELLER SPEED INDICATOR
8DJ162LZZ2	PROPELLER SPEED INDICATOR
8DJ163LWT2	GAS TEMPERATURE INDICATOR
8DJ163LWV2	GAS TEMPERATURE INDICATOR
8DJ163LWY2	GAS TEMPERATURE INDICATOR
8DJ163LWZ2	GAS TEMPERATURE INDICATOR
8DJ163LXA4	GAS TEMPERATURE INDICATOR
8DJ163LXB2	GAS TEMPERATURE INDICATOR
8DJ163LXC2	GAS TEMPERATURE INDICATOR
8DJ163LXC3	GAS TEMPERATURE INDICATOR
8DJ163LXD2	GAS TEMPERATURE INDICATOR
8DJ163LXD3	GAS TEMPERATURE INDICATOR
8DJ163LXD4	GAS TEMPERATURE INDICATOR

8DJ163LXE2	GAS TEMPERATURE INDICATOR
8DJ163LXE3	GAS TEMPERATURE INDICATOR
8DJ163LXE4	GAS TEMPERATURE INDICATOR
8DJ163LXF2	GAS TEMPERATURE INDICATOR
8DJ163LXF3	GAS TEMPERATURE INDICATOR
8DJ163LXF4	GAS TEMPERATURE INDICATOR
8DJ163LXH4	GAS TEMPERATURE INDICATOR
8DJ163LXK4	GAS TEMPERATURE INDICATOR
8DJ163LXM4	GAS TEMPERATURE INDICATOR
8DJ163LXP4	GAS TEMPERATURE INDICATOR
8DJ163LXR4	GAS TEMPERATURE INDICATOR
8DJ163LXY4	GAS TEMPERATURE INDICATOR
8DJ163LXZ4	GAS TEMPERATURE INDICATOR
8DJ163LYA4	GAS TEMPERATURE INDICATOR
8DJ163LYC4	GAS TEMPERATURE INDICATOR
8DJ163LYD4	GAS TEMPERATURE INDICATOR
8DJ163LYH4	GAS TEMPERATURE INDICATOR
8DJ163LYK4	GAS TEMPERATURE INDICATOR
8DJ163LYL4	GAS TEMPERATURE INDICATOR
8DJ163LYM4	GAS TEMPERATURE INDICATOR
8DJ163LYN4	GAS TEMPERATURE INDICATOR
8DJ163LYP4	GAS TEMPERATURE INDICATOR
8DJ163LYR4	GAS TEMPERATURE INDICATOR
8DJ163LYS4	GAS TEMPERATURE INDICATOR
8DJ163LYT4	GAS TEMPERATURE INDICATOR
8DJ163LYV4	GAS TEMPERATURE INDICATOR
8DJ163LYW4	GAS TEMPERATURE INDICATOR
8DJ163LYX4	GAS TEMPERATURE INDICATOR
8DJ163LYY4	GAS TEMPERATURE INDICATOR
8DJ163LYZ4	GAS TEMPERATURE INDICATOR
8DJ163LZB4	GAS TEMPERATURE INDICATOR
8DJ163LZC4	GAS TEMPERATURE INDICATOR
8DJ163LZD4	GAS TEMPERATURE INDICATOR
8DJ167FCA-1	DUAL TACHOMETER INDICATOR
8DJ167FCM-1	DUAL TACHOMETER INDICATOR
8DJ167FCW-1	DUAL TACHOMETER INDICATOR
8DJ173LWA1	OIL QUANTITY INDICATOR
8DJ173LWC1	OIL QUANTITY INDICATOR
8DJ173LWD1	OIL QUANTITY INDICATOR
8DJ173LWE1	OIL QUANTITY INDICATOR
8DJ176FAB-1	TACHOMETER INDICATOR
8DJ176LWX1	ENGINE SPEED INDICATOR
8DJ176LWY1	ENGINE SPEED INDICATOR
8DJ176LZB1	ENGINE SPEED INDICATOR
8DJ176LZC1	ENGINE SPEED INDICATOR
8DJ176LZP1	ENGINE SPEED INDICATOR
8DJ176LZR1	ENGINE SPEED INDICATOR

8DJ176LZY1	ENGINE SPEED INDICATOR
8DJ176LZZ1	ENGINE SPEED INDICATOR
8DJ176WAD1	ENGINE SPEED INDICATOR
8DJ176WAE1	ENGINE SPEED INDICATOR
8DJ176WAV1	ENGINE SPEED INDICATOR
8DJ176WBH1	ENGINE SPEED INDICATOR
8DJ176WBN1	ENGINE SPEED INDICATOR
8DJ176WBP1	ENGINE SPEED INDICATOR
8DJ177LWN1	TEMPERATURE INDICATOR
8DJ177LWP1	TEMPERATURE INDICATOR
8DJ177LWR1	TEMPERATURE INDICATOR
8DJ177LWS1	TEMPERATURE INDICATOR
8DJ177LWV1	TEMPERATURE INDICATOR
8DJ177LWW1	TEMPERATURE INDICATOR
8DJ177LWX1	TEMPERATURE INDICATOR
8DJ179KAA2	TEMPERATURE INDICATOR
8DJ179LAD4	TACHOMETER INDICATOR
8DJ179WAD1	TACHOMETER INDICATOR
8DJ179WAD4	TACHOMETER INDICATOR
8DJ181LAA-2	TACHOMETER INDICATOR
8DJ181LAA-4	TACHOMETER INDICATOR
8DJ181LCP4	TACHOMETER INDICATOR
8DJ181LCR4	TACHOMETER INDICATOR
8DJ181LVA-4	TACHOMETER INDICATOR
8DJ181LVG4	TACHOMETER INDICATOR
8DJ181LVH4	TACHOMETER INDICATOR
8DJ19AAH	TACHOMETER INDICATOR
8DJ19AAY	TACHOMETER INDICATOR
8DJ19ABR	TACHOMETER INDICATOR
8DJ19ACV	TACHOMETER INDICATOR
8DJ19ADH	TACHOMETER INDICATOR
8DJ19ADK	TACHOMETER INDICATOR
8DJ19ADV	TACHOMETER INDICATOR
8DJ26AAA1	WHEELS & FLAPS POSITION INDICATOR
8DJ26AAA2	WHEELS & FLAPS POSITION INDICATOR
8DJ26AAA50	WHEELS & FLAPS POSITION INDICATOR
8DJ26AAA51	WHEELS & FLAPS POSITION INDICATOR
8DJ43AAD	TACHOMETER INDICATOR
8DJ48FAL2	POSITION INDICATOR
8DJ48FAR2	POSITION INDICATOR
8DJ49GAW1	POSITION INDICATOR
8DJ49GAW2	POSITION INDICATOR
8DJ49GAX1	POSITION INDICATOR
8DJ49GAX2	POSITION INDICATOR
8DJ49GAY1	POSITION INDICATOR
8DJ49GAY2	POSITION INDICATOR
8DJ49GBV2	POSITION INDICATOR

8DJ49LAL2	POSITION INDICATOR
8DJ49LAM2	POSITION INDICATOR
8DJ49LAN2	POSITION INDICATOR
8DJ49LAV2	POSITION INDICATOR
8DJ67FAB-1	DUAL TACHOMETER INDICATOR
8DJ67-FAF-1	DUAL TACHOMETER INDICATOR
8DJ67FAH1	DUAL TACHOMETER INDICATOR
8DJ67FBC	DUAL TACHOMETER INDICATOR
8DJ67FBC-1	DUAL TACHOMETER INDICATOR
8DJ67FCA-1	DUAL TACHOMETER INDICATOR
8DJ67FCM-1	DUAL TACHOMETER INDICATOR
8DJ67FCW-1	DUAL TACHOMETER INDICATOR
8DJ71GAB1	FUEL FLOW INDICATOR
8DJ71GAK2	FUEL FLOW INDICATOR
8DJ81AA4U	TACHOMETER INDICATOR
8DJ81BLB4	TACHOMETER INDICATOR
8DJ81BLB4U	TACHOMETER INDICATOR
8DJ81BLC4	TACHOMETER INDICATOR
8DJ81BLC4U	TACHOMETER INDICATOR
8DJ81CAA	TACHOMETER INDICATOR
8DJ81CAA1	TACHOMETER INDICATOR
8DJ81CAA2	TACHOMETER INDICATOR
8DJ81CAA4	TACHOMETER INDICATOR
8DJ81CAN1	TACHOMETER INDICATOR
8DJ81CAN2	TACHOMETER INDICATOR
8DJ81CAN4	TACHOMETER INDICATOR
8DJ81CBD	TACHOMETER INDICATOR
8DJ81CBD4	TACHOMETER INDICATOR
8DJ81CDF2	TACHOMETER INDICATOR
8DJ81CDF4	TACHOMETER INDICATOR
8DJ81CDG2	TACHOMETER INDICATOR
8DJ81CDG4	TACHOMETER INDICATOR
8DJ81CDR4	TACHOMETER INDICATOR
8DJ81CDS4	TACHOMETER INDICATOR
8DJ81CDW4	TACHOMETER INDICATOR
8DJ81CDX4	TACHOMETER INDICATOR
8DJ81CDY4	TACHOMETER INDICATOR
8DJ81CDZ4	TACHOMETER INDICATOR
8DJ81CER4	TACHOMETER INDICATOR
8DJ81CET4	TACHOMETER INDICATOR
8DJ81CFA4	TACHOMETER INDICATOR
8DJ81LAA1	TACHOMETER INDICATOR
8DJ81LAA2	TACHOMETER INDICATOR
8DJ81LAA4	TACHOMETER INDICATOR
8DJ81LAA4U	TACHOMETER INDICATOR
8DJ81LAV4	TACHOMETER INDICATOR
8DJ81LAX2	TACHOMETER INDICATOR

8DJ81LCA2	TACHOMETER INDICATOR
8DJ81LCP4	TACHOMETER INDICATOR
8DJ81LCP4U	TACHOMETER INDICATOR
8DJ81LCR4	TACHOMETER INDICATOR
8DJ81LCR4U	TACHOMETER INDICATOR
8DJ81LCT4	TACHOMETER INDICATOR
8DJ81LCT4U	TACHOMETER INDICATOR
8DJ81LSC4	TACHOMETER INDICATOR
8DJ81LSC4U	TACHOMETER INDICATOR
8DJ81LV4	TACHOMETER INDICATOR
8DJ81LVA4	TACHOMETER INDICATOR
8DJ81LVA4U	TACHOMETER INDICATOR
8DJ81LVB4	TACHOMETER INDICATOR
8DJ81LVB4U	TACHOMETER INDICATOR
8DJ81LVF4	TACHOMETER INDICATOR
8DJ81LVF4U	TACHOMETER INDICATOR
8DJ81LVG4	TACHOMETER INDICATOR
8DJ81LVG4U	TACHOMETER INDICATOR
8DJ81LVH4	TACHOMETER INDICATOR
8DJ81LVL4	TACHOMETER INDICATOR
8DJ81LVL4U	TACHOMETER INDICATOR
8DJ81LWA1	TACHOMETER INDICATOR
8DJ81LWA2	TACHOMETER INDICATOR
8DJ81LWA3	TACHOMETER INDICATOR
8DJ81LWA4	TACHOMETER INDICATOR
8DJ81LWA4U	TACHOMETER INDICATOR
8DJ81LWC4	TACHOMETER INDICATOR
8DJ81LWC4U	TACHOMETER INDICATOR
8DJ81LWR4	TACHOMETER INDICATOR
8DJ81LWR4U	TACHOMETER INDICATOR
8DJ81LWS4	TACHOMETER INDICATOR
8DJ81LWS4U	TACHOMETER INDICATOR
8DJ81LWT4	TACHOMETER INDICATOR
8DJ81LWT4U	TACHOMETER INDICATOR
8DJ81LWY4	TACHOMETER INDICATOR
8DJ81LWY4U	TACHOMETER INDICATOR
8DJ81LWZ4	TACHOMETER INDICATOR
8DJ81LWZ4U	TACHOMETER INDICATOR
8DJ81LXF4	TACHOMETER INDICATOR
8DJ81LXF4U	TACHOMETER INDICATOR
8DJ81LXG4	TACHOMETER INDICATOR
8DJ81LXG4U	TACHOMETER INDICATOR
8DJ81LXH4	TACHOMETER INDICATOR
8DJ81LXH4U	TACHOMETER INDICATOR
8DJ81LXK4	TACHOMETER INDICATOR
8DJ81LXK4U	TACHOMETER INDICATOR
8DJ81LXT4	TACHOMETER INDICATOR

8DJ81LXT4U	TACHOMETER INDICATOR
8DJ81LYP4	TACHOMETER INDICATOR
8DJ81LYP4U	TACHOMETER INDICATOR
8DJ81LYT4	TACHOMETER INDICATOR
8DJ81LYT4U	TACHOMETER INDICATOR
8DJ81LYV4	TACHOMETER INDICATOR
8DJ81LYV4U	TACHOMETER INDICATOR
8DJ81LYX4	TACHOMETER INDICATOR
8DJ81LYX4U	TACHOMETER INDICATOR
8DJ81LZA2	TACHOMETER INDICATOR
8DJ81LZC4	TACHOMETER INDICATOR
8DJ81LZC4U	TACHOMETER INDICATOR
8DJ81LZE4	TACHOMETER INDICATOR
8DJ81LZE4U	TACHOMETER INDICATOR
8DJ81LZF4	TACHOMETER INDICATOR
8DJ81LZF4U	TACHOMETER INDICATOR
8DJ81WAG4	TACHOMETER INDICATOR
8DJ81WAG4U	TACHOMETER INDICATOR
8DJ81WAL4	TACHOMETER INDICATOR
8DJ81WAL4U	TACHOMETER INDICATOR
8DJ81WAP4	TACHOMETER INDICATOR
8DJ81WAP4U	TACHOMETER INDICATOR
8DJ81WAY4	TACHOMETER INDICATOR
8DJ81WAY4U	TACHOMETER INDICATOR
8DJ81WBA4	TACHOMETER INDICATOR
8DJ81WBA4U	TACHOMETER INDICATOR
8DJ81WBB4	TACHOMETER INDICATOR
8DJ81WBB4U	TACHOMETER INDICATOR
8DJ81WBC4	TACHOMETER INDICATOR
8DJ81WBC4U	TACHOMETER INDICATOR
8DJ81WBD4	TACHOMETER INDICATOR
8DJ81WBD4U	TACHOMETER INDICATOR
8DJ81WBF4	TACHOMETER INDICATOR
8DJ81WBF4U	TACHOMETER INDICATOR
8DJ81WBG4	TACHOMETER INDICATOR
8DJ81WBG4U	TACHOMETER INDICATOR
8DJ81WBL4	TACHOMETER INDICATOR
8DJ81WBL4U	TACHOMETER INDICATOR
8DJ81WBM4	TACHOMETER INDICATOR
8DJ81WBM4U	TACHOMETER INDICATOR
8DJ81WBS4	TACHOMETER INDICATOR
8DJ81WBS4U	TACHOMETER INDICATOR
8DJ81WBT4	TACHOMETER INDICATOR
8DJ81WBT4U	TACHOMETER INDICATOR
8DJ81WCF4	TACHOMETER INDICATOR
8DJ81WCF4U	TACHOMETER INDICATOR
8DJ81WCG4	TACHOMETER INDICATOR

8DJ81WCG4U	TACHOMETER INDICATOR
8DJ81WCR4	TACHOMETER INDICATOR
8DJ81WCR4U	TACHOMETER INDICATOR
8DJ81WCS4	TACHOMETER INDICATOR
8DJ81WCS4U	TACHOMETER INDICATOR
8DJ81WCT4	TACHOMETER INDICATOR
8DJ81WCT4U	TACHOMETER INDICATOR
8DJ81WCW4	TACHOMETER INDICATOR
8DJ81WCW4U	TACHOMETER INDICATOR
8DJ81WCX4	TACHOMETER INDICATOR
8DJ81WCX4U	TACHOMETER INDICATOR
8DJ81WDE4	TACHOMETER INDICATOR
8DJ81WDG4	TACHOMETER INDICATOR
8DJ81WDK4	TACHOMETER INDICATOR
8DJ81WDK4U	TACHOMETER INDICATOR
8DJ81WDL4	TACHOMETER INDICATOR
8DJ81WDL4U	TACHOMETER INDICATOR
8DJ8ACAA1	TACHOMETER INDICATOR
8ES455070-00	EMERGENCY POWER SUPPLY
8G1229	OIL PRESSURE SWITCH
8SC0072	AC POWER MONITOR
8SC-0109	AIRSPEED INDICATOR
8TJ124GGD3	TRANSMITTER, FULE FLOW
8TJ124GGT1	TRANSMITTER, FUEL FLOW
9000407-15	TRANSMITTER, FLAP POSITION
9000407-16	TRANSMITTER, FLAP POSTION
9000407-19	TRANSMITTER, FLAP POSITION
9000407-20	TRANSMITTER, FLAP POSITION
9002-1101	INSTRUMENT CLUSTER
90024-1	VOLTAGE REGULATOR
90-060-1	SEARCHLIGHT
90090001-02	MGT INDICATOR
90090002-02	INDICATOR
90090003-01	NG INDICATOR
90090003-2	NG INDICATOR
90090004-03	FUEL PRESSURE/AMMETER INDICATOR
90090004-04	FUEL PRESSURE/AMMETER INDICATOR
90090005-01	FUEL QUANTITY INDICATOR
90090005-02	FUEL QUANTITY INDICATOR
90090007-01	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
90090007-02	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
9009006-01	TRANSMISSION OIL TEMPERATURE/PRESSURE INDICATOR
9009006-02	TRANSMISSION OIL TEMPERATURE/PRESSURE INDICATOR
9009-1015	DUAL INDICATOR
9009-1016	DUAL INDICATOR
9009-3003	TEMPERATURE & PRESSURE INDICATOR
9009-3004	TEMPERATURE & PRESSURE INDICATOR

9009-3006	OIL TEMPERATURE INDICATOR
9009-3009	DUAL INDICATOR
9009-3010	DUAL INDICATOR
9009-3013	DUAL INDICATOR
9009-3016	DUAL INDICATOR
9009-3023	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
9009-3028	DUAL INDICATOR
9009-3042	ENGINE OIL TEMPERATURE & PRESSURE INDICATOR
9009-3043	TRANSMISSION OIL TEMPERATURE & PRESSURE INDICATOR
900E3720017-101	AIRSPEED INDICATOR
901-366-014	MOTOR DRIVEN VALVE
901-366-563-107	MOTOR DRIVEN VALVE
901-366-563-109	MOTOR DRIVEN VALVE
901-366-596-101	MOTOR DRIVEN VALVE
9016-1017	FUEL PRESSURE/LOAD METER
9016-3001	FUEL PRESSURE/LOAD METER
9016-3002	FUEL PRESSURE/LOAD METER
9016-3003	FUEL PRESSURE/LOAD METER
9016-3018	FUEL PRESSURE/LOAD METER
9016-3019	FUEL PRESSURE/LOAD METER
9016-3021	FUEL PRESSURE/LOAD METER
9016-3022	FUEL PRESSURE/LOAD METER
9016-3023	FUEL PRESSURE/LOAD METER
9016-3024	FUEL PRESSURE/LOAD METER
9016-3025	FUEL PRESSURE/LOAD METER
9016-3029	FUEL PRESSURE/LOAD METER
9018-1003	OIL TEMPERATURE INDICATOR
9018-1006	OIL TEMPERATURE INDICATOR
9018-1007	TEMPERATURE INDICATOR
9019-1018	TEMPERATURE & PRESSURE INDICATOR
9019-3001	TEMPERATURE & PRESSURE INDICATOR
9019-3002	TEMPERATURE & PRESSURE INDICATOR
9019-3003	TEMPERATURE & PRESSURE INDICATOR
9019-3018	TEMPERATURE & PRESSURE INDICATOR
9019-3019	TEMPERATURE & PRESSURE INDICATOR
9019-3020	TEMPERATURE & PRESSURE INDICATOR
9019-3021	TEMPERATURE & PRESSURE INDICATOR
9019-3025	TEMPERATURE & PRESSURE INDICATOR
9019-3026	TEMPERATURE & PRESSURE INDICATOR
9019-3027	TEMPERATURE & PRESSURE INDICATOR
9019-3028	TEMPERATURE & PRESSURE INDICATOR
9019-3029	TEMPERATURE & PRESSURE INDICATOR
9019-3031	TEMPERATURE & PRESSURE INDICATOR
9019-3036	TEMPERATURE & PRESSURE INDICATOR
9019-3037	TEMPERATURE & PRESSURE INDICATOR
9019-3039	TEMPERATURE & PRESSURE INDICATOR
9019-3040	TEMPERATURE & PRESSURE INDICATOR

9019-3041	TEMPERATURE & PRESSURE INDICATOR
9019-3042	TEMPERATURE & PRESSURE INDICATOR
9019-3043	TEMPERATURE & PRESSURE INDICATOR
9019-3048	OIL TEMPERATURE & PRESSURE INDICATOR
9019-3056	OIL TEMPERATURE & PRESSURE INDICATOR
9019-8021	OIL TEMPERATURE & PRESSURE INDICATOR
9019-8050	OIL TEMPERATURE & PRESSURE INDICATOR
9019-8054	OIL TEMPERATURE & PRESSURE INDICATOR
9020-1041	VOLTMETER
9020-2012	VOLTMETER
9020-3002	VOLTMETER
9020-3003	VOLTMETER
9020-3004	VOLTMETER
9020-3011	AMMETER
9020-3015	VOLTMETER
9020-3017	DUAL AMMETER
9020-3026	DUAL AMMETER
9020-3032	DUAL AMMETER
9020-8049	VOLTMETER
9024-3001	INSTRUMENT CLUSTER
9024-3002	INSTRUMENT CLUSTER
9024-3003	INSTRUMENT CLUSTER
9024-3004	INSTRUMENT CLUSTER
9024-3005	INSTRUMENT CLUSTER
9024-3006	INSTRUMENT CLUSTER
902F010100	VALVE
9030-1017	FUEL PRESSURE INDICATOR
9032-1003	FUEL QUANTITY INDICATOR
9034-1003	TRIPLE OIL PRESSURE INDICATOR
9036-1018	TEMPERATURE & PRESSURE INDICATOR
9036-2006	TEMPERATURE & PRESSURE INDICATOR
9036-2007	TEMPERATURE & PRESSURE INDICATOR
9036-2132	TEMPERATURE & PRESSURE INDICATOR
9036-2133	TEMPERATURE & PRESSURE INDICATOR
9036-3010	TEMPERATURE & PRESSURE INDICATOR
9036-3011	TEMPERATURE & PRESSURE INDICATOR
9036-3012	TEMPERATURE & PRESSURE INDICATOR
9036-3014	TEMPERATURE & PRESSURE INDICATOR
9036-3023	TEMPERATURE & PRESSURE INDICATOR
9036-3024	TEMPERATURE & PRESSURE INDICATOR
9036-3067	ENGINE OIL TEMPERATURE INDICATOR
9036-8153	OIL TEMPERATURE & PRESSURE INDICATOR
90-380037-1	FUEL FLOW INDICATOR
9050-2001	OIL TEMPERATURE & PRESSURE INDICATOR
906B-4-015	DIFFERENTIAL PRESSURE GAGE
906C-13-018	DIFFERENTIAL PRESSURE GAGE
906D-10-020	DIFFERENTIAL PRESSURE GAGE

906D-13-018	DIFFERENTIAL PRESSURE GAGE
906D-4-015	DIFFERENTIAL PRESSURE GAGE
906D-6-020	DIFFERENTIAL PRESSURE GAGE
90G235	GAGE PRESSURE SWITCH
90G236	GAGE PRESSURE SWITCH
90G237	GAGE PRESSURE SWITCH
910GC01Y01	CIRCUIT CARD
912041T	FUEL FLOW INDICATOR
912041T-D	FUEL FLOW INDICATOR
9133-25-B1	FUEL FLOW TRANSMITTER
91-380012-1	SYNCHRO INDICATOR
91-380012-3	SYNCHRO INDICATOR
91380015-1	SYNCHRO INDICATOR
91D74-1	SERVO CONTROL
91D75-1	ACTUATOR
91F389	PANEL
9204401-88	FUEL QUANTITY TRANSMITTER
921012-1	VHF/FM TRANSCEIVER
921012-1 (5V)	VHF/FM COM TRANSCEIVER
921012-2	VHF/FM COM TRANSCEIVER
921012-2 (5V)	VHF/FM COM TRANSCEIVER
92DR147	DIFFERENTIAL PRESSURE INDICATOR
930-500-15-1	SEARCHLIGHT
930-500-25	SEARCHLIGHT
930-500-25-1	LANDING LIGHT
930-500-25-2	SEARCHLIGHT
930-500-25-3	SEARCHLIGHT
930-500-25-4	SEARCHLIGHT
930-500-25-5	SEARCHLIGHT
930-500-25-6	SEARCHLIGHT
930-500-25-7	SEARCHLIGHT
930-500-25-8	SEARCHLIGHT
930-500-25-9	SEARCHLIGHT
930-500-25-A	SEARCHLIGHT
930-500-25-B	SEARCHLIGHT
930-500-25-C	SEARCHLIGHT
930-500-33	SEARCHLIGHT
930-500-35	SEARCHLIGHT
930-500-50-1	SEARCHLIGHT
930-500-50-1-1	SEARCHLIGHT
930-500-50-2	SEARCHLIGHT
9377M61MP02	TRANSMTTER, FUEL FLOW
9377M61P01	TRANSMITTER, FUEL FLOW
940L-02	ALTIMETER
941059-1	UHF/FM COMM TRANSCEIVER
941059-1 (5V)	UHF/FM COMM TRANSCEIVER
941059-2	UHF/FM COMM TRANSCEIVER

941059-2 (5V)	UHF/FM COMM TRANSCEIVER
94123-A	VOLTAGE REGULATOR
94214-A	VOLTAGE REGULATOR
94P32	GAGE PRESSURE SWITCH
9500A	TURN AND SLIP INDICATOR
9500B	TURN AND SLIP INDICATOR
9501-3004	CLOCK
9501A	TURN AND SLIP INDICATOR
9501B	TURN AND SLIP INDICATOR
9502A	TURN AND SLIP INDICATOR
9502B	TURN AND SLIP INDICATOR
95-40-17-B6-56885	INDICATOR SWITCH
95-40-17-H6-56909	RPM INDICATOR
9550 N.589	TURN AND SLIP INDICATOR
9550-8340N5L	TURN AND SLIP INDICATOR
9550A	TURN AND SLIP INDICATOR
9550AN.589	TURN AND SLIP INDICATOR
9550B	TURN AND SLIP INDICATOR
9550BN.540	TURN AND SLIP INDICATOR
9551A	TURN AND SLIP INDICATOR
9551AN.510	TURN AND SLIP INDICATOR
9551B	TURN AND SLIP INDICATOR
9551BN541	TURN AND SLIP INDICATOR
9552A	TURN AND SLIP INDICATOR
9552B	TURN AND SLIP INDICATOR
961068-2	AUDIO CONTROLLER
961068-4	AUDIO CONTROLLER
961072-1	AUDIO CONTROLLER
961072-2	AUDIO CONTROLLER
961082-1	VHF/FM COM TRANSCEIVER
961082-1 (5V)	VHF/FM COM TRANSCEIVER
961082-2	VHF/FM COM TRANSCEIVER
961082-2 (5V)	VHF/FM COM TRANSCEIVER
96774-18-1814	TRANSMITTER
96774-18-1842-7	TORQUE/PRESSURE TRANSMITTER
96774-18-1874	COURSE INDICATOR
971083-1	VHF/UHF FM COMM TRANSCEIVER
971083-1 (5V),	VHF/UHF FM COMM TRANSCEIVER
971083-3	VHF/UHF FM COMM TRANSCEIVER
971083-3 (5V),	VHF/UHF FM COMM TRANSCEIVER
97-384009-1	SYNCHRO INDICATOR
97-384009-3	SYNCHRO INDICATOR
97-384009-5	SYNCHRO INDICATOR
97-384010-1	SYNCHRO INDICATOR
97-384010-3	SYNCHRO INDICATOR
97-384010-5	SYNCHRO INDICATOR
975.21.15.206	PRESSURE TRANSDUCER

980-4535-001	ATTENDANT CONTROL UNIT
9807-56	HYDRAULIC PRESSURE INDICATOR
981086-1	VHF/FM COM TRANSCEIVER
981086-1 (5V)	VHF/FM COM TRANSCEIVER
981086-2	VHF/FM COM TRANSCEIVER
981086-2 (5V)	VHF/FM COM TRANSCEIVER
981087-1	VHF/FM DIGITAL COMM TRANSCEIVER
981087-1 (5V)	VHF/FM DIGITAL COMM TRANSCEIVER
981087-2	VHF/FM DIGITAL COMM TRANSCEIVER
981087-2 (5V)	VHF/FM DIGITAL COMM TRANSCEIVER
9813-25	DUAL TORQUE INDICATOR
9813-25-02	DUAL TORQUE INDICATOR
9813-25-03	DUAL TORQUE INDICATOR
9813-25-05	DUAL TORQUE INDICATOR
9813-25-07	DUAL TORQUE INDICATOR
9813-25-12	DUAL TORQUE INDICATOR
9813-25-13	DUAL TORQUE INDICATOR
9813-25-15	DUAL TORQUE INDICATOR
9813-25-16	DUAL TORQUE INDICATOR
9813-25-17	DUAL TORQUE INDICATOR
9813-25-18	DUAL TORQUE INDICATOR
9813-25-19	DUAL TORQUE INDICATOR
9813-25-20	DUAL TORQUE INDICATOR
9813-25-21	DUAL TORQUE INDICATOR
9813-25-5	DUAL TORQUE INDICATOR
9819-90	FLAP POSITION INDICATOR
9819-90-01	FLAP POSITION INDICATOR
99002-8	GYRO HORIZON
99020-3026	INDICATOR
9910113-1	BLOWER ASSEMBLY
991095-1	FM RADIO
9912117-5	FAN SPEED INDICATOR
991214-34	INTER TURBINE TEMPERATURE INDICATOR
9912147-1	OIL TEMPERATURE INDICATOR
9912147-10	OIL PRESSURE INDICATOR
9912147-11	OIL TEMPERATURE INDICATOR
9912147-12	FUEL QUANTITY INDICATOR
9912147-13	FAN SPEED INDICATOR
9912147-14	FUEL FLOW INDICATOR
9912147-15	INTER TURBINE TEMPERATURE INDICATOR
9912147-16	FUEL FLOW INDICATOR
9912147-17	FUEL FLOW INDICATOR
9912147-18	FAN SPEED INDICATOR
9912147-19	FAN SPEED INDICATOR
9912147-2	FUEL FLOW INDICATOR
9912147-20	FAN SPEED INDICATOR
9912147-21	TURBINE SPEED INDICATOR

9912147-22	FUEL FLOW INDICATOR
9912147-23	FAN SPEED INDICATOR
9912147-24	FAN SPEED INDICATOR
9912147-25	TURBINE SPEED INDICATOR
9912147-27	FAN SPEED INDICATOR
9912147-28	TURBINE SPEED INDICATOR
9912147-3	OIL PRESSURE INDICATOR
9912147-30	OIL PRESSURE INDICATOR
9912147-34	INTER TURBINE TEMPERATURE INDICATOR
9912147-35	FAN SPEED INDICATOR
9912147-36	TURBINE SPEED INDICATOR
9912147-4	INTER TURBINE TEMPERATURE INDICATOR
9912147-5	FAN SPEED INDICATOR
9912147-6	TURBINE SPEED INDICATOR
9912147-7	FUEL QUANTITY INDICATOR
9912147-8	FAN SPEED INDICATOR
9912147-9	TURBINE SPEED INDICATOR
9913147-3	OIL PRESSURE INDICATOR
99193SOCN897331	PRESSURE TRANSDUCER
99193SOCN897331-2B	TRANSDUCER
99193SOCN897331-2D	PRESSURE TRANSDUCER
99193SOCN897331-2E	PRESSURE TRANSDUCER
99193SOCN897331-2F	PRESSURE TRANSDUCER
99193SOCN897331-2G	PRESSURE TRANSDUCER
99193SOCN897331-3B	PRESSURE TRANSDUCER
99193SOCN897331-3D	PRESSURE TRANSDUCER
99193SOCN897331-5E	PRESSURE TRANSDUCER
99251-3252011-0101	ENCODING ALTIMETER
99-384009-1	SYNCHRO INDICATOR
99-384029	SYNCHRO INDICATOR
99-384030-3	SYNCHRO INDICATOR
99-384030-5	SYNCHRO INDICATOR
99-384030-7	SYNCHRO INDICATOR
9A1290	GAS TEMPERATURE INDICATOR
9A2630	TORQUE INDICATOR
9A26302	TORQUE INDICATOR
9A2630-2	TORQUE INDICATOR
9A2640-2	INDICATOR
9A2650	DUAL TACHOMETER INDICATOR
9A375	TEMPERATURE INDICATOR
9A400	TEMPERATURE INDICATOR
9A550	TEMPERATURE INDICATOR
9AA11SOCN897331-2	PRESSURE SWITCH
9DJ176WBG1	ENGINE SPEED INDICATOR
9DJ81CAA4	TACHOMETER INDICATOR
9DJ81CDW4	TACHOMETER INDICATOR
A. N. 3202-1	VOLTMETER

A.13A	CLOCK
A/S INDICATOR	AIRSPEED INDICATOR
A102AN116	QUANTITY INDICATOR
A1050-02	TURN AND SLIP INDICATOR
A1050-03	TURN AND SLIP INDICATOR
A1060	TURN AND SLIP INDICATOR
A-11	TURN AND BANK INDICATOR
A-1155-1	LOADMETER
A-1155-3	LOADMETER
A-12	TURN AND BANK INDICATOR
A-13A-1	AIRCRAFT CLOCK
A1600	TURN AND SLIP INDICATOR
A1600B-1	TURN AND SLIP INDICATOR
A1605	TURN AND SLIP INDICATOR
A1615	TURN AND SLIP INDICATOR
A1620	TURN AND SLIP INDICATOR
A162003	TURN AND BANK INDICATOR
A-20-CM	ALTIMETER
A2125-1B-100	STATIC INVERTER
A218-965616-00	CONTROL GRIP ASSEMBLY
A218-967750-00	HAND GRIP
A2200	TURN AND SLIP INDICATOR
A2250-1	TURN AND SLIP INDICATOR
A24A9170	VOLTAGE REGULATOR
A250-1B-1	STATIC INVERTER
A2550-1	TURN AND SLIP INDICATOR
A2562-01	TURN AND SLIP INDICATOR
A301	AUDIO PANEL
A301-1	AUDIO PANEL
A301-12-1	AUDIO PANEL
A301-14A	AUDIO PANEL
A301-412	AUDIO PANEL
A301-6	AUDIO PANEL
A301-61	AUDIO PANEL
A301-61A	CONTROL COMMUNICATION
A30161ACVR	AUDIO CONTROL
A301-61B1	AUDIO PANEL
A301-61B-1	AUDIO PANEL
A301-6R	CONTROL COMMUNICATION PANEL
A301-6W	CONTROL COMMUNICATION
A301-6W/CVR	CONTROL COMMUNICATIONS PANEL
A301-6W-001	AUDIO PANEL
A301-6WCR	COMMUNICATION CONTROL
A3562-01	TURN AND SLIP INDICATOR
A-35-AAU-8A/A	ALTIMETER
A35MA	ALTIMETER
A-35MA	ALTIMETER

A35-MA-10L-2	ALTIMETER
A412AHS-28	STROBE POWER SUPPLY
A413A	STROBE POWER SUPPLY
A490ATSC	POWER SUPPLY
A50691103	TACH GENERATOR
A5069110302	TACH GENERATOR
A5930-01	TURN AND SLIP INDICATOR
A5930-02	TURN AND SLIP INDICATOR
A5930-03	TURN AND SLIP INDICATOR
A5930-04	TURN AND SLIP INDICATOR
A5930-05	TURN AND SLIP INDICATOR
A5930-06	TURN AND SLIP INDICATOR
A5930-07	TURN AND SLIP INDICATOR
A615A	OIL MONITOR
A710	AUDIO CONTROL SYSTEM
A711	AUDIO CONTROL SYSTEM
A740	AUDIO CONTROL SYSTEM
A8/A-10-4	ALTIMETER
A80 AAU 8A/A	ALTIMETER
A80-AAU-7A/A	ALTIMETER
A80-AAU7A/A-101	ALTIMETER
A80-AAU-8/A	ALTIMETER
A-80-AAU-8/A	ALTIMETER
A-80-AAU-8A/A	ALTIMETER
AA21-403	PA/SIREN CONTROLLER
AA21-406	CONTROLLER
AA22-110	CONTROL PA
AA22-170	SIREN CONTROLLER
AA25-001	AUDIO CONTROLLER
AA25-007	AUDIO PANEL
AA25-008	AUDIO PANEL
AA31-002	INTERCOM
AA31-301	ICS MOD CONTROLLER
AA34-200	RADIO INTERFACE
AA35-100	AUDIO MIXER
AA36-001	AUDIO ADAPTER
AA36-100	AUDIO ADAPTER, ICS TIE LINE
AA37-001	ICS CALL/ALERT SYSTEM
AA37-002	ICS CALL/ALERT SYSTEM
AA37-212	AUDIO MODULE
AA82-001	STEREO INTERCOM
AA82-060	STEREO INTERCOM
AA83-001	STEREO INTERCOM
AA92H-407	AUDIO CONTROL PANEL
AA94-401	AUDIO PANEL
AA94-426	AUDIO CONTROL PANEL
AA94-435	AUDIO PANEL

AA95	AUDIO CONTROLLER
AA95-452	AUDIO CONTROLLER
AA95-453	AUDIO CONTROL PANEL
AA95-479	ICS AUDIO PANEL
AA95-498	AUDIO SELECTOR
AA95-524	AUDIO CONTROLLER
AA95-525	ICS RADIO
AA95-528	AUDIO CONTROLLER
AA95-564	AUDIO CONTROL PANEL
AA95-567	AUDIO CONTROL PANEL
AA95-725	AUDIO CONTROL PANEL
AA95-728	AUDIO CONTROL PANEL
AA95-728N	AUDIO PANEL NVG
AA95-729	AUDIO CONTROL PANEL
AA95-764	AUDIO CONTROL PANEL
AA95-766	AUDIO CONTROL PANEL
AA95-863	AUDIO CONTROLLER
AA95-863 TSO	AUDIO CONTROL PANEL
AA95-912N	AUDIO CONTROL PANEL
AA95-913N	AUDIO CONTROL PANEL
AA96	AUDIO CONTROLLER
AA97	AUDIO CONTROLLER
AA97-402	AUDIO CONTROL PANEL
AA97-402N	TRANSCEIVER
AA97-420	AUDIO CONTROL PANEL
AA97-431	AUDIO CONTROLLER
AA97-451	AUDIO CONTROL PANEL
AA97-MSP	AUDIO CONTROL PANEL
AAU/21/A	ALTIMETER
AAU/24/A	ALTIMETER
AAU/27/A	ALTIMETER
AAU/31/A	ALTIMETER
AAU/32/A	ALTIMETER
AAU/7/A	ALTIMETER
AAU/8/A	ALTIMETER
AAU-21/A	ALTIMETER
AAU-24/A	ALTIMETER
AAU-27/A	ALTIMETER
AAU-31/A	ENCODING ALTIMETER
AAU-31/A-1	ALTIMETER
AAU-32/A	ENCODING ALTIMETER
AAU-32/A-1	ALTIMETER
AAU-7/A	ALTIMETER
AC-102	AIRSPEED INDICATOR
AC131	AIRSPEED INDICATOR
AC-131	AIRSPEED INDICATOR
AC131A	AIRSPEED INDICATOR

AC-131-A	AIRSPEED INDICATOR
ACP53-001	AUDIO CONTROL PANEL
AD-600A	ATTITUDE DIRECTOR INDICATOR
AD-600B	ATTITUDE DIRECTOR INDICATOR
AD-600C	ATTITUDE DIRECTOR INDICATOR
AD-600H	ATTITUDE DIRECTOR INDICATOR
AD-650A	ATTITUDE DIRECTOR INDICATOR
AD-650B	ATTITUDE DIRECTOR INDICATOR
AD-650C	ATTITUDE DIRECTOR INDICATOR
AD-650H	ATTITUDE DIRECTOR INDICATOR
ADI-350AP	ATTITUDE INDICATOR
ADI-350AT	ATTITUDE INDICATOR
ADI-350AU	ATTITUDE GYRO
ADI-350B	ATTITUDE INDICATOR
ADI-350J	ATTITUDE INDICATOR
ADI-350K	ATTITUDE INDICATOR
ADI-350U	ATTITUDE INDICATOR
ADI-35AR	ATTITUDE INDICATOR
AF200	CABIN PRESSURE INDICATOR
AF200A	CABIN PRESSURE INDICATOR
AG34	TACH GENERATOR
AG-44	TACH GENERATOR
AGU-21/A	HYDRAULIC PRESSURE INDICATOR
AHC-SP-034-01	VERTICAL SPEED INDICATOR
AI360	ATTITUDE INDICATOR
AI-360	ATTITUDE INDICATOR
AI803	ATTITUDE INDICATOR
AI-804A	ATTITUDE INDICATOR
AI-804AA	ATTITUDE INDICATOR
AI-804AB	ATTITUDE INDICATOR
AI-804AC	ATTITUDE INDICATOR
AI-804AD	ATTITUDE INDICATOR
AI-804AE	ATTITUDE INDICATOR
AI-804AF	ATTITUDE INDICATOR
AI-804AG	ATTITUDE INDICATOR
AI-804AH	ATTITUDE INDICATOR
AI-804AJ	ATTITUDE INDICATOR
AI-804AK	ATTITUDE INDICATOR
AI-804AL	ATTITUDE INDICATOR
AI-804AN	ATTITUDE INDICATOR
AI-804AR	ATTITUDE INDICATOR
AI-804AS	ATTITUDE INDICATOR
AI-804AU	ATTITUDE INDICATOR
AI-804AV	ATTITUDE INDICATOR
AI-804AW	ATTITUDE INDICATOR
AI-804AX	ATTITUDE INDICATOR
AI-804AY	ATTITUDE INDICATOR

AI-804AZ	ATTITUDE INDICATOR
AI-804B	ATTITUDE INDICATOR
AI-804BA	ATTITUDE INDICATOR
AI-804BB	ATTITUDE INDICATOR
AI-804BC	ATTITUDE INDICATOR
AI-804BE	ATTITUDE INDICATOR
AI-804BF	ATTITUDE INDICATOR
AI-804BG	ATTITUDE INDICATOR
AI-804BJ	ATTITUDE INDICATOR
AI-804BK	ATTITUDE INDICATOR
AI-804BL	ATTITUDE INDICATOR
AI-804BM	ATTITUDE INDICATOR
AI-804BN	ATTITUDE INDICATOR
AI-804BP	ATTITUDE INDICATOR
AI-804BR	ATTITUDE INDICATOR
AI-804BT	ATTITUDE INDICATOR
AI-804BU	ATTITUDE INDICATOR
AI-804BV	ATTITUDE INDICATOR
AI-804BW	ATTITUDE INDICATOR
AI-804BY	ATTITUDE INDICATOR
AI-804BZ	ATTITUDE INDICATOR
AI-804C	ATTITUDE INDICATOR
AI-804CA	ATTITUDE INDICATOR
AI-804CC	ATTITUDE INDICATOR
AI-804CD	ATTITUDE INDICATOR
AI-804CE	ATTITUDE INDICATOR
AI-804CF	ATTITUDE INDICATOR
AI-804CH	ATTITUDE INDICATOR
AI-804CJ	ATTITUDE INDICATOR
AI-804CK	ATTITUDE INDICATOR
AI-804CM	ATTITUDE INDICATOR
AI-804CN	ATTITUDE INDICATOR
AI-804CP	ATTITUDE INDICATOR
AI-804CR	ATTITUDE INDICATOR
AI-804CT	ATTITUDE INDICATOR
AI-804CU	ATTITUDE INDICATOR
AI-804CV	ATTITUDE INDICATOR
AI-804CW	ATTITUDE INDICATOR
AI-804CY	ATTITUDE INDICATOR
AI-804D	ATTITUDE INDICATOR
AI-804DA	ATTITUDE INDICATOR
AI-804DB	ATTITUDE INDICATOR
AI-804DC	ATTITUDE INDICATOR
AI-804DD	ATTITUDE INDICATOR
AI-804E	ATTITUDE INDICATOR
AI-804F	ATTITUDE INDICATOR
AI-804G	ATTITUDE INDICATOR

AI-804H/B	ATTITUDE INDICATOR
AI-804H/G	ATTITUDE INDICATOR
AI-804J/B	ATTITUDE INDICATOR
AI-804J/G	ATTITUDE INDICATOR
AI-804K	ATTITUDE INDICATOR
AI-804L	ATTITUDE INDICATOR
AI-804N	ATTITUDE INDICATOR
AI-804P	ATTITUDE INDICATOR
AI-804R	ATTITUDE INDICATOR
AI-804S	ATTITUDE INDICATOR
AI-804T	ATTITUDE INDICATOR
AI-804U	ATTITUDE INDICATOR
AI-804V	ATTITUDE INDICATOR
AI-804W	ATTITUDE INDICATOR
AI-804Y	ATTITUDE INDICATOR
AI-804Z	ATTITUDE INDICATOR
AI-904AD	ATTITUDE INDICATOR
AI-904HA/B	ATTITUDE INDICATOR
AI-904HA/G	ATTITUDE INDICATOR
AI-904HB/B	ATTITUDE INDICATOR
AI-904HB/G	ATTITUDE INDICATOR
AI-904HC/B	ATTITUDE INDICATOR
AI-904HC/G	ATTITUDE INDICATOR
AI-904M/B	ATTITUDE INDICATOR
AI-904M/G	ATTITUDE INDICATOR
AI-904N/B	ATTITUDE INDICATOR
AI-904N/G	ATTITUDE INDICATOR
AI-904P/B	ATTITUDE INDICATOR
AI-904P/G	ATTITUDE INDICATOR
AI-904R/B	ATTITUDE INDICATOR
AI-904R/G	ATTITUDE INDICATOR
AI-904S/B	ATTITUDE INDICATOR
AI-904S/G	ATTITUDE INDICATOR
AI-904S/HB/B	ATTITUDE INDICATOR
AI-904S/HB/G	ATTITUDE INDICATOR
AI-904T/B	ATTITUDE INDICATOR
AI-904T/G	ATTITUDE INDICATOR
AI-904U/B	ATTITUDE INDICATOR
AI-904U/G	ATTITUDE INDICATOR
AI-904U/HA/B	ATTITUDE INDICATOR
AI-904U/HA/G	ATTITUDE INDICATOR
AI-904U/HC/B	ATTITUDE INDICATOR
AI-904V/B	ATTITUDE INDICATOR
AI-904V/G	ATTITUDE INDICATOR
AIM 200	TURN AND SLIP INDICATOR
AIM 200DC (14)	TURN AND SLIP INDICATOR
AIM 200DC (14) P	TURN AND SLIP INDICATOR

AIM 200DC (28)	TURN AND SLIP INDICATOR
AIM 200DC (28) P	TURN AND SLIP INDICATOR
AIM 200E (AeroCom)	TURN AND SLIP INDICATOR
AIM 200ED	TURN AND SLIP INDICATOR
AIM 200EDC	TURN AND SLIP INDICATOR
A-J5-AAU-8A/A	ALTIMETER
AK2823AK10	AIRSPEED INDICATOR
AMP1100-1100S	CLOCK
AMP1100-1100SW	CLOCK
AMP-1100-1100SW	CLOCK
AMP1100-1101	CLOCK
AMP1100-1108	CLOCK
AMP1100-1111	CLOCK
AMP1100-1120	CLOCK
AMP-1100-1120	CLOCK
AMP1100-11200SE	CLOCK
AMP1100-11200WE	CLOCK
AMP1100-11200YE	CLOCK
AMP1100-1120WE	CLOCK
AMP1100-1121	CLOCK
AMP1100-1124	CLOCK
AMP-1100-1124	CLOCK
AMP1100-1124B	CLOCK
AMP1100-1125	CLOCK
AMP-1100-1125	CLOCK
AMP1100-1126	CLOCK
AMP-1100-1126	CLOCK
AMP-1101-1108	CLOCK
AMP-1110-1110S-1110SW	CLOCK
AMP-1111	CLOCK
AMP-1120-1120WE	CLOCK
AMP-1121	CLOCK
AMP-1124	CLOCK
AMP-1124B	CLOCK
AMP-1125	CLOCK
AMR 350	AUDIO CONTROL PANEL
AMR 350H	AUDIO CONTROL PANEL
AMR-350	AUDIO CONTROL PANEL
AMR-350H	AUDIO CONTROL PANEL
AMS 44	AUDIO CONTROL PANEL
AMS42	AUDIO CONTROL PANEL
AMS42F	AUDIO CONTROL PANEL
AMS43	AUDIO CONTROL PANEL
AMS43 TSO	AUDIO CONTROL PANEL
AMS43HP	AUDIO CONTROL PANEL
AMS43T	AUDIO CONTROL PANEL
AMS43TSO	SINGLE CHANNEL AUDIO CONTROLLER

AMS44	AUDIO CONTROL PANEL
AMS44T	AUDIO CONTROL PANEL
AMS50-000	AUDIO PANEL WITH MARKER BEACON
AMS50-100	AUDIO PANEL, STEREO
AMS-6000	AUDIO MODE SELECTOR
AN 5760	ALTIMETER
AN 5771-5	SUCTION GAGE
AN 5771-5A	SUCTION GAGE
AN/ASN-43	GYRO
AN3095-1	LANDING LIGHT
AN3095-10	LANDING LIGHT
AN3095-11	LANDING LIGHT
AN3095-2	LANDING LIGHT
AN3095-3	LANDING LIGHT
AN3095-4	LANDING LIGHT
AN3095-4A	LANDING LIGHT
AN3095-5	LANDING LIGHT
AN3095-6	LANDING LIGHT
AN3095-6A	LANDING LIGHT
AN3095-7	LANDING LIGHT
AN3095-8	LANDING LIGHT
AN3095-9	LANDING LIGHT
AN-30959	LANDING LIGHT
AN3095-A4	LANDING LIGHT
AN3203V30	VOLTMETER
AN3203-V30	DC VOLTMETER
AN395-5A	LANDING LIGHT
AN5531-1	TACHOMETER INDICATOR
AN5766-1	MAGNETIC COMPASS
AN5766-2	MAGNETIC COMPASS
AN5766-3	MAGNETIC COMPASS
AN5766-4	MAGNETIC COMPASS
AN5766-T3	MAGNETIC COMPASS
AN5766-T4	MAGNETIC COMPASS
AN5770-1	MANIFOLD PRESSURE GAGE
AN5770-2	MANIFOLD PRESSURE GAGE
AN5770-2-12	MANIFOLD PRESSURE GAGE
AN5770-2A-12	MANIFOLD PRESSURE GAGE
AN5770-2A-34	MANIFOLD PRESSURE GAGE
AN5770-3	MANIFOLD PRESSURE GAGE
AN5770-4-12	MANIFOLD PRESSURE GAGE
AN5770-4-34	MANIFOLD PRESSURE GAGE
AN-5771-2	PRESSURE GAUGE
AN5772-1	DUAL FUEL PRESSURE GAGE
AN5772-2	OIL PRESSURE INDICATOR
AN-5825-1	CLIMB GAUGE
AN6011-1B	O2 PRESSURE GAUGE

APM1100	CLOCK
APM1100S	CLOCK
APM1100SW	CLOCK
APM1101	CLOCK
APM1101S	CLOCK
APM1101SW	CLOCK
APM1111	CLOCK
APM1120	CLOCK
APM11200SE	CLOCK
APM11200WE	CLOCK
APM11200YE	CLOCK
APM1120WE	CLOCK
APM1121	CLOCK
APM1124	CLOCK
APM1124B	CLOCK
APM1125	CLOCK
APM1126	CLOCK
APT-100-1000-2030SG	PRESSURE TRANSDUCER
APT-150-1000-125G	OIL PRESSURE TRANSMITTER
APT-279-1000-125G	PRESSURE SWITCH
APT-291A-1000-250G	TRANSMITTER
APT-294A-1000-150G	OIL PRESSURE TRANSDUCER
APT-311-1000-200G	OIL PRESSURE TRANSMITTER
APT-48KBS-1000-150G	PRESSURE TRANSDUCER
APTE-130-1000-75G	TRANSDUCER
APTE-130LF-1000-75G	TRANSMITTER
APTE-138-100G	TRANSDUCER
APTE-138-150G	PRESSURE TRANSDUCER
APTE-138-50G	PRESSURE TRANSDUCER
APTE-138A-100G	PRESSURE TRANSDUCER
APTE-138A-150G	TRANSMITTER
APTE-138A-50G	PRESSURE TRANSDUCER
APTE-139-1500SG	PRESSURE TRANSDUCER
APTE-139KBS-1000-1500SG	PRESSURE TRANSDUCER
APTE-173RT1-75G	OIL PRESSURE TRANSMITTER
AR-209-4	FUEL FLOW INDICATOR
ARU-3/A	TURN AND SLIP INDICATOR
ARU-3A	TURN AND SLIP INDICATOR
ARU-48/A	ATTITUDE INDICATOR
ARU-65/A	ATTITUDE INDICATOR
ARU-68/A	ATTITUDE INDICATOR
ARU-69/A	ATTITUDE INDICATOR
ARU-70/A	ATTITUDE INDICATOR
ARU-71/A	ATTITUDE INDICATOR
ASC 1006 DO38	TORQUE INDICATOR
ASH450-1	STATIC INVERTER
ASH564B-9	STATIC INVERTER

ASH584-1	STATIC INVERTER
ASH584-2	STATIC INVERTER
ASH584-3	STATIC INVERTER
ASH584-4	STATIC INVERTER
ASH584-5	STATIC INVERTER
ASH584-6	STATIC INVERTER
ASO AAU-6A/A	ALTIMETER
AT4110A6	CLOCK
AT420000	CLOCK
AT4200C0	CLOCK
AT420100	CLOCK
AT420102	CLOCK
AT4210A5	CLOCK
AT4210A6	CLOCK
AT4210P0	CLOCK
AT4210R0	CLOCK
AT4211A5	CLOCK
AT4211A6	CLOCK
AT4211P0	CLOCK
AT422002	CLOCK
AT422004	CLOCK
AT4220A5	CLOCK
AT4220A6	CLOCK
AT4220C1	CLOCK
AT4220C2	CLOCK
AT4220P0	CLOCK
AT4220P1	CLOCK
AT42210H	CLOCK
AT4221A5	CLOCK
AT4221A6	CLOCK
AT4221E1	CLOCK
AT4221P0	CLOCK
AT4250P1	CLOCK
AT42510H	CLOCK
AT4251E1	CLOCK
AT4251E1C	CLOCK
AT660100	CLOCK
ATP-100-1000-2030 SG	PRESSURE TRANSDUCER
ATPE-138-100G	PRESSURE TRANSDUCER
ATPE-138-150G	PRESSURE TRANSDUCER
ATPE-138A-100G	PRESSURE TRANSMITTER
ATPE-138A-150G	PRESSURE TRANSMITTER
ATPE-138A-50G	PRESSURE TRANSMITTER
AU-10	RPM WARNING BOX
AU-10-1	WARNING CONTROL UNIT
AUD 250H	AUDIO PANEL IC
AUD 251H	AUDIO PANEL

AUD-250H	AUDIO PANEL IC
AUD-251H	AUDIO PANEL
AV16B1667D	MOTOR DRIVEN VALVE
AV16B17480-2	MOTOR DRIVEN VALVE
AV16B2095D	MOTOR DRIVEN VALVE
AV16E1217C	FUEL SHUT OFF VALVE
AV24B1119B	MOTOR DRIVEN VALVE
AV24B1179B	MOTOR DRIVEN VALVE
AV24B1260AR	FUEL VALVE
AV24B1265AR	VALVE, FUEL SHUT OFF
AW-17/8-27-E5	O2 PRESSURE GAUGE
AW-1-7/8-4	SUCTION GAGE
AW1814AB09	OIL PRESSURE INDICATOR
AW1842AR01	TORQUE INDICATOR
AW1842AR02	TORQUE INDICATOR
AW1842AR04	TORQUE INDICATOR
AW1842AR05	TORQUE INDICATOR
AW1842AR07	TORQUE INDICATOR
AW1842BA01	TORQUE INDICATOR
AW1842BA02	TORQUE INDICATOR
AW1842BA03	TORQUE INDICATOR
AW1842BA04	TORQUE INDICATOR
AW1842BA05	TORQUE INDICATOR
AW1842BA06	TORQUE INDICATOR
AW2812AQ01	AIRSPEED INDICATOR
AW2823AK01	AIRSPEED INDICATOR
AW2823AK02	AIRSPEED INDICATOR
AW2823AK03	AIRSPEED INDICATOR
AW2823AK04	AIRSPEED INDICATOR
AW2823AK05	AIRSPEED INDICATOR
AW2823AK06	AIRSPEED INDICATOR
AW2823AK09	AIRSPEED INDICATOR
AW2823AK11	AIRSPEED INDICATOR
AW2823AK12	AIRSPEED INDICATOR
AW2823AK13	AIRSPEED INDICATOR
AW2823AK15	AIRSPEED INDICATOR
AW2823AK16	AIRSPEED INDICATOR
AW2823AK17	AIRSPEED INDICATOR
AW2823AK18	AIRSPEED INDICATOR
AW2823AK19	AIRSPEED INDICATOR
AW2823AM01	AIRSPEED INDICATOR
AW2823AM02	AIRSPEED INDICATOR
AW2829AE02	AIRSPEED INDICATOR
AW2837AB01	MACH AIRSPEED INDICATOR
AW2837AB02	MACH AIRSPEED INDICATOR
AW2837AB03	MACH AIRSPEED INDICATOR
AW2837AB04	MACH AIRPSEED INDICATOR

AW2837AC01	MACH AIRSPEED INDICATOR
AW2837AC03	MACH AIRSPEED INDICATOR
AW2837AC05	MACH AIRSPEED INDICATOR
AW2837AH01	MACH AIRSPEED INDICATOR
AW2837AJ01	MACH AIRSPEED INDICATOR
AW2842AH01	TORQUE INDICATOR
AW2923AK08	AIRSPEED INDICATOR
AW2938AC02	MACH AIRSPEED INDICATOR
AZ649	AIR DATA SENSOR
B0090 81101	ALTIMETER
B0090 81102	ALTIMETER
B0090 81104	ALTIMETER
B0090 81107	ALTIMETER
B0090 81108	ALTIMETER
B0090 81110	ALTIMETER
B024381143	MACH AIRSPEED INDICATOR
B0294-2001844204	CONTROL MOTION TRANSDUCER
B13-941.22.05.1.CW	CLOCK
B13-941.22.05.4.AM	CLOCK
B13-944.22.00.0.A	CLOCK
B13-944.22.28.2.A	CLOCK
B13-944.32.05.1.CH	CLOCK
B15821-10-008	AIRSPEED INDICATOR
B15-945.32.05.4.CD	CLOCK
B17-941.22.05.1.A	CLOCK
B17-941.22.28.4.CR	CLOCK
B17-941.27.00.0.A	CLOCK
B17-951.22.05-4.AA	CLOCK
B17-951.22-05-1.DG	CLOCK
B17-952.22.05.3.A	CLOCK
B18-945.22.00.0.A	CLOCK
B18-945.22.05.1.A	CLOCK
B18-945.22.05.4.CR	CLOCK
B18-945.22.05-1.K	CLOCK
B18-945.22.28.1.A	CLOCK
B18-945.22.28.1.K	CLOCK
B18-945.22.28.2.A	CLOCK
B18-945.22.28.4.CR	CLOCK
B18-945.22.28.4.DN	CLOCK
B18-945.25.00.0.AH	CLOCK
B18-945.32.28.1.AJ	CLOCK
B18-945.32.28.3.AG	CLOCK
B18-945.35.28.1.AF	CLOCK
B18-945.35.28.1.AI	CLOCK
B18-945-32-28-1AG	CLOCK
B18-955.22.00.0.CL	CLOCK
B18-955.22.00.0.CS	CLOCK

B18-955.22.05.4.CG	CLOCK
B18-955.22.28.4.DC	CLOCK
B2350-0016	MOTOR DRIVEN VALVE
B4420210002	ENCODING ALTIMETER
B4515210002	ALTIMETER
B4515210004	ALTIMETER
B45152-10-004	ALTIMETER
B4515210005	ALTIMETER
B45152-10-005	ALTIMETER
B45152-10-009	ALTIMETER
B4515210013	ALTIMETER
B45152-10-013	ENCODING ALTIMETER
B451521002	ALTIMETER
B45152-10-113	ENCODING ALTIMETER
B4515210410	ENCODING ALTIMETER
B45451-10-001	ENCODING ALTIMETER
B45451-10-002	ENCODING ALTIMETER
B45451-10-011	ENCODING ALTIMETER
B45451-10-101	ENCODING ALTIMETER
B45451-10-102	ENCODING ALTIMETER
B45501-10-001	ENCODING ALTIMETER
B45501-10-002	ENCODING ALTIMETER
B45501-10-101	ENCODING ALTIMETER
B45501-10-102	ENCODING ALTIMETER
B45521-10-001	ENCODING ALTIMETER
B45521-10-002	ENCODING ALTIMETER
B45521-10-101	ENCODING ALTIMETER
B45521-10-102	ENCODING ALTIMETER
B45531-10-001	ENCODING ALTIMETER
B4553110002	ALTIMETER
B4553110004	ALTIMETER
B455311002	ALTIMETER
B455311004	ALTIMETER
B45531-10-101	ENCODING ALTIMETER
B45531-10-102	ENCODING ALTIMETER
B4553110104	ALTIMETER
B709-7	TORQUE INDICATOR
B771M40C1003	TRIPLE TACHOMETER INDICATOR
BAS-212/412-100G	OIL PRESSURE TRANSMITTER
BAS-212/412-1500SG	PRESSURE TRANSDUCER
BAS-212/412-150G	PRESSURE TRANSDUCER
BAS-212/412-50G	PRESSURE TRANSDUCER
BAS-222-125G-1	ENGINE OIL PRESSURE TRANSDUCER
BAS-222-250G	PRESSURE TRANSDUCER
BE409	VOLTMETER
BE412	VOLTMETER
BE412-40	VOLTMETER

BE413	VOLTMETER
BE413-40	AMMETER
BE418-3	AMMETER
BE440	DUAL VOLT/AMP INDICATOR
BH183M-13	TURBINE INLET TEMPERATURE INDICATOR
BH183R-16	TURBINE INLET TEMPERATURE INDICATOR
BH183R-58	TURBINE INLET TEMPERATURE INDICATOR
BH185L-37	TACH INDICATOR, FAN SPEED
BHI85L-37	FAN SPEED INDICATOR
BHL-4305-15	SENSOR SPA
BHTI 214-175-299-105	AIRSPEED INDICATOR
BHTI 214-175-299-107	AIRSPEED INDICATOR
BSE-206-30G	FUEL PRESSURE TRANSDUCER
BYLF-51514	TEMPERATURE SENSOR ASSY
C-1000	C-1000 CONTROL UNIT
C14	DIRECTIONAL GYRO
C-14	DIRECTIONAL GYRO
C14158AA	ALTIMETER
C14A	DIRECTIONAL GYRO
C-14A	DIRECTIONAL GYRO
C-14D	DIRECTIONAL GYRO
C16111AA	HORIZONTAL SITUATION INDICATOR
C16112AA	FUEL PRESSURE CONDITIONING UNIT
C16113AA	FUEL PRESSURE CONDITIONING UNIT
C16159AB	TRIPLE TACHOMETER INDICATOR
C16239AA	TACHOMETER INDICATOR
C16240AA	TEMPERATURE INDICATOR
C19239AA	TACHOMETER INDICATOR
C2200-L4	COMPASS
C2200-L4-1	COMPASS
C2200-L4-1B	COMPASS
C2200-L4-B	COMPASS
C2300-DL4	COMPASS
C2300-DL4-1	COMPASS
C2300-DL4-1B	COMPASS
C2300DL4-24B	COMPASS
C2300DL4-B	COMPASS
C2300DL4-CM	COMPASS
C2300DL4-CM-24	COMPASS
C2300DL4-CM-24B	COMPASS
C2300DL4-CM-B	COMPASS
C2300DL4-CMI-B	COMPASS
C2300-L-24	COMPASS
C2300L4	COMPASS
C2300-L4	COMPASS
C2300-L4-24	COMPASS
C2300L4-24B	COMPASS

C2300-L4-24B	COMPASS
C2300-L4-B	COMPASS
C2300L4I	COMPASS
C2300L4I-24B	COMPASS
C2300L4-M23	COMPASS
C2300L4VFM-12	COMPASS
C2300L4VFM-24	COMPASS
C2300L4VM-12	COMPASS
C2300L4VM-24	COMPASS
C2300LV4M-23	COMPASS
C2350-DL4-VF	COMPASS
C2350L4-M23	COMPASS
C2400-L4P	COMPASS
C2400-L4P-1	COMPASS
C2400-L4P-1A	COMPASS
C2400-L4P-1AB	COMPASS
C2400-L4P-1B	COMPASS
C2400-L4P-2	COMPASS
C2400-L4P-24	COMPASS
C2400-L4P-24B	COMPASS
C2400-L4P-2A	COMPASS
C2400-L4P-B	COMPASS
C2400-L4T-1BB	COMPASS
C2400L4VM24B	COMPASS
C2400-L4VT	COMPASS
C2400-L4VT-1A	COMPASS
C2400-L4VT-1B	COMPASS
C2400-L4VT-1BB	COMPASS
C2400-L4VT-24	COMPASS
C2400-L4VT-B	COMPASS
C2400L4VW-310-RG	COMPASS
C406-2	EMERGENCY LOCATOR TRANSMITTER
C406-2HM	EMERGENCY LOCATOR TRANSMITTER
C450-1	ENGINE GAGE UNIT
C450-2	ENGINE GAGE UNIT
C450A-1	ENGINE GAGE UNIT
C450A-2	ENGINE GAGE UNIT
C450A-3	ENGINE GAGE UNIT
C45501-10-001	ENCODING ALTIMETER
C45501-10-002	ENCODING ALTIMETER
C45501-10-101	ENCODING ALTIMETER
C45501-10-102	ENCODING ALTIMETER
C45521-10-001	ENCODING ALTIMETER
C45521-10-002	ENCODING ALTIMETER
C45521-10-101	ENCODING ALTIMETER
C45521-10-102	ENCODING ALTIMETER
C-5C	STANDBY COMPASS

C-6280(P)/APX	TRANSPONDER CONTOL
C-6280A(P)/APX	TRANSPONDER CONTROL
C6533/ARC	AUDIO PANEL
C661003-0506	TURN AND SLIP INDICATOR
C661011-0105	ALTIMETER
C661011-0805	ALTIMETER
C661045-0301	AIRSPEED INDICATOR
C661045-0302	AIRSPEED INDICATOR
C661045-0303	AIRSPEED INDICATOR
C661045-0304	AIRSPEED INDICATOR
C661045-0305	AIRSPEED INDICATOR
C661045-0306	AIRSPEED INDICATOR
C661045-0308	AIRSPEED INDICATOR
C661045-0309	AIRSPEED INDICATOR
C661045-0310	AIRSPEED INDICATOR
C661045-0311	AIRSPEED INDICATOR
C661045-0312	AIRSPEED INDICATOR
C661045-0313	AIRSPEED INDICATOR
C661045-0315	AIRSPEED INDICATOR
C661045-0316	AIRSPEED INDICATOR
C661045-0317	AIRSPEED INDICATOR
C661045-0318	AIRSPEED INDICATOR
C661045-0319	AIRSPEED INDICATOR
C661061-0101	MACH AIRSPEED INDICATOR
C661062-0102	MACH AIRSPEED INDICATOR
C661063-0101	MACH AIRSPEED INDICATOR
C661063-0102	MACH AIRSPEED INDICATOR
C661063-0103	MACH AIRSPEED INDICATOR
C661071-0101	ALTIMETER
C661072-0102	ALTIMETER
C-6717/APX	TRANSPONDER CONTROL
C6SC1034-29	AIRSPEED INDICATOR
C-7483/APX	TRANSPONDER CONTROL
CB2100	COMPASS
CB2100T4	COMPASS
CB-2100T4	COMPASS
CB-2100-T4	COMPASS
CB-2100-T4A	COMPASS
CB2100T6C	COMPASS
CB2100T6D	COMPASS
CB2100-T6D	COMPASS
CB-2100-T6-D	COMPASS
CC250-001	COMMUNICATION CONTROL
CH251-01F	NAT RT
CL2300L4-24B	COMPASS
CL-ABU-11/A	CLOCK
CM2645L1	FUEL QUANTITY INDICATOR

CM2675-1	DIRECTIONAL GYRO
CN1314/A	DISPLACEMENT GYRO
CN-1314/A	DISPLACEMENT GYRO
CN-1314B/A	DISPLACEMENT GYRO
CN-1497C/A	DISPLACEMENT GYRO
CN-811A/ASN	DISPLACEMENT GYRO
CN-998/ASN-43	DIRECTIONAL GYRO
CN-998A/ASN-43	DIRECTIONAL GYRO
CN-998B	DISPLACEMENT GYRO
CN-998B/ASN-43	DIRECTIONAL GYRO
CP1755ABC	AUDIO CONTROL PANEL
CP1766G	AUDIO CONTROL PANEL
CP1766GB01	AUDIO CONTROL PANEL
CP1766GB02	AUDIO CONTROL PANEL
CP1766H	AUDIO CONTROL PANEL
CP1766J	AUDIO CONTROL PANEL
CP1766K	AUDIO CONTROL PANEL
CP1876EB01	AUDIO CONTROL PANEL
CP1976A1	AUDIO CONTROL PANEL LIGHTING
CP1976A2	AUDIO CONTROL PANEL
CP1976AA01	AUDIO CONTROL PANEL
CP1976AA02	AUDIO CONTROL PANEL
CP1976AA03	AUDIO CONTROL PANEL
CP1976B1	AUDIO CONTROL PANEL
CP1976B2	AUDIO CONTROL PANEL
CP1976C	AUDIO CONTROL PANEL
CP1976DA02	AUDIO CONTROL PANEL
CP1976EA01	AUDIO CONTROL PANEL
CP1976FA01	AUDIO CONTROL PANEL
CP1976FB01	AUDIO CONTROL PANEL
CP1976GA01	AUDIO CONTROL PANEL
CP2321A	AUDIO CONTROL PANEL
CP2321B	AUDIO CONTROL PANEL
CP2618A	AUDIO CONTROL PANEL
CP2618AA02	AUDIO CONTROL PANEL
CP2618AA03	AUDIO CONTROL PANEL
CP2618AA05	AUDIO CONTROL PANEL
CP2618BA03	AUDIO CONTROL PANEL
CP2618CA03	AUDIO CONTROL PANEL
CP2618CB03	AUDIO CONTROL PANEL
CP2618DA01	AUDIO CONTROL PANEL
CP2618DB01	AUDIO CONTROL PANEL
CPT 606	BEACON ASSEMBLY
CR2795B105A1	VOLTAGE REGULATOR
CS412	DUAL REMOTE COMPENSATOR
CSV1152-12AB	VOLTAGE REGULATOR
CSV1829-1	VOLTAGE REGULATOR

CSV1829-3	VOLTAGE REGULATOR
CSV1829-7	VOLTAGE REGULATOR
CW801M	POWER SUPPLY
D107318	FUEL BOOST PUMP
D107318D	FUEL BOOST PUMP
D107318D1	FUEL BOOST PUMP
D107318E	FUEL BOOST PUMP
D107319	FUEL BOOST PUMP
D107613	SERVO MOTOR
D120-P2-T	ALTIMETER
D2206104004	ALTIMETER
D2206104010	ALTIMETER
D2206122010	ALTIMETER
D-30337-04-008	DUAL TACHOMETER INDICATOR
D-3040	LANDING LIGHT
D-30401	LANDING LIGHT
D-3040B	LANDING LIGHT
D-3040B-1	LANDING LIGHT
D-3040E	LANDING LIGHT
D-3040E-1	LANDING LIGHT
D42129/1	CONTROL MOTION TRANSDUCER
D42129/2	CONTROL MOTION TRANSDUCER
D4720-01	TURN AND BANK INDICATOR
D480-07-001	ANNUNCIATOR
DA-42-37	PRESSURE GAUGE
DCR-40-70B	POWER SUPPLY
DCR-40-70B2	POWER SUPPLY
DDL-OC110A	TURBINE SPEED INDICATOR
DDL-OC110B	TURBINE SPEED INDICATOR
DDL-OC110D	TURBINE SPEED INDICATOR
DG02E-3BHL	DIRECTIONAL GYRO
DG02E-3BL	DIRECTIONAL GYRO
DG-0C110D	TURBINE SPEED INDICATOR
DG-OC110A	TURBINE SPEED INDICATOR
DG-OC110D	DIGITAL TURBINE SPEED INDICATOR
DGS-65	DIRECTIONAL GYRO
DK 457-120	TRIPLE TACHOMETER INDICATOR
DK033	PRESSURE TRANSMITTER
DK033-1	PRESSURE TRANSMITTER
DK033-3	WATER PRESSURE TRANSMITTER
DK040	PRESSURE TRANSMITTER
DK042	PRESSURE TRANSMITTER
DK433	FUEL PRESSURE INDICATOR
DK433-39	FUEL PRESSURE INDICATOR
DK433-40	FUEL PRESSURE INDICATOR
DK433-53	FUEL PRESSURE INDICATOR
DK449	TRIPLE OIL PRESSURE INDICATOR

DK449-39	TRIPLE OIL PRESSURE INDICATOR
DK449-40	TRIPLE OIL PRESSURE INDICATOR
DK449-42	TRIPLE OIL PRESSURE INDICATOR
DK449-53	TRIPLE OIL PRESSURE INDICATOR
DK453	PRESSURE INDICATOR
DK504	DUAL TORQUE INDICATOR
DK504-39	DUAL TORQUE INDICATOR
DK504-40	DUAL TORQUE INDICATOR
DK504-45	DUAL TORQUE INDICATOR
DL 453	DUAL TACHOMETER INDICATOR
DL1326M164	LINEAR ACTUATOR
DL401-14	DUAL TACHOMETER INDICATOR
DL401-15	DUAL TACHOMETER INDICATOR
DL401-16	DUAL TACHOMETER INDICATOR
DL401-17	DUAL TACHOMETER INDICATOR
DL401-18	DUAL TACHOMETER INDICATOR
DL401-1A	DUAL TACHOMETER INDICATOR
DL404-109	TRIPLE TACHOMETER INDICATOR
DL404-112	TRIPLE TACHOMETER INDICATOR
DL404-19	TRIPLE TACHOMETER INDICATOR
DL404-38	TRIPLE TACHOMETER INDICATOR
DL404-39	TRIPLE TACHOMETER INDICATOR
DL404-4	TRIPLE TACHOMETER INDICATOR
DL404-40	TRIPLE TACHOMETER INDICATOR
DL404-41	TRIPLE TACHOMETER INDICATOR
DL404-42	TRIPLE TACHOMETER INDICATOR
DL404-50	TRIPLE TACHOMETER INDICATOR
DL404-53	TRIPLE TACHOMETER INDICATOR
DL404-7	TRIPLE TACHOMETER INDICATOR
DL404-9	TRIPLE TACHOMETER INDICATOR
DL412	TACHOMETER INDICATOR
DL412-39	TACHOMETER INDICATOR
DL412-40	TACHOMETER INDICATOR
DL412-41	TACHOMETER INDICATOR
DL412-41A	TACHOMETER INDICATOR
DL412-53	TACHOMETER INDICATOR
DL412-55	TACHOMETER INDICATOR
DL412-56	TACHOMETER INDICATOR
DL412-57	TACHOMETER INDICATOR
DL412-61	TACHOMETER INDICATOR
DL412-62	TACHOMETER INDICATOR
DL412-63	TACHOMETER INDICATOR
DL412-64	TACHOMETER INDICATOR
DL412-65	TACHOMETER INDICATOR
DL412-66	TACHOMETER INDICATOR
DL412-67	TACHOMETER INDICATOR
DL412-70	TACHOMETER INDICATOR

DL436-36	TRIPLE TACHOMETER INDICATOR
DL436-38	TRIPLE TACHOMETER INDICATOR
DL436-39	TRIPLE TACHOMETER INDICATOR
DL439	DUAL TACHOMETER INDICATOR
DL439-003-003	DUAL TACHOMETER INDICATOR
DL439-003-003MA	DUAL TACHOMETER INDICATOR
DL439-004-003	DUAL TACHOMETER INDICATOR
DL439-101-003	DUAL TACHOMETER INDICATOR
DL4451-2	PROPELLER SPEED INDICATOR
DL446	GAS PRODUCER TACHOMETER INDICATOR
DL446-2	GAS PRODUCER TACHOMETER INDICATOR
DL446-3	GAS PRODUCER TACHOMETER INDICATOR
DL446-6	TURBINE RPM INDICATOR
DL450	DUAL TACHOMETER INDICATOR
DL453	DUAL TACHOMETER INDICATOR
DL457-021	TRIPLE TACHOMETER INDICATOR
DL457-120	TRIPLE TACHOMETER INDICATOR
DL457-300	TRIPLE TACHOMETER INDICATOR
DL457-400	TRIPLE TACHOMETER INDICATOR
DL457-600	TRIPLE TACHOMETER INDICATOR
DSA274	ATTITUDE INDICATOR
DSF 1549-10	FLOW RATE INDICATOR
DSF 1549-4	FLOW RATE INDICATOR
DSF 1549-5	FLOW RATE INDICATOR
DSF1549-2	FUEL FLOW INDICATOR
DSF419	FUEL QUANTITY INDICATOR
DSF508-11	OIL QUANTITY INDICATOR
DSF508-12	OIL QUANTITY INDICATOR
DSF508-12M	OIL QUANTITY INDICATOR
DSF508-13	OIL QUANTITY INDICATOR
DSF508-14	OIL QUANTITY INDICATOR
DSF508-15	OIL QUANTITY INDICATOR
DSF508-16	OIL QUANTITY INDICATOR
DSF508-17	OIL QUANTITY INDICATOR
DSF508-18	OIL QUANTITY INDICATOR
DSF508-8	OIL QUANTITY INDICATOR
DSF508-9	OIL QUANTITY INDICATOR
DSF-684-1	FUEL QUANTITY INDICATOR
DSF989-2	FUEL QUANTITY INDICATOR
DSF989-3	FUEL QUANTITY INDICATOR
DSF989-5	FUEL QUANTITY INDICATOR
DSF989-7	FUEL QUANTITY INDICATOR
DST1017-25	INTER TURBINE TEMPERATURE INDICATOR
DST17-1	TEMPERATURE INDICATOR
DT405-1	DUAL TORQUE INDICATOR
DT409-10	TRIPLE TORQUE INDICATOR
DT409-11	TRIPLE TORQUE INDICATOR

DT409-12	TRIPLE TORQUE INDICATOR
DT409-13	TRIPLE TORQUE INDICATOR
DT409-3	TRIPLE TORQUE INDICATOR
DT409-4	TRIPLE TORQUE INDICATOR
DT409-6	TRIPLE TORQUE INDICATOR
DT409-8	TRIPLE TORQUE INDICATOR
DT409-9	TRIPLE TORQUE INDICATOR
DT410-10	DUAL TORQUE INDICATOR
DT410-11	DUAL TORQUE INDICATOR
DT410-2	DUAL TORQUE INDICATOR
DT410-3	DUAL TORQUE INDICATOR
DT410-4	DUAL TORQUE INDICATOR
DT410-5	DUAL TORQUE INDICATOR
DT410-8	DUAL TORQUE INDICATOR
DT411	TORQUE INDICATOR
DT413-021	DUAL TORQUE INDICATOR
DT413-121	DUAL TORQUE INDICATOR
DT501-6	DUAL TORQUE INDICATOR
DT501-7	DUAL TORQUE INDICATOR
E1070-2	POWER MODULE
E1070C	POWER MODULE
E1070F	POWER MODULE
E1070G	POWER MODULE
E149AC	TRIPLE TACHOMETER INDICATOR
E149AC1	TRIPLE TACHOMETER INDICATOR
E149AC2	TRIPLE TACHOMETER INDICATOR
E149U	TRIPLE TACHOMETER INDICATOR
E149V	TRIPLE TACHOMETER INDICATOR
EA100AN17	QUANTITY INDICATOR
EA100AN53	QUANTITY INDICATOR
EA100AN62	QUANTITY INDICATOR
EA100AN70	QUANTITY INDICATOR
EA100AN93	QUANTITY INDICATOR
EA100ANH	QUANTITY INDICATOR
EA100ANH126	QUANTITY INDICATOR
EA100ANH133H	QUANTITY INDICATOR
EA100ANH-141H	HYDRAULIC FLUID INDICATOR
EA100ANH144	OIL QUANTITY INDICATOR
EA100ANH94	QUANTITY INDICATOR
EA100ANH97	QUANTITY INDICATOR
EA100ANH98	QUANTITY INDICATOR
EA102AN44	QUANTITY INDICATOR
EA102AN65	QUANTITY INDICATOR
EA1065AW-2315	OIL QUANTITY TRANSMITTER
EA124AN110	QUANTITY INDICATOR
EA124AN115	QUANTITY INDICATOR
EA-1409A	VERTICAL SPEED INDICATOR

EA148AN46	QUANTITY INDICATOR
EA148AN47	QUANTITY INDICATOR
EA148AN51	QUANTITY INDICATOR
EA148AN71	QUANTITY INDICATOR
EA-401A	ENCODING ALTIMETER
EA470-3518	FUEL QUANTITY PROBE
EA470-3587	FUEL QUANTITY PROBE
EA470-3588	FUEL PROBE
EA470-3709	TANK UNIT
EA470A-1526	FUEL PROBE
EA470B-3588	FUEL PROBE
EA470B-3710	FUEL PROBE
EA-5171	AIRSPEED
EA-5172	AIRSPEED
EA-5173	AIRSPEED
EA-5174	AIRSPEED
EA-5175	AIRSPEED
EA5175-13	AIRSPEED
EA-5176	AIRSPEED
EA-801A	ENCODING ALTIMETER
EE0033	STANDBY BATTERY
EHU-15A/A	TEMPERATURE INDICATOR
ELT96 A 25 60 000 000	EMERGENCY LOCATOR TRANSMITTER
ELT97 A 20 60 000 000	EMERGENCY LOCATOR TRANSMITTER
EM8000	TACH GENERATOR
EM8000-1	TACH GENERATOR
EM8000-2	TACH GENERATOR
EM8000-3	TACH GENERATOR
EM8000-4	TACH GENERATOR
EM8000-5	TACH GENERATOR
EM8001	TACH GENERATOR
EM8001-1	TACH GENERATOR
EM8001-2	TACH GENERATOR
EM8001-3	TACH GENERATOR
EM8001-4	TACH GENERATOR
EM8001-5	TACH GENERATOR
EM8002	TACH GENERATOR
EMSE377-2	POWER SUPPLY
ERU6A/A	TACHOMETER INDICATOR
EVT422G	ELECTRICAL FAN
EVT605C00	ELECTRICAL FAN
F-1	AIRSPEED INDICATOR
F11504-4D	AIRSPEED INDICATOR
F1559710003	TACHOMETER INDICATOR
F-1A	AIRSPEED
FA 6268	TURBINE OUTLET TEMPERATURE INDICATOR
FA-6268	TURBINE OUTLET TEMPERATURE INDICATOR

FG1006AA50	FUEL PROBE
FG1006AA51	FUEL PROBE
FG1006AA52	FUEL PROBE
FG1006AA53	FUEL PROBE
FG1006AA56	FUEL PROBE
FG1006AA57	FUEL PROBE
FG1006AA58	FUEL PROBE
FG1006AA63	FUEL PROBE
FG1007AA04	FUEL PROBE
FM504	AIRSPEED INDICATOR
FM504-39	AIRSPEED INDICATOR
FM504-40	AIRSPEED INDICATOR
FM504-49	AIRSPEED INDICATOR
FM504-50	AIRSPEED INDICATOR
FM504-53	AIRSPEED INDICATOR
G 6250-5	SEARCHLIGHT
G3 001 03	ROTOR RPM WARNING
G-3001	LANDING LIGHT
G-3001-1	LANDING LIGHT
G3001A	LANDING LIGHT
G-3001A	LANDING LIGHT
G-3001A-1	LANDING LIGHT
G-3001B	LANDING LIGHT
G-3001B-1	LANDING LIGHT
G-3001B-2	LANDING LIGHT
G-3101	LANDING LIGHT
G-3101-1	LANDING LIGHT
G-3101A	LANDING LIGHT
G-3201	LANDING LIGHT
G-3201-1	LANDING LIGHT
G-3201A	LANDING LIGHT
G-3201A-1	LANDING LIGHT
G-3201B	LANDING LIGHT
G-3201B-1	LANDING LIGHT
G-371-01-1A	ALTIMETER
G371-01-1B	ALTIMETER
G-4433A	CONTROL ADF
G-4434A	VHF CONTROL UNIT
G5400-1	LANDING LIGHT
G5400-15	LANDING LIGHT
G5400-16	LANDING LIGHT
G5400-17	LANDING LIGHT
G5400-18	LANDING LIGHT
G5400-2	LANDING LIGHT
G5400-3	LANDING LIGHT
G5400-4	LANDING LIGHT
G5400-5	LANDING LIGHT

G5400-6	LANDING LIGHT
G-5400-6	LANDING LIGHT
G-5400A-6	LANDING LIGHT
G6250-1	SEARCHLIGHT
G-6250-1	SEARCHLIGHT
G6250-2	SEARCHLIGHT
G6250-3	SEARCHLIGHT
G6250-4	SEARCHLIGHT
G-6250-4	SEARCHLIGHT
G6250-5	SEARCHLIGHT
G-6250-5	SEARCHLIGHT
G-6250-6	SEARCHLIGHT
G8385-1	SEARCHLIGHT
G-8385-1	SEARCHLIGHT
G-8385-3	SEARCHLIGHT
G8385-7	SEARCHLIGHT
G-8385-7	SEARCHLIGHT
G-8385-9	SEARCHLIGHT
G8400A8-24S	ROTATING WARNING LIGHT
G991-01-10	VERTICAL SPEED INDICATOR
G991-01-1C	VERTICAL SPEED INDICATOR
G9950-1	NAVIGATION LIGHT
G9950-11	NAVIGATION LIGHT
G9950-13	NAVIGATION LIGHT
G9950-17	NAVIGATION LIGHT
G9950-19	NAVIGATION LIGHT
G9950-2	NAVIGATION LIGHT
G9950-21	NAVIGATION LIGHT
G9950-23	NAVIGATION LIGHT
G9950-25	NAVIGATION LIGHT
G9950-27	NAVIGATION LIGHT
G9950-5	NAVIGATION LIGHT
G9950-7	NAVIGATION LIGHT
G9950-9	NAVIGATION LIGHT
GA-4088	ALTIMETER
GC-1010-24-6AM	GENERATOR CONTROL UNIT
GC-1010-24-6D	VOLTAGE REGULATOR
GC10257-4	PRINTED CIRCUIT BOARD
GC10257-5	REGULATOR CIRCUIT CARD
GC10257-6A	E.C.E. CARD ASSEMBLY
GC10257-6B	E.C.E. CARD ASSEMBLY
GC10257-7	E.C.E. CARD ASSEMBLY
GC10257-8	CIRCUIT BOARD, GENERATOR
GC10257-9	E.C.E. CARD ASSEMBLY
GC10257Y1	E.C.E. CARD ASSEMBLY
GCSC502-4	GENERATOR CONTROL UNIT
GCSG505-28-1	DC GENERATOR CONTROL UNIT

GENERATOR CONTROL UNIT	GENERATOR CONTROL UNIT
GEU-7/A	TACH GENERATOR
GEU7A	TACH GENERATOR
GEU-7A	TACH GENERATOR
GG2479AA01	RATE GYRO
GG2479AA03	RATE GYRO
GG2479AB01	RATE GYRO
GG2479AB03	RATE GYRO
GG2479AB04	RATE GYRO
GH-14	GYRO HORIZON
GH-14A	GYRO HORIZON
GH-14C	ATTITUDE INDICATOR
GH206	GYRO HORIZON
GH-206	GYRO HORIZON
GTX 327 ATC	TRANSPONDER
GV76-1	VERTICAL GYRO
H138JFM	GYRO HORIZON
H140ABM2	GYRO HORIZON
H140ACM2	GYRO HORIZON
H140ADM2	GYRO HORIZON
H140AMM	GYRO HORIZON
H140ARM2	GYRO HORIZON
H140ASM2	GYRO HORIZON
H140ATM2	GYRO HORIZON
H140AUM1	GYRO HORIZON
H140AUM2	GYRO HORIZON
H140BAM2	GYRO HORIZON
H140BHM2	GYRO HORIZON
H140BKM	GYRO HORIZON
H140BLM	GYRO HORIZON
H140CAM1	GYRO HORIZON
H140CJM1	GYRO HORIZON
H140CLM1	GYRO HORIZON
H140CPM1	GYRO HORIZON
H140CQM3	GYRO HORIZON
H140CRM1	GYRO HORIZON
H140CSM1	GYRO HORIZON
H140CWM	GYRO HORIZON
H140DCM	GYRO HORIZON
H140JAM1	GYRO HORIZON
H140JBM	GYRO HORIZON
H140JBM1	GYRO HORIZON
H140JDM1	GYRO HORIZON
H140JJM1	GYRO HORIZON
H140JKM1	GYRO HORIZON
H140JLM	GYRO HORIZON
H140JSM3	GYRO HORIZON

H140JTM1	GYRO HORIZON
H140JUM2	GYRO HORIZON
H140JVM2	GYRO HORIZON
H140JWM1	GYRO HORIZON
H140JYM1	GYRO HORIZON
H140KAM	GYRO HORIZON
H140KBM	GYRO HORIZON
H140KDM	GYRO HORIZON
H140KRM	GYRO HORIZON
H150AKM	STANDBY ATTITUDE INDICATOR
H150AKM1	STANDBY ATTITUDE INDICATOR
H188C	PFCS INDICATOR
H1900K-8	TEMPERATURE INDICATOR
H1901-10	N1 MONITOR/INDICATOR
H221AGM	GYRO HORIZON
H221AHM	GYRO HORIZON
H221ALM	GYRO HORIZON
H221AMM	GYRO HORIZON
H221ANM	GYRO HORIZON
H221APM	GYRO HORIZON
H221ARM	GYRO HORIZON
H221AUM	GYRO HORIZON
H221AVM	GYRO HORIZON
H221AWM	GYRO HORIZON
H221BDM	GYRO HORIZON
H221BFM	GYRO HORIZON
H221BLM	GYRO HORIZON
H221BPM	GYRO HORIZON
H221FAM	GYRO HORIZON
H301ABM1	GYRO HORIZON
H321AAM1	GYRO HORIZON
H321ABM1	GYRO HORIZON
H321ACM1	GYRO HORIZON
H321AFM1	GYRO HORIZON
H321AGM1	GYRO HORIZON
H321AKM1	GYRO HORIZON
H321ALM1	GYRO HORIZON
H321AMM1	GYRO HORIZON
H321ANM1	GYRO HORIZON
H321AQM1	GYRO HORIZON
H321ASM1	GYRO HORIZON
H321AYM1	GYRO HORIZON
H321AZM1	GYRO HORIZON
H321BAM1	GYRO HORIZON
H321BBM	GYRO HORIZON
H321BDM1	GYRO HORIZON
H321BDM2	GYRO HORIZON

H321BEM2	GYRO HORIZON
H321BFM2	GYRO HORIZON
H321BGM1	GYRO HORIZON
H321BHM1	GYRO HORIZON
H321BKM	GYRO HORIZON
H321BNM	GYRO HORIZON
H321BTM	GYRO HORIZON
H321BVM1	GYRO HORIZON
H321BWM	GYRO HORIZON
H321CBM	GYRO HORIZON
H321CCM	GYRO HORIZON
H321CEM	GYRO HORIZON
H321CJM	GYRO HORIZON
H321CMM	GYRO HORIZON
H321CZM	GYRO HORIZON
H321DAM	GYRO HORIZON
H321DBM	GYRO HORIZON
H321EEM	GYRO HORIZON
H321EFM	GYRO HORIZON
H321EGM	GYRO HORIZON
H321EHM	GYRO HORIZON
H321ENM	GYRO HORIZON
H321EPM	ATTITUDE INDICATOR
H321FBM	GYRO HORIZON
H321FCM	GYRO HORIZON
H321FDM	GYRO HORIZON
H341ALM	GYRO HORIZON
H341AYM	GYRO HORIZON
H341TAM	GYRO HORIZON
H900K-2007	TEMPERATURE INDICATOR
H900K-2007A	TEMPERATURE INDICATOR
H900K-2077	AUTOTEMP INDICATOR
HM547	ALTIMETER
HM565	ALTIMETER
HS-100	STATIC INVERTER
IB1000-1GJ-2044	STATIC INVERTER
ID1347C/ARN-82	COURSE INDICATOR
ID-1791/A	ATTITUDE INDICATOR
ID-1791A/A	ATTITUDE INDICATOR
ID-2103/A	HORIZONTAL SITUATION INDICATOR
ID-2104/A	ATTITUDE INDICATOR
ID-2104A/A	ATTITUDE INDICATOR
ID-250/ARN	RADIO MAGNETIC INDICATOR
ID250A/ARN	COURSE INDICATOR
ID-250A/ARN	RADIO MAGNETIC INDICATOR
IFR5-12-8	INDICATOR
IN602	INDICATOR

IND 351	NAVIGATION INDICATOR
IND 451	DME INDICATOR
IND 650	ADF INDICATOR
IND-351	NAVIGATION INDICATOR
IND-451	DME INDICATOR
IND-650	ADF INDICATOR
IND-A5-UH-1	ATTITUDE INDICATOR
INDICATOR	SYNCHRO INDICATOR
IPT-19-1000-2000A	PRESSURE TRANSDUCER
IPT-20-1000-150G	PRESSURE TRANSMITTER
IPT-20-1000-80G	PRESSURE TRANSMITTER
IPT-20R1-1000-150G	PRESSURE TRANSMITTER
IPT-20RT1-1000-100G	PRESSURE TRANSMITTER
IPT-20RT1-1000-150G	PRESSURE TRANSDUCER
IPT-20RT1-1000-250G	PRESSURE TRANSMITTER
IPT-20RT1-1000-30G	PRESSURE TRANSMITTER
IPT-20RT1-1000-80G	PRESSURE TRANSMITTER
IPT-20RT1K-1000-80G	PRESSURE TRANSDUCER
IPT-20RTI-1000-100G	PRESSURE TRANSMITTER
IPT-24RT1-1000-190G	PRESSURE TRANSMITTER
IPT-38-1000-80D	PRESSURE TRANSMITTER
IPT-49-1000-4000A	PRESSURE TRANSMITTER
IPT-51DFP-1000-70D	PRESSURE TRANSDUCER
IPT-70RT1-1000-250G	PRESSURE TRANSDUCER
IPT-70RT1-1000-25G	PRESSURE TRANSDUCER
ISA0301367	TORQUE INDICATOR
IU262-001-10	DIRECTIONAL GYRO
IU262-001-13	DIRECTIONAL GYRO
IU305	INSTRUMENT CLUSTER
IU367	ATTITUDE DIRECTIOR INDICATOR
IU569-001	CLUSTER GAUGE
IV150N	VERTICAL SPEED INDICATOR
J.G.402-A3	FUEL QUANTITY INDICATOR
J8000-01	DIRECTIONAL GYRO
J8000-02	DIRECTIONAL GYRO
J8000-03	DIRECTIONAL GYRO
J8000-04	DIRECTIONAL GYRO
J8000-05	DIRECTIONAL GYRO
J8000-06	DIRECTIONAL GYRO
J8000-07	DIRECTIONAL GYRO
J8000-08	DIRECTIONAL GYRO
J8000-09	DIRECTIONAL GYRO
J8000-10	DIRECTIONAL GYRO
J8000-11	DIRECTIONAL GYRO
JB153.07	CLOCK
JE2-NG	EMERGENCY LOCATOR TRANSMITTER
JG402A2	FUEL QUANTITY INDICATOR

JG402A3	FUEL QUANTITY INDICATOR
JG402A32	FUEL QUANTITY INDICATOR
JG402A4	FUEL QUANTITY INDICATOR
JG402A52	FUEL QUANTITY INDICATOR
JG402A53	FUEL QUANTITY INDICATOR
JG402A55	FUEL QUANTITY INDICATOR
JG412A1	FUEL QUANTITY INDICATOR
JG412A10	FUEL QUANTITY INDICATOR
JG412A11	FUEL QUANTITY INDICATOR
JG412A2	FUEL QUANTITY INDICATOR
JG412A3	FUEL QUANTITY INDICATOR
JG412A4	FUEL QUANTITY INDICATOR
JG412A52	FUEL QUANTITY INDICATOR
JG412A53	FUEL QUANTITY INDICATOR
JG412A54	FUEL QUANTITY INDICATOR
JG412A55	FUEL QUANTITY INDICATOR
JG412A56	FUEL QUANTITY INDICATOR
K1010	TEMPERATURE INDICATOR
K5400-01	GYRO HORIZON
K5400-02	HORIZON GYRO
K5400-03	GYRO HORIZON
K5400-04	GYRO HORIZON
K5400-05	GYRO HORIZON
K5400-06	GYRO HORIZON
KA 35	MARKER BEACON
KA 39	POWER SUPPLY
KA25	ISOLATION AMPLIFIER
KA40	REMOTE LIGHT ADAPTER
KA51A	SLAVING ACCESSORY
KA51B	SLAVING ACCESSORY
KAA18031U/0/1	ALTIMETER
KAA1803K	ALTIMETER
KAA1803LU/0/1	ALTIMETER
KAA1803LU0-3	ALTIMETER
KAA1803PM0	ALTIMETER
KAA1803PMFO	ALTIMETER
KAA1803R	ALTIMETER
KANNAD 121 AF	EMERGENCY LOCATOR TRANSMITTER
KANNAD 406 AF	EMERGENCY LOCATOR TRANSMITTER
KANNAD 406 AF-H	EMERGENCY LOCATOR TRANSMITTER
KANNAD 406 AP	EMERGENCY LOCATOR TRANSMITTER
KANNAD 406 AS	EMERGENCY LOCATOR TRANSMITTER
KC1276	POWER SUPPLY
KCA 01012C	STANDBY COMPASS
KCA 0101C	STANDBY COMPASS
KCA 0101W	STANDBY COMPASS
KCA 0102C	STANDBY COMPASS

KCA 0102W	STANDBY COMPASS
KCA 0104W	STANDBY COMPASS
KCA 0106W	STANDBY COMPASS
KCA01012C	STANDBY COMPASS
KCA0101C	COMPASS
KCA0101W	COMPASS
KCA0102C	COMPASS
KCA0102W	COMPASS
KCA0104FY	STANDBY COMPASS
KCA0104W	COMPASS
KCA0105W	COMPASS
KCA-0105W	STANDBY COMPASS
KCA0106W	STANDBY COMPASS
KCA0107W	STANDBY COMPASS
KCA0109W	STANDBY COMPASS
KCA0110W	STANDBY COMPASS
KCA0112W	STANDBY COMPASS
KCA0113FY	STANDBY COMPASS
KCA0113W	STANDBY COMPASS
KCA0114W	STANDBY COMPASS
KDA 697	RMI ADAPTER
KDF 806	ADF RECEIVER
KDF806	ADF RECEIVER
KDI 572	DME INDICATOR
KDI 573	DME SLAVE INDICATOR
KDI 574	DME INDICATOR
KDI571	DME INDICATOR
KDI572	DME INDICATOR
KDI573	DME INDICATOR
KDI574	DME INDICATOR
KDM 706	DME INDICATOR
KDM 706A	DME INDICATOR
KDM705A	DME INDICATOR
KDM706	DME INDICATOR
KDM706A	DME INDICATOR
K-DW-02	RPM WARNING BOX
K-DW-02/1	RPM WARNING SYSTEM
K-DW-02/1A	WARNING CONTROL BOX RPM
KDW02-1A	RPM WARNING BOX
KE-127	ALTIMETER
KEA 346	ENCODING ALTIMETER
KEA129	ENCODING ALTIMETER
KEA346	ENCODING ALTIMETER
KFS 560B	NAVIGATION CONTROLLER
KFS 564	NAV CONTROL KFS 564
KFS 564A	COMMUNICATION CONTROL
KFS 570B	ATC TRANSPONDER CONTROL

KFS 576	DIGITAL CONTROL
KFS 576A	DIGITAL CONTROL
KFS 586	ADF CONTROL
KFS 586	ADF CONTROL
KFS 586A	ADF CONTROL
KFS 598	COMMUNICATION CONTROL
KFS 598A	COMMUNICATION CONTROL
KFS564	NAV CONTROL KFS 564
KFS564A	NAV CONTROL UNIT
KFS576	ATC TRANSPONDER
KFS576A	ATC TRANSPONDER
KFS-580	ADF CONTROL
KFS586	ADF CONTROL
KFS586A	ADF CONTROL
KFS598	VHF COMMUNICATIONS TRANSCEIVER
KFS-598	VHF RECEIVER/TRANSMITTER
KFS598A	VHF COMM CONTROL
KFS599A	UHF COMMUNICATION CONTROL
KG 102A	DIRECTIONAL GYRO
KG 107	DIRECTIONAL GYRO
KG 253	GYRO HORIZON
KG 258-5	ATTITUDE GYRO
KG102A	DIRECTIONAL GYRO
KG-102A	DIRECTIONAL GYRO
KI 202	VOR/LOC INDICATOR
KI 203	VOR/LOC INDICATOR
KI 204	VOR/LOC GLIDESLOPE INDICATOR
KI 205	VOR/LOC GLIDESLOPE INDICATOR
KI 206	VOR/LOC GLIDESLOPE INDICATOR
KI 207	NAVIGATION INDICATOR
KI 208	VOR/LOC CONVERTER/INDICATOR
KI 209	INDICATOR
KI 227	ADF INDICATOR
KI 229	RMI
KI 250	RADAR ALTIMETER
KI 254	ATTITUDE GYRO
KI204	NAVIGATION INDICATOR
KI-227	ADF INDICATOR
KI229	RMI
KI250	RADAR ALTIMETER INDICATOR
KI254	GYRO HORIZON
KI525	HORIZONTAL SITUATION INDICATOR
KI525A	HORIZONTAL SITUATION INDICATOR
KM 455-3	OIL TEMPERATURE & PRESSURE INDICATOR
KM432-3	OIL TEMPERATURE & PRESSURE INDICAT0R
KMA 24	AUDIO PANEL/MARKER RECEIVER
KMA 24H	AUDIO PANEL

KMA24 H70	ISOLATION AMPLIFIER
KMA24H	ISOLATION AMPLIFIER
KMR 675	MARKER BEACON
KMT 112	SLAVING CONTROL
KMT112	FLUX VALVE
KN 53	NAVIGATION RECEIVER
KN 62A	DME TRANSCEIVER
KN 63	DME TRANSCEIVER
KN 64	DME TRANSCEIVER
KN 72	VOR CONVERTER
KN63	DME INDICATOR
KNI 416	RADAR ALTIMETER
KNI 573	DME SLAVE INDICATOR
KNI 582	RMI
KNI416	RADAR ALTIMETER
KNI582	RMI
KNR 630	VOR RECEIVER
KNR 634	NAVIGATION RECEIVER
KNR 634A	NAVIGATION RECEIVER
KNR634	NAVIGATION RECEIVER
KNR634A	NAVIGATION RECEIVER
KPI552B	HORIZONTAL SITUATION INDICATOR
KR 21	MARKER RECEIVER
KR 22	MARKER SYSTEM
KR 87	ADF CONTROL
KR87	ADF RECEIVER
KR-87	ADF RECEIVER
KRA 10	RECEIVER/TRANSMITTER
KRA 10A	RECEIVER / TRANSMITTER
KRA10	RADAR ALTIMETER
KRA10A	RADAR ALTIMETER
KRG333	3 AXIS SENSOR
KSG105	DIRECTIONAL GYRO
KT 76A	TRANSPONDER
KT 76C	TRANSPONDER
KT 78	TRANSPONDER
KT 78A	TRANSPONDER
KT 79	TRANSPONDER
KT70	ATC TRANSPONDER
KT76A	ATC TRANSPONDER
KT78A	TRANSPONDER
KT79	TRANSPONDER
KTR 905	VHF COMMUNICATIONS TRANSCEIVER
KTR 908	VHF NAV/COMM TRANSCEIVER
KTR908	VHF COMMUNICATIONS TRANSCEIVER
KTR909	COMM TRANSCEIVER
KTS153	PICTORIAL NAVIATION SYSTEM

KTS-598	VHF COMM. TRANSCEIVER
KTS-598A	VHF COMM. TRANSCEIVER
KVG350	VERTICAL GYRO
KX 155	VHF NAV/COMM TRANSCEIVER
KX 165	VHF NAV/COMM TRANSCEIVER
KX 175B	VHF NAV/COMM TRANSCEIVER
KX155	VHF TRANSCEIVER /NAVIGATION RECEIVER
KX165	TRANSCEIVER
KX165A	TRANSCEIVER
KXP 755	TRANSPONDER
KXP 756	TRANSPONDER
KXP755	TRANSPONDER
KY 195B	VHF COMMUNICATIONS TRANSCEIVER
KY 196	VHF COMMUNICATIONS TRANSCEIVER
KY 196A	VHF COMMUNICATIONS TRANSCEIVER
KY 196B	VHF COMMUNICATIONS TRANSCEIVER
KY 197	VHF COMMUNICATIONS TRANSCEIVER
KY 197A	VHF COMMUNICATIONS TRANSCEIVER
KY 197E	VHF COMMUNICATIONS TRANSCEIVER
KY 96A	VHF COMM CONTROL
KY 97A	VHF COMMUNICATIONS TRANSCEIVER
KY196A	VHF COMMUNICATIONS TRANSCEIVER
L281M2008101	FUEL PROBE
L293M00C1001	PRESSURE SWITCH
L316M20C1001	OIL TEMPERATURE & PRESSURE INDICATOR
L334M3820101	LANDING LIGHT
L334M3820101.A003	LANDING LIGHT
L341M30C1001	VERTICAL SPEED INDICATOR
L771M20C1003	DUAL TORQUE INDICATOR
L771M40C1004	TRIPLE TACHOMETER INDICATOR
L771M40C1005	TRIPLE TACHOMETER INDICATOR
L771M40C1010	TRIPLE TACHOMETER INDICATOR
L771M40C1014	TRIPLE TACHOMETER INDICATOR
L7815CT	VOLTAGE REGULATOR
LA11A2104	LINEAR ACTUATOR
LA11A2118	LINEAR ACTUATOR
LA11A2119-1	ACTUATOR
LA11A2121	ACTUATOR
LA11A2121-1	ACTUATOR
LA11A2129	PASSENGER STEP ACTUATOR
LA11A2129-1	PASSENGER STEP ACTUATOR
LA11A2142	LINEAR ACTUATOR
LA-71-11	ALTIMETER
LC-2	CLOCK
LD12-001	LIGHT DIMMER
LE-50-IL	ALTIMETER
LE-50-ILB	ALTIMETER

LLLC-12047	TACHOMETER INDICATOR
LM117K	VOLTAGE REGULATOR
LT-370	LIGHT DIMMER POWER SUPPLY
LT-48	LIGHT DIMMER POWER SUPPLY
LT-48(A)	LIGHT DIMMER POWER SUPPLY
LT-48(B)	LIGHT DIMMER POWER SUPPLY
LT-48(C)	LIGHT DIMMER POWER SUPPLY
LT-48(D)	LIGHT DIMMER POWER SUPPLY
LT-48(E)	LIGHT DIMMER POWER SUPPLY
LT-48(G)	LIGHT DIMMER POWER SUPPLY
LT-48(H)	LIGHT DIMMER POWER SUPPLY
LT-48(N)	LIGHT DIMMER POWER SUPPLY
LT-48B	LIGHT DIMMER POWER SUPPLY
LT-50	LIGHT DIMMER POWER SUPPLY
LT-53	LIGHT DIMMER POWER SUPPLY
LT-71	DC TO DC CONVERTER
M/C438532323-00	HANDGRIP
M1986	HOURMETER
M3075-05	TURN AND SLIP INDICATOR
M3075-07	TURN AND SLIP INDICATOR
M3075-1	TURN AND SLIP INDICATOR
M3075-2	TURN AND SLIP INDICATOR
M3075-3	TURN AND SLIP INDICATOR
M3075-4	TURN AND SLIP INDICATOR
M3075-5	TURN AND SLIP INDICATOR
M3075-6	TURN AND SLIP INDICATOR
M3075-7	TURN AND SLIP INDICATOR
M-3075-7	TURN AND SLIP INDICATOR
M3075-8	TURN AND SLIP INDICATOR
M3075-9	TURN AND SLIP INDICATOR
M3540-01	TURN AND SLIP INDICATOR
M3540-04	TURN AND SLIP INDICATOR
M3540-05	TURN AND SLIP INDICATOR
M3540-06	TURN AND SLIP INDICATOR
M3540-1	TURN AND SLIP INDICATOR
M3540-4	TURN AND SLIP INDICATOR
M3562-01	TURN AND SLIP INDICATOR
M450	DC VOLTMETER
M5000-08	TURN AND BANK INDICATOR
M5600-01	TURN RATE INDICATOR
M5600-02	TURN RATE INDICATOR
M5930-02	TURN RATE INDICATOR
M7921T-1A	FAN MOTOR
M800	CLOCK
M800-5-BATT	CLOCK
M803-2-0/5V-BATT	CLOCK/OAT/VOLT INDICATOR
M803B-2-0/5V-BATT	CLOCK

M811B	CLOCK
MB-1A	ALTIMETER
MBT 251B	POWER SUPPLY
MC1723L	VOLTAGE REGULATOR
MD-1	VERTICAL GYRO
MD41-1408A	GPS ANNUNCIATION UNIT
MD41-1468A	GPS ANNUNCIATION CONTROL UNIT
MD41-324	ANNUNCATION CONTROL UNIT
MD41-328	ANNUNCATION CONTROL UNIT
MD41-334	ANNUNCATION CONTROL UNIT
MD41-338	ANNUNCATION CONTROL UNIT
MD41-448	ANNUNCATION CONTROL UNIT
MD41-524	ANNUNCATION CONTROL UNIT
MD41-528	ANNUNCATION CONTROL UNIT
MD41-534	ANNUNCATION CONTROL UNIT
MD41-538	ANNUNCATION CONTROL UNIT
MD41-624	GPS ANNUNCIATION CONTROL UNIT
MD41-628	ANNUNCIATOR
MD41-634	GPS ANNUNCIATION CONTROL UNIT
MD41-638	GPS ANNUNCIATION CONTROL UNIT
MIL-A-6752A	VOLTMETER
MM-0C19A	INTER TURBINE TEMPERATURE INDICATOR
MM-0C19D	INTER TURBINE TEMPERATURE INDICATOR
MM-0C19E	INTER TURBINE TEMPERATURE INDICATOR
MML-0C19AR	INTER TURBINE TEMPERATURE INDICATOR
MML-0C19AS	INTER TURBINE TEMPERATURE INDICATOR
MML-0C19AT	INTER TURBINE TEMPERATURE INDICATOR
MML-OC19AR	TEMPERATURE INDICATOR
MML-OC19AS	TEMPERATURE INDICATOR
MML-OC19AT	INTER TURBINE TEMPERATURE INDICATOR
MM-OC19A	TEMPERATURE INDICATOR
MM-OC19D	TEMPERATURE INDICATOR
MM-OC19E	TEMPERATURE INDICATOR
MP-498	MAGNETIC BRAKE
MP498-103	MAGNETIC BRAKE
MP498-3	MAGNETIC BRAKE
MP-498-3	MAGNETIC BRAKE
MS17313-1	ATTITUDE INDICATOR
MS17406-3	INVERTER
MS17983-1	COMPASS
MS17983-2	COMPASS
MS18071-12	VOLTAGE REGULATOR
MS18071-2	VOLTAGE REGULATOR
MS21971-1	TACHOMETER INDICATOR
MS21983-1	INVERTER
MS24332-1	AC VOLTMETER
MS24569-1	TEMPERATURE INDICATOR

MS25025-1	LOADMETER
MS25277-1	BEACON ASSEMBLY
MS25454-3	VERTICAL SPEED INDICATOR
MS28004-1	TEMPERATURE INDICATOR
MS28004-2	TEMPERATURE INDICATOR
MS28004-3	TEMPERATURE INDICATOR
MS28004-4	TEMPERATURE INDICATOR
MS28009-1	OIL TEMPERATURE INDICATOR
MS28009-2	OIL TEMPERATURE INDICATOR
MS28010-1	FUEL PRESSURE INDICATOR
MS-28021	AIRSPEED INDICATOR
MS28024-3	TURN AND SLIP INDICATOR
MS28024-3A	TURN AND SLIP INDICATOR
MS28027-2	RMI
MS-28041	AIRSPEED INDICATOR
MS28044-1	ALTIMETER
MS28044-L1	ALTIMETER
MS28044-L1A	ALTIMETER
MS28045T1	AIRSPEED INDICATOR
MS28045-T1	AIRSPEED INDICATOR
MS28045-T2	AIRSPEED INDICATOR
MS33629	TACHOMETER INDICATOR
MS33639	PERCENT TACHOMETER INDICATOR
MS-702	FLIGHT DIRECTOR MODE SELECTOR
MU-1	N1 PERCENT TACHOMETER INDICATOR
MV524D-2	VALVE ASSEMBLY
MV524D-3	VALVE ASSEMBLY
N301-503	ICS BOX
N301A-000	SINGLE USER AUDIO CONTROL BOX
N301A-032	AUDIO CONTROL BOX
N301A-500	SINGLE USER CONTROLLER
N30A5B	UNDERWATER ACOUSTIC BEACON
N335-001	DUAL AUDIO CONTROL
NE149AB4	TACHOMETER INDICATOR
NG6335	PRESSURE SWITCH
NPX136D	FM TRANSCEIVER
NPX138N	FM TRANSCEIVER
NSOA036-1	MACH AIRSPEED INDICATOR
NT150-000WR	VHF FM TRANSCEIVER
NT450	TRANSCIEVER
NT-450-000W/R	TRANSCIEVER
NTX138-050	VHF FM TRANSCEIVER
OPT-20RT1-1000-150G	PRESSURE TRANSMITTER
P166395	MOTOR DRIVEN VALVE
P2-07-0001-100	EF-1FLASHLIGHT
P2-07-0001-101	EF-1 FLASHLIGHT
P2-07-0001-201	EF-1 FLASHLIGHT

P2-07-0001-205	EF-1 FLASHLIGHT
P2-07-0001-207	EF-1 FLASHLIGHT
P2-07-0001-211	EF-1 FLASHLIGHT
P2-07-0001-214	EF-1 FLASHLIGHT
P2-07-0001-215	EF-1 FLASHLIGHT
P2-07-0001-400	EF-1 FLASHLIGHT
P2-07-0009-120	EFC-2C FLASHLIGHT
P2-07-0009-520	EFC-2C FLASHLIGHT
P94B12-202	FUEL PUMP
P94B12-203	FUEL PUMP
P94B12-205	FUEL PUMP
P94B12-207	FUEL PUMP
P94B12-208	FUEL PUMP
P94B12-209	FUEL PUMP
P94C16-601	FUEL PUMP
P94C16-602	FUEL PUMP
PA 110	PA AMP
PA110-010	AMPLIFIER PA
PA110-015	LOUDHAILER POWER AMPLIFIER
PC-125-3A	STATIC INVERTER
PC-12VR	DC TO DC CONVERTER
PC-15	STATIC INVERTER
PC-15A	STATIC INVERTER
PC-15B	STATIC INVERTER
PC-15BC	STATIC INVERTER
PC15BC(A)	STATIC INVERTER
PC-15C	STATIC INVERTER
PC-15D	STATIC INVERTER
PC-15E	STATIC INVERTER
PC-15F	STATIC INVERTER
PC-15G	STATIC INVERTER
PC-251	STATIC INVERTER
PC251123A	STATIC INVERTER
PC-251-123A	STATIC INVERTER
PC-251-123B	STATIC INVERTER
PC-251-123C	STATIC INVERTER
PC-251-123D	STATIC INVERTER
PC-251-123E	STATIC INVERTER
PC-251-15A	STATIC INVERTER
PC-251-15B	STATIC INVERTER
PC-251-15C	STATIC INVERTER
PC-251-1C	STATIC INVERTER
PC-251-1D	STATIC INVERTER
PC-251-3A	STATIC INVERTER
PC-251-3B	STATIC INVERTER
PC-251-5A	STATIC INVERTER
PC-251-5B	STATIC INVERTER

PC-251-5C	STATIC INVERTER
PC350	STATIC INVERTER
PC450-1A	STATIC INVERTER
PC-450-1A	STATIC INVERTER
PC-450-1B	STATIC INVERTER
PC-50	STATIC INVERTER
PC900-1A0800PH1-1	FUEL FLOW INDICATOR
PC900-6A0600PH-8-2	FUEL FLOW INDICATOR
PF240-N3	FUEL QUANTITY INDICATOR
PF240-N4	FUEL QUANTITY INDICATOR
PF537-N1	FUEL QUANTITY TRANSMITTER
PF537-N2	FUEL QUANTITY TRANSMITTER
PF537-N3	FUEL QUANTITY TRANSMITTER
PH-130	EMERGENCY FIRE CONTROL SWITCH
PM 22880-1	HANDGRIP
PM21110-1	HANDGRIP
PM21225-6A	HANDGRIP
PM21225-6F	HANDGRIP
PM21225-9	HANDGRIP
PM21239-11	HANDGRIP
PM21239-19	HANDGRIP
PM21319-1	GRIP ASSEMBLY
PM21329-11	GRIP ASSEMBLY
PM21329-13	GRIP ASSEMBLY
PM21329-17	HANDGRIP
PM21329-19	GRIP ASSEMBLY
PM21331-2	HANDGRIP
PM213329-13	HANDGRIP
PM21486	HANDGRIP
PM21487	HANDGRIP
PM21515-3	GRIP ASSEMBLY
PM21515-4	GRIP ASSEMBLY
PM21657-13	GRIP ASSEMBLY
PM21657-14	HANDGRIP
PM21657-15	HANDGRIP
PM21657-16	HANDGRIP
PM21657-3	HANDGRIP
PM21657-4	HANDGRIP
PM21657-5	GRIP ASSEMBLY
PM21657-6	GRIP ASSEMBLY
PM21657-7	GRIP ASSEMBLY
PM21657-8	HANDGRIP
PM21662-1	HANDGRIP
PM21663-2	HANDGRIP
PM21675-1	HANDGRIP
PM21681-1	HANDGRIP
PM21718-1	HANDGRIP

PM21718-11	HANDGRIP
PM21718-12	HANDGRIP
PM21718-13	HANDGRIP
PM21718-2	HANDGRIP
PM21718-4	HANDGRIP
PM21718-5	HANDGRIP
PM21718-7	GRIP ASSEMBLY
PM21840	HANDGRIP
PM21885-4	HANDGRIP
PM21885-5	HANDGRIP
PM21908	HANDGRIP
PM21913	HANDGRIP
PM21913-1	HANDGRIP
PM21913-2	HANDGRIP
PM21913-3	HANDGRIP
PM21914	HANDGRIP
PM21914-1	HANDGRIP
PM21914-2	HANDGRIP
PM21914-3	HANDGRIP
PM21914-4	HANDGRIP
PM21915	HANDGRIP
PM2220	HANDGRIP
PM22220	HANDGRIP
PM22220-1	HANDGRIP
PM22220-5	HANDGRIP
PM22220-6	HANDGRIP
PM22220-7	HANDGRIP
PM22225-2	HANDGRIP
PM22228	HANDGRIP
PM22228-1	HANDGRIP
PM22259-2	HANDGRIP
PM22319	HANDGRIP
PM22362	HANDGRIP
PM22362-1	HANDGRIP
PM22404	HANDGRIP
PM22427	HANDGRIP
PM22427-1	HANDGRIP
PM22477	HANDGRIP
PM22478-11	HANDGRIP
PM22514-3	HANDGRIP
PM22515-3	HANDGRIP
PM22515-4	HANDGRIP
PM22554	HANDGRIP
PM22604-2	HANDGRIP
PM22608	HANDGRIP
PM22608-1	HANDGRIP
PM22609	HANDGRIP

PM22659-2	GRIP ASSEMBLY
PM22700	HANDGRIP
PM22700-1	HANDGRIP
PM22720-1	HANDGRIP
PM22723-1	HANDGRIP
PM22724-4	HANDGRIP
PM22724-5	HANDGRIP
PM22740	HANDGRIP
PM22755	HANDGRIP
PM22760-2	HANDGRIP
PM22760-3	HANDGRIP
PM22762	HANDGRIP
PM22780-1	HANDGRIP
PM22783-1	HANDGRIP
PM22785	HANDGRIP
PM22815-1	HANDGRIP
PM22830	HANDGRIP
PM22880	HANDGRIP
PM22880-1	HANDGRIP
PM22885	HANDGRIP
PM22921	HANDGRIP
PM22921-1	HANDGRIP
PM22921-2	HANDGRIP
PM22981	HANDGRIP
PM22983-1	HANDGRIP
PM23125	HANDGRIP
PM23210	HANDGRIP
PM23223-1	HANDGRIP
PM23225-1	HANDGRIP
PM23225-2	HANDGRIP
PM23230-1	HANDGRIP
PM23233-1	HANDGRIP
POWER SUPPLY	POWER SUPPLY
PS 347	POWER SUPPLY
PS240	INVERTER
PS-240	INVERTER
PS277-3	INVERTER
PS285	INVERTER
PS304	STATIC INVERTER
PS304-1	STATIC INVERTER
PS347	POWER SUPPLY
PS-835C	POWER SUPPLY
PTA12-100	TELEPHONE ADAPTER
R30-VIL-3	VERTICAL SPEED INDICATOR
R460M10	MAGNETIC BRAKE
R460M15	MAGNETIC BRAKE
R460M15-11	MAGNETIC BRAKE

R460M15-3	MAGNETIC BRAKE
R460M43	MAGNETIC BRAKE
RA235	ALTIMETER
RAA82-R004	AUXILIARY ALARM CONTROL
RC 500	CONTROL HEAD
RC 550	CONTROL HEAD
RC30V	VERTICAL SPEED INDICATOR
RC-30-V	VERTICAL SPEED INDICATOR
RC30V10	VERTICAL SPEED INDICATOR
RC30VIL	VERTICAL SPEED INDICATOR
RC-30-VIL	VERTICAL SPEED INDICATOR
RC30VIL-2	VERTICAL SPEED INDICATOR
RC-30-VIL-2	VERTICAL SPEED INDICATOR
RC30VIL4	VERTICAL SPEED INDICATOR
RC-30-VIL-4	VERTICAL SPEED INDICATOR
RC-60 VIL	VERTICAL SPEED INDICATOR
RC60MS	VERTICAL SPEED INDICATOR
RC60VIL3	VERTICAL SPEED INDICATOR
RCA 11/A-8F	DIRECTIONAL GYRO
RCA 11A-15	DIRECTIONAL GYRO
RCA 11A-16B	DIRECTIONAL GYRO
RCA 11A-17B	DIRECTIONAL GYRO
RCA 11A-8	DIRECTIONAL GYRO
RCA 15AK-1	DIRECTIONAL GYRO
RCA 15AK-2	DIRECTIONAL GYRO
RCA 15BK-1	DIRECTIONAL GYRO
RCA 26BK-8	GYRO HORIZON
RCA 40A-( )	TACHOMETER INDICATOR
RCA 40AB-( )	TACHOMETER INDICATOR
RCA 41A-( )	TACHOMETER INDICATOR
RCA 41A-07	TACHOMETER INDICATOR
RCA 41A-09	TACHOMETER INDICATOR
RCA 56-3B	TURN AND SLIP INDICATOR
RCA 82A-11	TURN COORDINATOR
RCA 83A-11	TURN COORDINATOR
RCA11-4	DIRECTIONAL GYRO
RCA11A-1	DIRECTIONAL GYRO
RCA11A-10	DIRECTIONAL GYRO
RCA11A-11	DIRECTIONAL GYRO
RCA11A-12	DIRECTIONAL GYRO
RCA11A-13	DIRECTIONAL GYRO
RCA11A-14	DIRECTIONAL GYRO
RCA11A-15	DIRECTIONAL GYRO
RCA11A-16	DIRECTIONAL GYRO
RCA11A-2	DIRECTIONAL GYRO
RCA11A-3	DIRECTIONAL GYRO
RCA11A-8	DIRECTIONAL GYRO

RCA11A-9	DIRECTIONAL GYRO
RCA12F65	TURN AND BANK INDICATOR
RCA12P1	TURN AND BANK INDICATOR
RCA12P61	TURN AND BANK INDICATOR
RCA12P64	TURN AND BANK INDICATOR
RCA12R22M	TURN AND BANK INDICATOR
RCA12R65	TURN AND BANK INDICATOR
RCA12W2	TURN AND BANK INDICATOR
RCA15A-1	DIRECTIONAL GYRO
RCA15AK-1	DIRECTIONAL GYRO
RCA15AK-16	DIRECTIONAL GYRO
RCA15AK-17	DIRECTIONAL GYRO
RCA15AK-2	DIRECTIONAL GYRO
RCA15B-1	DIRECTIONAL GYRO
RCA15B-2	DIRECTIONAL GYRO
RCA15BK-1	GYRO HORIZON
RCA15BK-16	DIRECTIONAL GYRO
RCA15BK-17	DIRECTIONAL GYRO
RCA15BK2	DIRECTIONAL GYRO
RCA15BK-2	DIRECTIONAL GYRO
RCA15BK-4	DIRECTIONAL GYRO
RCA15BK-7	DIRECTIONAL GYRO
RCA15C-1	DIRECTIONAL GYRO
RCA15C-3	DIRECTIONAL GYRO
RCA15C-4	DIRECTIONAL GYRO
RCA15CM-1	DIRECTIONAL GYRO
RCA15CM-2	DIRECTIONAL GYRO
RCA18P61	TURN AND BANK INDICATOR
RCA25A-5	ATTITUDE GYRO
RCA25A-6	ATTITUDE INDICATOR
RCA25B-2	ATTITUDE INDICATOR
RCA25B-6	ATTITUDE INDICATOR
RCA25B-8	ATTITUDE INDICATOR
RCA25B-9	ATTITUDE INDICATOR
RCA25C2	ATTITUDE GYRO
RCA25C-2	ATTITUDE GYRO
RCA26AK-1	ATTITUDE GYRO
RCA26AK-2	ATTITUDE GYRO
RCA26AK-3	ATTITUDE GYRO
RCA26AK-4	ATTITUDE GYRO
RCA26BK-12	GYRO HORIZON
RCA26BK-2	ATTITUDE GYRO
RCA26BK-31	GYRO HORIZON
RCA26BK-34	ATTITUDE GYRO
RCA26BK-36	ATTITUDE GYRO
RCA26BK-7	ATTITUDE GYRO
RCA26BK8	ATTITUDE GYRO

RCA26BK-9	ATTITUDE GYRO
RCA26EK-6	ATTITUDE GYRO
RCA26EK-7	ATTITUDE GYRO
RCA26EK-8	ATTITUDE GYRO
RCA26EK-9	ATTITUDE GYRO
RCA26EX-2	ATTITUDE GYRO
RCA28F65	TURN AND BANK INDICATOR
RCA28P61	TURN AND BANK INDICATOR
RCA28P61D2A	TURN AND SLIP INDICATOR
RCA28P64	TURN AND BANK INDICATOR
RCA28R22M	TURN AND BANK INDICATOR
RCA28R65	TURN AND BANK INDICATOR
RCA28W2	TURN AND BANK INDICATOR
RCA28WP	TURN AND BANK INDICATOR
RCA29AK-1	ATTITUDE INDICATOR
RCA29BK-3	ATTITUDE INDICATOR
RCA30-01	TURN AND SLIP INDICATOR
RCA30-02	TURN AND SLIP INDICATOR
RCA30-03	TURN AND SLIP INDICATOR
RCA30-04	TURN AND SLIP INDICATOR
RCA30-05	TURN AND SLIP INDICATOR
RCA30-06	TURN AND SLIP INDICATOR
RCA30-07	TURN AND SLIP INDICATOR
RCA30-08	TURN AND SLIP INDICATOR
RCA30-09	TURN AND SLIP INDICATOR
RCA30-10	TURN AND SLIP INDICATOR
RCA30-11	TURN AND SLIP INDICATOR
RCA30-12	TURN AND SLIP INDICATOR
RCA30-13	TURN AND SLIP INDICATOR
RCA35-1	TURN AND BANK INDICATOR
RCA40-02	TACHOMETER INDICATOR
RCA40-03	TACHOMETER INDICATOR
RCA40-05	TACHOMETER INDICATOR
RCA40-06	TACHOMETER INDICATOR
RCA40-07	TACHOMETER INDICATOR
RCA40-09	TACHOMETER INDICATOR
RCA40A-10	TACHOMETER INDICATOR
RCA40A-11	TACHOMETER INDICATOR
RCA40B-01	TACHOMETER INDICATOR
RCA40B-02	TACHOMETER INDICATOR
RCA40B-03	TACHOMETER INDICATOR
RCA40B-04	TACHOMETER INDICATOR
RCA40B-05	TACHOMETER INDICATOR
RCA40B-07	TACHOMETER INDICATOR
RCA40B-08	TACHOMETER INDICATOR
RCA40B-09	TACHOMETER INDICATOR
RCA40B-10	TACHOMETER INDICATOR

RCA40B-11	TACHOMETER INDICATOR
RCA40B-12	TACHOMETER INDICATOR
RCA41-04	TACHOMETER INDICATOR
RCA41A-07	TACHOMETER INDICATOR
RCA80B-15	TURN COORDINATOR
RCA80B-15L	TURN COORDINATOR
RCR 650A	ADF RECEIVER
RCS60IL	VERTICAL SPEED INDICATOR
RD-650	HORIZONTAL SITUATION INDICATOR
RD650A	HORIZONTAL SITUATION INDICATOR
RG12240-1	FUEL BOOST PUMP
RG12240D	FUEL BOOST PUMP
RG20E	RATE GYRO
RL/801 AM/MS/3	ALTIMETER
RS08-001	RELAY/TRANSFER SWITCH
RS08-350	RELAY/TRANSFER SWITCH
RS08-500	RELAY/TRANSFER SWITCH
RS12-020	RELAY/TRANSFER SWITCH
RS12-030	RELAY/TRANSFER SWITCH
RS12-350	RELAY/TRANSFER SWITCH
RS16 001	RELAY/TRANSFER SWITCH
RS24 020	RELAY/TRANSFER SWITCH
RS24 350	RELAY/TRANSFER SWITCH
RT 406F-1	UHF FM TRANSCEIVER
RT 406F-2	UHF FM TRANSCEIVER
RT 406F-50	UHF FM TRANSCEIVER
RT 138 2	VHF HI BAND FM TRANSCEIVER
RT 138 3	VHF HI BAND FM TRANSCEIVER
RT 138-0	VHF HI BAND FM TRANSCEIVER
RT 138-1	VHF HI BAND FM TRANSCEIVER
RT 138F 00	VHF HI BAND FM TRANSCEIVER
RT 138F 02	VHF HI BAND FM TRANSCEIVER
RT 138F 03	VHF HI BAND FM TRANSCEIVER
RT 138F 50	VHF HI BAND FM TRANSCEIVER
RT 138F 51	VHF HI BAND FM TRANSCEIVER
RT 138F 52	VHF HI BAND FM TRANSCEIVER
RT 138F 53	VHF HI BAND FM TRANSCEIVER
RT 138F-01	VHF HI BAND FM TRANSCEIVER
RT 30-0	VHF LOW BAND FM TRANSCEIVER
RT 30-1	VHF LOW BAND FM TRANSCEIVER
RT 30-2	VHF LOW BAND FM TRANSCEIVER
RT 406F	UHF FM TRANSCEIVER
RT 406F-3	UHF FM TRANSCEIVER
RT 406F-51	UHF FM TRANSCEIVER
RT 406F-52	UHF FM TRANSCEIVER
RT 406F-53	UHF FM TRANSCEIVER
RT 450-0	UHF FM TRANSCEIVER

RT 450-1	UHF FM TRANSCEIVER
RT 450-2	UHF FM TRANSCEIVER
RT 450-3	UHF FM TRANSCEIVER
RT138	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
RT-138	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
RT-138F	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
RT-30	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
RT-38	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
RT-406F	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
RT-450	FM COMM. TRANSCEIVER
RYLC-53076-1	LINEAR ACTUATOR
S 206-2	DUAL OIL PRESSURE INDICATOR
S 206-3	DUAL OIL PRESSURE INDICATOR
S 206-4	DUAL OIL PRESSURE INDICATOR
S 206-5	DUAL OIL PRESSURE INDICATOR
S 208-1	DUAL OIL PRESSURE INDICATOR
S 208-6	DUAL OIL PRESSURE INDICATOR
S1226	BEACON ASSEMBLY
S128-5-150	RPM INDICATOR
S1323N4	AIRSPEED INDICATOR
S15 KILR1	AIRSPEED INDICATOR
S-15-KA	AIRSPEED INDICATOR
S15KAW	AIRSPEED INDICATOR
S-15-KAW	AIRSPEED INDICATOR
S15KILR-11	AIRSPEED INDICATOR
S-15-KILR-11	AIRSPEED INDICATOR
S-15-KILR-13	AIRSPEED INDICATOR
S-15-KILR-15	AIRSPEED INDICATOR
S-15-KILR-17	AIRSPEED INDICATOR
S15KILR-19	AIRSPEED INDICATOR
S-15-KILR-19	AIRSPEED INDICATOR
S-15-KILR-20	AIRSPEED INDICATOR
S-15-KILR-21	AIRSPEED INDICATOR
S15KILR-9	AIRSPEED INDICATOR
S-15-KILR-9	AIRSPEED INDICATOR
S-15-KLIR-1	AIRSPEED INDICATOR
S-15-KLIR-9	AIRSPEED INDICATOR
S15-TSO	AIRSPEED INDICATOR
S1770	AMMETER
S1820501-01	EMERGENCY LOCATOR TRANSMITTER
S1820501-02	EMERGENCY LOCATOR TRANSMITTER
S1821501-01	EMERGENCY LOCATOR TRANSMITTER
S1821501-02	EMERGENCY LOCATOR TRANSMITTER
S1822501-01	EMERGENCY LOCATOR TRANSMITTER
S1822501-02	EMERGENCY LOCATOR TRANSMITTER
S1823501-01	EMERGENCY LOCATOR TRANSMITTER
S1823501-02	EMERGENCY LOCATOR TRANSMITTER

S1824501-01	EMERGENCY LOCATOR TRANSMITTER
S1824501-02	EMERGENCY LOCATOR TRANSMITTER
S201-5	TACHOMETER INDICATOR
S-208-6	OIL INDICATOR
S-218-2	HYDRAULIC PRESSURE GAUGE
S231N001-5	STANDBY ENGINE INDICATOR
S231N001-9	STANDBY ENGINE INDICATOR
S231T110-6	STANDBY ATTITUDE INDICATOR
S251N402-12	TRANSMITTER, FLAP LEVER POSITION
S251N403-17	TRANSMITTER, FLAP POSITION
S251N403-18	TRANSMITTER, FLAP POSITION
S256T007-10	FLAP POSITION TRANSMITTER
S256T007-11	FLAP POSITION TRANSMITTER
S256T007-12	FLAP POSITION TRANSMITTER
S256T007-13	FLAP POSITION TRANSMITTER
S256T007-14	FLAP POSITION TRANSMITTER
S256T007-15	FLAP POSITION TRANSMITTER
S256T007-16	FLAP POSITION TRANSMITTER
S256T007-17	FLAP POSITION TRANSMITTER
S256T007-19	FLAP POSITION TRANSMITTER
S256T007-20	FLAP POSITION TRANSMITTER
S256U002-15	TRANSMITTER, FLAP POSITION
S256U002-16	TRANSMITTER, FLAP POSITION
S256U002-19	TRANSMITTER, FLAP POSITION
S256U002-20	TRANSMITTER, FLAP POSITION
S25-KILR1	AIRSPEED INDICATOR
S332T301-181	FIRE OVERHEAT CONTROL CARD
S332T301-81	FIRE OVERHEAT CONTROL CARD
S347-001-13	FUEL FLOW INDICATOR
S347T001-11	FUEL FLOW INDICATOR
S347T001-13	FUEL FLOW INDICATOR
S347T001-14	FUEL FLOW INDICATOR
S347T001-15	FUEL FLOW INDICATOR
S347T001-16	FUEL FLOW INDICATOR
S347T001-24	FUEL FLOW INDICATOR
S347T001-25	FUEL FLOW INDICATOR
S347T001-26	FUEL FLOW INDICATOR
S347T001-7	FUEL FLOW INDICATOR
S347T001-8	FUEL FLOW INDICATOR
S36016-002	DIRECTIONAL GYRO
S-40-KAW	AIRSPEED INDICATOR
S46007-H4C6	DIRECTIONAL GYRO
S46018-03C05PBB	DIRECTIONAL GYRO
S61401-01104-101	HANDGRIP
S61401-01104-102C	HANDGRIP
S6140-61105-11	HANDGRIP
S6140-61105-13	HANDGRIP

S6140-61105-17	HANDGRIP
S6140-61105-19	HANDGRIP
S6140-61416-2	HANDGRIP
S6142-51005-001	HANDGRIP
S6142-61416-10	HANDGRIP
S6142-61416-13	HANDGRIP
S6142-61416-14	HANDGRIP
S6142-61416-15	HANDGRIP
S6142-61416-16	HANDGRIP
S6142-61416-4	HANDGRIP
S6142-61416-5	HANDGRIP
S6142-61416-6	HANDGRIP
S6142-61416-7	HANDGRIP
S6142-61416-8	HANDGRIP
S6142-61416-9	HANDGRIP
S6145-61445-001	ALTIMETER
SA-40-1	AIRSPEED INDICATOR
SEC-OC19EJ-1	INTER TURBINE TEMPERATURE INDICATOR
SEDLC329B-1	TACHOMETER INDICATOR
SEDL-C329C	TACHOMETER INDICATOR
SEL-019	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-019DR	TURBINE OUTLET TEMPERATURE INDICATOR
SEL019-DT	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-0C19AP	T5 TEMP INDICATOR
SELO19BC	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BC	TURBINE OUTLET TEMPERATURE INDICATOR
SELO19BD	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BD	TURBINE OUTLET TEMPERATURE INDICATOR
SELO19BU	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BU	TURBINE OUTLET TEMPERATURE INDICATOR
SELO19BW	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19BW	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19DR	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19DS	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19DT	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-O19ED	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-OC19AM	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-OC19AP	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-OC19EG	T4 TEMPERATURE INDICATOR
SEL-OC19EH	TURBINE OUTLET TEMPERATURE INDICATOR
SEL-OC19EJ	INTER TURBINE TEMPERATURE INDICATOR
SEL-OC19EJ-1	INTER TURBINE TEMPERATURE INDICATOR
SEL-OC19EP	INTER TURBINE TEMPERATURE INDICATOR
SEL-OC19G	TEMPERATURE INDICATOR
SEL-OC29CF	N1 TACHOMETER INDICATOR
SETL-OC329A	TRIPLE TACHOMETER INDICATOR
SLZ7011A	VERTICAL SPEED INDICATOR

SLZ8126	VERTICAL SPEED INDICATOR
SLZ9084	VERTICAL SPEED INDICATOR
SLZ9123	VERTICAL SPEED INDICATOR
SLZ9125	VERTICAL SPEED INDICATOR
SLZ9125A	VERTICAL SPEED INDICATOR
SLZ9127	VERTICAL SPEED INDICATOR
SLZ9140	VERTICAL SPEED INDICATOR
SLZ9141	VERTICAL SPEED INDICATOR
SLZ9145	VERTICAL SPEED INDICATOR
SLZ9157	VERTICAL SPEED INDICATOR
SLZ9157-1	VERTICAL SPEED INDICATOR
SLZ9158	VERTICAL SPEED INDICATOR
SLZ9190	VERTICAL SPEED INDICATOR
SLZ9200	VERTICAL SPEED INDICATOR
SLZ9200A	VERTICAL SPEED INDICATOR
SLZ9200A-1	VERTICAL SPEED INDICATOR
SLZ9244	VERTICAL SPEED INDICATOR
SLZ9247	VERTICAL SPEED INDICATOR
SLZ9248	VERTICAL SPEED INDICATOR
SLZ9410	VERTICAL SPEED INDICATOR
SLZ9415	RATE OF CLIMB INDICATOR
SLZ9415(TSO-C8)	RATE OF CLIMB INDICATOR
SLZ9464A	VERTICAL SPEED INDICATOR
SLZ9464A-1	VERTICAL SPEED INDICATOR
SLZ9504A	VERTICAL SPEED INDICATOR
SLZ9688A	VERTICAL SPEED INDICATOR
SLZ9832A	VERTICAL SPEED INDICATOR
SLZ9845A	VERTICAL SPEED INDICATOR
SP-1400	VERTICAL SPEED INDICATOR
SP-7576 SERIES	DIRECTIONAL GYRO
SP-7600 SERIES	DIRECTIONAL GYRO
SPC-10(W)	STATIC INVERTER
SPC10N	STATIC INVERTER
SPC-30	STATIC INVERTER
SPC30B	STATIC INVERTER
SPC-5	STATIC INVERTER
SPS-1307	STATIC INVERTER
SPS-1307D	STATIC INVERTER
SPS-1607	STATIC INVERTER
SPS-206	STATIC INVERTER
SPS-750	STATIC INVERTER
SR-153C	SYNCHRO INDICATOR
SR-154C	SYNCHRO INDICATOR
SR-2AB	SYNCHRO INDICATOR
SR-2AC	SYNCHRO INDICATOR
SR-2AD	SYNCHRO INDICATOR
SR-2AE	SYNCHRO INDICATOR

SR-2AF	SYNCHRO INDICATOR
SR-2AG	SYNCHRO INDICATOR
SR-2AH	SYNCHRO INDICATOR
SR-2AJ	SYNCHRO INDICATOR
SR-2AK	SYNCHRO INDICATOR
SR-2AM	SYNCHRO INDICATOR
SR-2AP	SYNCHRO INDICATOR
SR-2AR	SYNCHRO INDICATOR
SR-2AT	SYNCHRO INDICATOR
SR-2AU	SYNCHRO INDICATOR
SR-2AW	SYNCHRO INDICATOR
SR-2W	SYNCHRO INDICATOR
SR-2Y	SYNCHRO INDICATOR
SR-2Z	SYNCHRO INDICATOR
SR-6A	SYNCHRO INDICATOR
SR-94J	SYNCHRO INDICATOR
SR-94K	SYNCHRO INDICATOR
SR-94L	SYNCHRO INDICATOR
SR-C2AQ	SYNCHRO INDICATOR
SR-C2AS	SYNCHRO INDICATOR
SRSW-94A	SYNCHRO INDICATOR
SRSW-94B	SYNCHRO INDICATOR
SRSW-94C	SYNCHRO INDICATOR
SSBU-23A/A	VERTICAL GYRO
SSD120	ALTITUDE DIGITIZER
SSD120-35A	ALTITUDE DIGITIZER
ST471	ELEVATOR TRIM INDICATOR
ST471-1	RUDDER TRIM INDICATOR
ST471-2	AILERON TRIM INDICATOR
ST475	AOA INDICATOR
ST-4H	OIL PRESSURE TRANSMITTER
ST-502N-1	TORQUE TRANSMITTER
ST-504AB-1	TORQUE TRANSMITTER
STROBE LIGHT	STROBE LIGHT
SWMK4E0188	WINDSHIELD WIPER MOTOR
SX7EJ10	RELAY
SX7EJ8	RELAY
SYLC 50293	LINEAR ACTUATOR
SYLC 50479	LINEAR ACTUATOR
SYLC 9190-10	LINEAR ACTUATOR
SYLC50114	ELECTROMECHANICAL LINEAR ACTUATOR
SYLC50228	ACTUATOR
SYLC50228-1	ACTUATOR
SYLC50228-3	PASSENGER STEP ACTUATOR
SYLC50479	LINEAR ACTUATOR
SYLC-52630-1	ACTUATOR
SYLC-52630-2	ACTUATOR

SYLC9548-1	ACTUATOR
SYLC-9548-1	LINEAR ACTUATOR
SYLC9868	LINEAR ACTUATOR
T101738-101	RPM LIMIIT DETECTOR
T101738-103	RPM LIMIIT DETECTOR
T4-50NM-A-4-R	TORQUE TRANSDUCER
TARSYN-333	THREE AXIS GYRO
TARSYN-555H	THREE AXIS GYRO
TC100 (12)	TURN COORDINATOR
TC100 (24)	TURN COORDINATOR
TC-120	TURN COORDINATOR
TCR 451	DME R/T
TDR 950	TRANSPONDER
TDR90	TRANSPONDER
TFM 138	VHF/FM COMM TRANSCEIVER
TFM 138A	VHF/FM COMM TRANSCEIVER
TFM 138B	VHF/FM COMM TRANSCEIVER
TFM 138C	VHF/FM COMM TRANSCEIVER
TFM 138D	VHF/FM COMM TRANSCEIVER
TFM 30	VHF/FM COMM TRANSCEIVER
TFM 403	VHF/FM COMM TRANSCEIVER
TFM 500	VHF/UHF COMM TRANSCEIVER
TFM 520	VHF AM/FM, UHF FM COM TRANSCEIVER
TFM 530	VHF/VHF LOW BAND FM COM TRANSCEIVER
TFM 550	VHF HIGH/VHF LOW/UHF FM COM TRANSCEIVER
TFM 556	VHF HIGH/VHF LOW/UHF FM COM TRANSCEIVER
TFM 66	VHF/UHF COMM TRANSCEIVER
TFM138	VHF FM TRANSCEIVER
TFM-138	VHF/FM TRANSCEIVER
TFM-138A	VHF/FM TRANSCEIVER
TG255-001	TACH GENERATOR
TG255-002	TACH GENERATOR
TG255-003	TACH GENERATOR
TG255-004	TACH GENERATOR
TG255-005	TACH GENERATOR
TG255-006	TACH GENERATOR
TG255-007	TACH GENERATOR
TG255-008	TACH GENERATOR
TGH-11-HS-4	TRANSMITTER
TH250-17JB	VHF FM CONTROL UNIT
TH250-2FF	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
TH250-2NN	COMMUNICATION CONTROL
TH260-2ZZ	FM TACTICAL COM
TH3502FFFY	CONTROL HEAD TAC/COM
TH350-2FFN	CONTROL HEAD
TH350-2FFNY	CONTROL HEAD
TH350-7FFN	FM CONTROL

TH450-0NNNE	COMM CONTROL UNIT
TH450-2FFFJ	FLEXCOMM FM COMMUNICATIONS TRANSCEIVER
TH450A-6JJDB	COMMUNICATION SYSTEM
TH460-2ZZZZY	CONTROLLER
TH460B-12ZZZZ	SLAVE HEAD
TM0502	TACH GENERATOR
TM113	TEMPERATURE SWITCH
TM113-1	TEMPERATURE SWITCH
TM410	OIL TEMPERATURE INDICATOR
TM410-39	OIL TEMPERATURE INDICATOR
TM410-40	OIL TEMPERATURE INDICATOR
TM410-41	OIL TEMPERATURE INDICATOR
TM410-53	OIL TEMPERATURE INDICATOR
TM410-54	TEMPERATURE INDICATOR
TM410-7	TRIPLE TEMPERATURE INDICATOR
TM420	TURBINE OUTLET TEMPERATURE INDICATOR
TM420-39	TURBINE OUTLET TEMPERATURE INDICATOR
TM420-40	TURBINE OUTLET TEMPERATURE INDICATOR
TM427-39	TURBINE OUTLET TEMPERATURE INDICATOR
TM427-40	TURBINE OUTLET TEMPERATURE INDICATOR
TM427-45	TURBINE OUTLET TEMPERATURE INDICATOR
TM427-53	TURBINE OUTLET TEMPERATURE INDICATOR
TM435-2	TURBINE OUTLET TEMPERATURE INDICATOR
TM435-53	EGT INDICATOR
TM472 MOD A	TEMPERATURE INDICATOR
TM476	TEMPERATURE INDICATOR
TNAS 1024-118	TRANSMITTER
TNS-012-A	LANDING GEAR ALARM
TS100A	SPEAKER
TS100WR	SPEAKER
TS200-4BL	TURN AND SLIP INDICATOR
TSG 420-103	STATIC INVERTER
TYPE 18-S104	BATTERY
TYPE MU-1	TACHOMETER INDICATOR
TYPE TRU-2A/2	RATE GYRO
UA723CN	VOLTAGE REGULATOR
UI15035P2-13 (-)	ALTIMETER
UI15035P2B P164 (-)	ALTIMETER
UI15035P2-P157 (A)	ALTIMETER
UI15035P2-P43 (H)	ALTIMETER
UI15035PB-P56 (J)	ALTIMETER
UI15035P-P23 (B)	ALTIMETER
UI15035P-P41 (B)	ALTIMETER
UI15035P-P59 (A)	ALTIMETER
UI15934 (K)	ALTIMETER
UI15934-A148 (C)	ALTIMETER
UI15934-A150 (-)	ALTIMETER

UI15934-A253 (-)	ALTIMETER
UI15934-A614 (-)	ALTIMETER
UI15934-A617 (D)	ALTIMETER
UI15934-A624 (-)	ALTIMETER
UI15934-A631 (A)	ALTIMETER
UI15934-A660 (-)	ALTIMETER
UI15934AD-A146 (E)	ALTIMETER
UI15934D (A)	ALTIMETER
UI15934PA-A184 (A)	ALTIMETER
UI15934PAL A436 (-)	ALTIMETER
UI15934PAL-A173 (A)	ALTIMETER
UI15934PAL-A334 (A)	ALTIMETER
UI15934PAM-A620 (B)	ALTIMETER
UI15934PAML-A132 (C)	ALTIMETER
UI15934PD-A158 (A)	ALTIMETER
UI15934PD-A656 (-)	ALTIMETER
UI15934PM-A440 (C)	ALTIMETER
UI15934PM-A619 (B)	ALTIMETER
UI15934PPA-A618 (B)	ALTIMETER
UI15950-A166 (-)	ALTIMETER
UI-3000	CABIN PRESSURE ALTIMETER
UI-3001	CABIN PRESSURE ALTIMETER
UI-3002	CABIN PRESSURE ALTIMETER
UI5035	ALTIMETER
UI5035-12P (-)	ALTIMETER
UI5035-P12 (-)	ENCODING ALTIMETER
UI5035-P154 (-)	ALTIMETER
UI5035P2-13 (-)	ENCODING ALTIMETER
UI5035P2B-P164 (-)	ENCODING ALTIMETER
UI5035P2--P157 (A)	ENCODING ALTIMETER
UI5035P2-P43 (H)	ENCODING ALTIMETER
UI5035-P47 (E)	ENCODING ALTIMETER
UI5035-P61 (B)	ENCODING ALTIMETER
UI5035-PA7 (E)	ALTIMETER
UI5035PB-P56 (J)	ENCODING ALTIMETER
UI5035PB-P61 (B)	ALTIMETER
UI5035P-P23 (B)	ENCODING ALTIMETER
UI5035P-P41 (B)	ENCODING ALTIMETER
UI5035P-P47 (E)	ENCODING ALTIMETER
UI5035P-P59 (A)	ENCODING ALTIMETER
UI5934	ALTIMETER
UI5934-A631 (A)	ALTIMETER
UI5934P2-P157 (A)	ALTIMETER
UI5950 (A)	ALTIMETER
UI59T	ALTIMETER
UI59T (C)	ALTIMETER
UI-6111	MANIFOLD PRESSURE GAGE

UI-6112	MANIFOLD PRESSURE GAGE
UI-6121	MANIFOLD PRESSURE GAGE
UI-6122	MANIFOLD PRESSURE GAGE
UI-6211	FUEL PRESSURE GAGE
UI-6212	FUEL PRESSURE GAGE
UI-6213	FUEL PRESSURE GAGE
UI-6221	FUEL PRESSURE GAGE
UI-6222	FUEL PRESSURE GAGE
UI-6223	FUEL PRESSURE GAGE
UI-6224	FUEL PRESSURE GAGE
UI-6225	FUEL PRESSURE GAGE
UI-6311	MANIFOLD/FUEL PRESSURE GAGE
UI-6312	MANIFOLD/FUEL PRESSURE GAGE
UI-6313	MANIFOLD/FUEL PRESSURE GAGE
UI-6314	MANIFOLD/FUEL PRESSURE GAGE
UI-6315	MANIFOLD/FUEL PRESSURE GAGE
UI-6331	MANIFOLD/FUEL PRESSURE GAGE
UI-6332	MANIFOLD/FUEL PRESSURE GAGE
UI-6333	MANIFOLD/FUEL PRESSURE GAGE
UI-7000	VERTICAL SPEED INDICATOR
UI-7020B	VERTICAL SPEED INDICATOR
UI-7030	VERTICAL SPEED INDICATOR
UI-7030B	VERTICAL SPEED INDICATOR
UI-7040	VERTICAL SPEED INDICATOR
UI-7040B	VERTICAL SPEED INDICATOR
UI-7060B	VERTICAL SPEED INDICATOR
UI-7100	VERTICAL SPEED INDICATOR
UI-7120	VERTICAL SPEED INDICATOR
UI-7120B	VERTICAL SPEED INDICATOR
UI-7120L	VERTICAL SPEED INDICATOR
UI-7130	VERTICAL SPEED INDICATOR
UI-7130B	VERTICAL SPEED INDICATOR
UI-7130L	VERTICAL SPEED INDICATOR
UI-7140	VERTICAL SPEED INDICATOR
UI-7140B	VERTICAL SPEED INDICATOR
UI-7140L	VERTICAL SPEED INDICATOR
UI-7160	VERTICAL SPEED INDICATOR
UI-7160B	VERTICAL SPEED INDICATOR
UI-7160L	VERTICAL SPEED INDICATOR
VCT1518C	BLOWER ASSEMBLY
VCT1518D	OIL COOLING FAN
VG-14	VERTICAL GYRO
VG-14H	VERTICAL GYRO
VG-204Y	DISPLACEMENT GYRO
VG-206A	DISPLACEMENT GYRO
VG-206B	DISPLACEMENT GYRO
VG206-C	DISPLACEMENT GYRO

VG208C	VERTICAL GYRO
VHF 20A	VHF TRANSCEIVER
VHF 251	VHF TRANSCEIVER
VHF 251E	VHF TRANSCEIVER
VHF21A	VHF TRANSCEIVER
VIR 351	VHF TRANSCEIVER
VM450-2L	VERTICAL SPEED INDICATOR
VM450-6-1LF	VERTICAL SPEED INDICATOR
VM450-6L	VERTICAL SPEED INDICATOR
VM-450-6-L	VERTICAL SPEED INDICATOR
VM450-6-L-P	VERTICAL SPEED INDICATOR
VR-1010-24-1A	VOLTAGE REGULATOR
VR-1010-24-4D	VOLTAGE REGULATOR
VR1530-3	VOLTAGE REGULATOR
VSDL-0C219A	OIL TEMPERATURE INDICATOR
VSDL-0C219AE	OIL TEMPERATURE INDICATOR
VSDL-0C219C	OIL TEMPERATURE INDICATOR
VSDL-0C219CF	OIL TEMPERATURE INDICATOR
VSDL-0C219E	OIL TEMPERATURE INDICATOR
VSDL-0C219F	OIL TEMPERATURE INDICATOR
VSDL-0C410AF	FAN SPEED INDICATOR
VSDL-OC19A	OIL TEMPERATURE INDICATOR
VSDL-OC19E	OIL TEMPERATURE INDICATOR
VSDL-OC203A	FUEL QUANTITY INDICATOR
VSDL-OC203AC	FUEL QUANTITY INDICATOR
VSDL-OC203C	FUEL QUANTITY INDICATOR
VSDL-OC204A	OIL PRESSURE INDICATOR
VSDL-OC204AG	OIL PRESSURE INDICATOR
VSDL-OC204C	OIL PRESSURE INDICATOR
VSDL-OC204CH	OIL PRESSURE INDICATOR
VSDL-OC204E	OIL PRESSURE INDICATOR
VSDL-OC204H	OIL PRESSURE INDICATOR
VSDL-OC204N	OIL PRESSURE INDICATOR
VSDL-OC208A	FUEL FLOW INDICATOR
VSDL-OC208A,D	FUEL FLOW INDICATOR
VSDL-OC208C	FUEL FLOW INDICATOR
VSDL-OC208C,E	FUEL FLOW INDICATOR
VSDL-OC208D	FUEL FLOW INDICATOR
VSDL-OC208E	FUEL FLOW INDICATOR
VSDL-OC208F	FUEL FLOW INDICATOR
VSDL-OC219C	OIL TEMPERATURE INDICATOR
VSDL-OC219F	OIL TEMPERATURE INDICATOR
VSDL-OC401A-1	FAN SPEED INDICATOR
VSDL-OC403A	FUEL QUANTITY INDICATOR
VSDL-OC403A,D	FUEL QUANTITY INDICATOR
VSDL-OC403D	FUEL QUANTITY INDICATOR
VSDL-OC403D-1	FUEL QUANTITY INDICATOR

VSDL-OC408A	FUEL FLOW INDICATOR
VSDL-OC408A,E	FUEL FLOW INDICATOR
VSDL-OC408D	FUEL FLOW INDICATOR
VSDL-OC408D,F	FUEL FLOW INDICATOR
VSDL-OC408E	FUEL FLOW INDICATOR
VSDL-OC408F	FUEL FLOW INDICATOR
VSDL-OC410A	FAN SPEED INDICATOR
VSDL-OC410A-1	FAN SPEED INDICATOR
VSDL-OC410AAB	FAN SPEED INDICATOR
VSDL-OC410AB	FAN SPEED INDICATOR
VSDL-OC410AD	FAN SPEED INDICATOR
VSDL-OC410AE	FAN SPEED INDICATOR
VSDL-OC410AF	FAN SPEED INDICATOR
VSDL-OC410B	FAN SPEED INDICATOR
VSDL-OC410B,P	FAN SPEED INDICATOR
VSDL-OC410H	FAN SPEED INDICATOR
VSDL-OC410L	FAN SPEED INDICATOR
VSDL-OC410L,R	FAN SPEED INDICATOR
VSDL-OC410L-1	FAN SPEED INDICATOR
VSDL-OC410M	FAN SPEED INDICATOR
VSDL-OC410M,S	FAN SPEED INDICATOR
VSDL-OC410M-1	FAN SPEED INDICATOR
VSDL-OC410N	FAN SPEED INDICATOR
VSDL-OC410N,T	FAN SPEED INDICATOR
VSDL-OC410N-1	FAN SPEED INDICATOR
VSDL-OC410P	FAN SPEED INDICATOR
VSDL-OC410R	FAN SPEED INDICATOR
VSDL-OC410S	FAN SPEED INDICATOR
VSDL-OC410T	FAN SPEED INDICATOR
VSDL-OC419A	INTER TURBINE TEMPERATURE INDICATOR
VSDL-OC419A,G	INTER TURBINE TEMPERATURE INDICATOR
VSDL-OC419E	INTER TURBINE TEMPERATURE INDICATOR
VSDL-OC419E,H	INTER TURBINE TEMPERATURE INDICATOR
VSDL-OC419G	INTER TURBINE TEMPERATURE INDICATOR
VSDL-OC419H	INTER TURBINE TEMPERATURE INDICATOR
VSDL-OC419L	INTER TURBINE TEMPERATURE INDICATOR
VT044	FUEL QUANTITY TRANSMITTER
VT044-1	FUEL QUANTITY TRANSMITTER
VT080	FUEL QUANTITY TRANSMITTER
VT081	FUEL QUANTITY TRANSMITTER
VT087-1	FUEL QUANTITY TRANSMITTER
VT087-2	FUEL QUANTITY TRANSMITTER
VT089-1	FUEL QUANTITY TRANSMITTER
VT089-11	FUEL PROBE
VT089-4	FUEL PROBE
VT089-9	FUEL PROBE
VT098-1	FUEL QUANTITY TRANSMITTER

VT108-2	LOW LEVEL PRESSUE SWITCH
VT246-14	TRANSMITTER
VT426	FUEL QUANTITY INDICATOR
VT426/1	FUEL QUANTITY INDICATOR
VT426-1	FUEL QUANTITY INDICATOR
VT426-10	FUEL QUANTITY INDICATOR
VT426-39	FUEL QUANTITY INDICATOR
VT426-40	FUEL QUANTITY INDICATOR
VT426-41	FUEL QUANTITY INDICATOR
VT443-40	FUEL QUANTITY INDICATOR
VT462-2	FUEL QUANTITY INDICATOR
VT462-4	FUEL QUANTITY INDICATOR
VT462-5	FUEL QUANTITY INDICATOR
VT476-2	FUEL QUANTITY INDICATOR
VT476-20	FUEL QUANTITY INDICATOR
VT477	HYDRAULIC QUANTITY INDICATOR
VT477-1	HYDRAULIC QUANTITY INDICATOR
VT477-2	HYDRAULIC QUANTITY INDICATOR
VT477-3	HYDRAULIC QUANTITY INDICATOR
VT484-4	FUEL QUANTITY INDICATOR
VT484-5	FUEL QUANTITY INDICATOR
W-33-7510	CLOCK
W-33-7510 ET	CLOCK
W33-7510-ET	CLOCK
W-33-7511	CLOCK
W-33-7511-10	CLOCK
W-33-7530-10	CLOCK
W-33-7530-101	CLOCK
W33-7530-102	CLOCK
W-33-7535-30	CLOCK
W-33-7535-302	CLOCK
W-33-7535-30-2	CLOCK
W33-7550-10A	CLOCK
WA310	AIRSPEED INDICATOR
WD01-45-91155-04	HANDGRIP
WD01-45-91157	HANDGRIP
WD01-45-91157/2	HANDGRIP
WD01-45-91157/3	HANDGRIP
WD01-45-91157/5	HANDGRIP
WD01-45-91159	HANDGRIP
WD0345-00010-041	HANDGRIP
WD4145-00008-041	HANDGRIP
WD4145-00010-041	HANDGRIP
WD47-45-00006-04	HANDGRIP
WL/1101AM/MS/2	ENCODING ALTIMETER
WL/113/AMA/JA/1	MACH AIRSPEED INDICATOR
WL/113AMA/JA/1	MACH AIRPSEED INDICATOR

WL/113AMA/JA/2	MACH AIRPSEED INDICATOR
WL/113AMA/JA/4	MACH AIRPSEED INDICATOR
WL/113AMA/JA/5	MACH AIRPSEED INDICATOR
WL/118AMA/JA/1	MACH AIRPSEED INDICATOR
WL/118AMA/JA/4	MACH AIRPSEED INDICATOR
WL/120AMA/JA/1	MACH AIRPSEED INDICATOR
WL/120AMA/JA/3	MACH AIRPSEED INDICATOR
WL/120AMA/JA/4	MACH AIRPSEED INDICATOR
WL/120AMA/JA/5	MACH AIRPSEED INDICATOR
WL/120AMA/JA/6	MACH AIRPSEED INDICATOR
WL/1401AM/MS/1	ENCODING ALTIMETER
WL/1401AM/MS/2	ENCODING ALTIMETER
WL/1401AM/MS/3	ENCODING ALTIMETER
WL/1401AM/MS/4	ENCODING ALTIMETER
WL/1403/AM/MS/1	ENCODING ALTIMETER
WL/1403/AM/MS/2	ENCODING ALTIMETER
WL/1403/AM/MS/3	ENCODING ALTIMETER
WL/1403/AM/MS/4	ENCODING ALTIMETER
WL/1403AM/MS/1	ENCODING ALTIMETER
WL/1403AM/MS/2	ENCODING ALTIMETER
WL/1403AM/MS/3	ENCODING ALTIMETER
WL/1403AM/MS/4	ENCODING ALTIMETER
WL/1403AM/MS/5	ENCODING ALTIMETER
WL/1404/AM/MS/1	ENCODING ALTIMETER
WL/1404/AM/MS/2	ENCODING ALTIMETER
WL/1404/AM/MS/3	ENCODING ALTIMETER
WL/1404/AM/MS/4	ENCODING ALTIMETER
WL/1404/AM/MS/5	ENCODING ALTIMETER
WL/1404/AM/MS/6	ENCODING ALTIMETER
WL/1404/AM/MS/7	ENCODING ALTIMETER
WL/1404/AM/MS/8	ENCODING ALTIMETER
WL/1404AM/MS/1	ENCODING ALTIMETER
WL/1404AM/MS/2	ENCODING ALTIMETER
WL/1404AM/MS/3	ENCODING ALTIMETER
WL/1404AM/MS/4	ENCODING ALTIMETER
WL/1404AM/MS/5	ENCODING ALTIMETER
WL/1404AM/MS/6	ENCODING ALTIMETER
WL/1404AM/MS/7	ENCODING ALTIMETER
WL/1404AM/MS/8	ENCODING ALTIMETER
WL/1407AM/MS/1	ENCODING ALTIMETER
WL/1407AM/MS/2	ENCODING ALTIMETER
WL/1407AM/MS/3	ENCODING ALTIMETER
WL/1407AM/MS/4	ENCODING ALTIMETER
WL1001KCA1	STANDBY COMPASS
WL101EED2	N1% RPM INDICATOR
WL101EED-2	N1 % RPM INDICATOR
WL101EED3	N1% RPM INDICATOR

WL101EED-3	N1 % RPM INDICATOR
WL102AMS1	ALTIMETER/AIRSPEED INDICATOR
WL102AMS2	ALTIMETER/AIRSPEED INDICATOR
WL102AMS3	ALTIMETER/AIRSPEED INDICATOR
WL102AMS4	ALTIMETER/AIRSPEED INDICATOR
WL102AMS5	ALTIMETER/AIRSPEED INDICATOR
WL102AMS6	ALTIMETER/AIRSPEED INDICATOR
WL1403AM/MS/1	ALTIMETER
WL1403AM/MS/2	ENCODING ALTIMETER
WL201EED2	N2 % RPM INDICATOR
WL202EED3	TEMPERATURE INDICATOR
WL202EED4	TEMPERATURE INDICATOR
WL202EED5	TEMPERATURE INDICATOR
WL202EED6	TEMPERATURE INDICATOR
WL203EED10	FUEL FLOW INDICATOR
WL203EED11	FUEL FLOW INDICATOR
WL203EED12	FUEL FLOW INDICATOR
WL203EED13	FUEL FLOW INDICATOR
WL203EED3	FUEL FLOW INDICATOR
WL203EED4	FUEL FLOW INDICATOR
WL203EED6	FUEL FLOW INDICATOR
WL203EED7	FUEL FLOW INDICATOR
WL203EED8	FUEL FLOW INDICATOR
WL203EED9	FUEL FLOW INDICATOR
WL501RC-1	RATE OF CLIMB INDICATOR
WL502RC-1	RATE OF CLIMB INDICATOR
WL503RC-1	RATE OF CLIMB INDICATOR
XW20345369-64	WIPER MOTOR
XW21173	MOTOR CONVERTER
XW21174 369 R64	MOTOR AND CONVERTeR ASSY RH
XW21174-369-L64	MOTOR AND CONVERTeR ASSY LH